Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IKIFLY HU9270

IKIFLY Floating TV Stand (Model HU9270) Instruction Manual

Wall Mounted Media Console with Rattan Door

1. Introduction

Thank you for choosing the IKIFLY Floating TV Stand, Model HU9270. This manual provides essential information for the safe assembly, operation, and maintenance of your new wall-mounted media console. Please read these instructions carefully before beginning assembly and retain them for future reference.

This floating TV stand is designed to accommodate televisions up to 75 inches, offering a modern aesthetic with practical storage solutions. It features a durable MDF board construction with a stylish rattan door and gold handle accents.

2. Safety Information

Adhering to these safety guidelines is crucial for preventing injury and damage to the product.

- Do not exceed the maximum weight capacity of 100 lbs on the countertop.
- Securely mount the TV stand to the wall using appropriate hardware for your wall type to prevent tip-over. Professional installation is recommended if you are unsure about wall mounting procedures.
- Be cautious when handling parts during assembly to avoid injury.
- Keep small parts and packaging materials away from children and pets.
- Ensure all connections are tight before placing items on the stand.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact IKIFLY customer support.

- 1x Floating TV Stand Unit
- 1x Assembly Manual
- Hardware Kit (screws, wall anchors, brackets, etc.)

4. Specifications

Feature	Detail
Model Number	HU9270
Material	MDF Board + Rattan
Product Dimensions (L x W x H)	57.7 x 9.3 x 10.5 inches
Item Weight	30 pounds
Maximum Weight Capacity (Countertop)	100 lbs
Recommended TV Size	Up to 75 inches



Figure 1: Product dimensions and weight capacity. The stand measures 57.7 inches long, 9.3 inches deep, and 10.5 inches high, with a countertop capacity of 100 lbs.

5. Setup and Assembly

Assembly requires basic tools (not included), such as a screwdriver and a drill for wall mounting. Follow the numbered steps in the included assembly manual for detailed instructions. The following is a general overview.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in your assembly manual to ensure all pieces and hardware are present.
2. **Assemble the Main Cabinet:** Follow the instructions to connect the side panels, top, and bottom boards using the provided fasteners. Ensure all connections are secure.
3. **Install Internal Shelves and Dividers:** Insert any internal shelves or dividers as indicated in the manual.
4. **Attach Rattan Door and Handle:** Secure the rattan door to the designated area. Install the gold handle onto the door.
5. **Prepare for Wall Mounting:** Determine the desired height and location for your TV stand on the wall. Use a level to mark the drilling points accurately. Ensure the wall material is suitable for mounting and use appropriate wall anchors (e.g., for drywall, concrete, or studs).
6. **Mount the Brackets:** Drill pilot holes and securely attach the wall mounting brackets to the wall using the provided hardware. Double-check that the brackets are level and firmly attached.
7. **Hang the TV Stand:** Carefully lift the assembled TV stand and align it with the wall mounting brackets. Secure the stand to the brackets according to the assembly manual's instructions. Ensure the stand is stable and level before proceeding.



Figure 2: The IKIFLY Floating TV Stand after successful assembly and wall mounting.

6. Operating Instructions

Your IKIFLY Floating TV Stand is designed for convenient storage and display.

- **Storage Compartments:** Utilize the open shelves and the compartment behind the rattan door for organizing media devices, remote controls, books, and decorative items.
- **Cable Management:** The stand may include pre-drilled holes or cutouts for cable routing. Use these to keep wires tidy and out of sight.
- **Rattan Door:** The hand-made rattan door provides breathability for electronics while offering a unique aesthetic. Open and close the door gently using the gold handle.



Figure 3: Interior view showcasing the storage capacity and cable management features.



Figure 4: Detail of the rattan door and gold handle.

7. Maintenance

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Rattan Care:** The rattan material is durable but can be sensitive to excessive moisture or direct sunlight. Keep it dry and avoid prolonged exposure to direct sun to prevent fading or brittleness.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight, especially those for wall mounting. Tighten if necessary.
- **Weight Distribution:** Distribute weight evenly across the stand's surface and shelves to maintain stability and prevent warping.

8. Troubleshooting

If you encounter any issues, refer to the following common solutions:

- **Stand feels unstable after mounting:** Ensure all wall mounting hardware is correctly installed and tightened. Verify that the wall material is appropriate for the chosen anchors. If unsure, consult a professional.
- **Door does not close properly:** Check the door hinges and alignment. Adjust screws on the hinges if necessary to ensure smooth operation.
- **Scratches or minor damage:** For minor scratches on the wood finish, a wood repair marker or furniture polish matching the color may be used.

9. Warranty and Support

IKIFLY products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the purchase documentation or contact IKIFLY customer service directly. If you have any questions, require replacement parts, or need further assistance, please reach out to our support team via the contact information provided at the point of purchase or on the official IKIFLY website.

IKIFLY Customer Service: Visit the IKIFLY Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDSWD21F

More documents and user manuals: **https://manuals.plus/**