Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hoement 1039J0KZP13HU0L

Hoement Glass Lampshade User Manual

Model: 1039J0KZP13HU0L

Introduction

Thank you for choosing the Hoement Glass Lampshade. This elegant and durable glass globe is designed to replace existing lampshades or enhance the aesthetic of various lighting fixtures, including pendant, wall, and table lamps. It diffuses light softly, creating a comfortable and inviting atmosphere. This manual provides essential information for safe installation, operation, and maintenance of your new lampshade.

Image: The Hoement Glass Lampshade, a clear spherical glass cover designed for light bulbs.

Safety Instructions

- Always disconnect power to the light fixture before installing or replacing the lampshade.
- Handle glass components with care to prevent breakage and injury.
- Ensure the lampshade is securely attached to the fixture to prevent it from falling.
- Do not use abrasive cleaners on the glass, as this may scratch or damage the surface.
- Keep out of reach of children.

Package Contents

Please verify that all components are present before proceeding with installation:

- 1 x Hoement Glass Lampshade

Setup and Installation

The Hoement Glass Lampshade is designed for easy installation. Follow these steps to attach it to your compatible light fixture:

1. **Prepare the Fixture:** Ensure the light fixture is turned off and disconnected from the power supply. Allow any existing bulb to cool down if it was recently in use.
2. **Remove Old Lampshade (if applicable):** Carefully remove any existing lampshade or cover from your light fixture according to its manufacturer's instructions.
3. **Attach the Lampshade:** The Hoement Glass Lampshade features a threaded opening designed to screw onto compatible bulb sockets or fixture bases. Align the threaded opening of the lampshade with the corresponding threads on your light fixture.
4. **Secure the Lampshade:** Gently screw the lampshade onto the fixture until it is snug and secure. Do not overtighten, as this may damage the glass or the fixture.
5. **Insert Bulb (if applicable):** If your fixture requires the bulb to be inserted after the lampshade, carefully screw in the appropriate light bulb.
6. **Restore Power:** Once the lampshade is securely installed and the bulb is in place, restore power to the light fixture.

Image: A hand demonstrating how to hold the glass lampshade, showing its size relative to a light bulb and fixture.

Image: A close-up view of the threaded opening of the glass lampshade, indicating how it attaches to a light fixture.

Image: A collage showing the versatility of the lampshade in various applications, including table lamps, bedroom lights, kitchen lamps, and cabinet lamps.

Operating the Lampshade

The Hoement Glass Lampshade functions as a decorative and light-diffusing element for your lighting fixture. Once installed, it requires no special operation beyond the normal use of your light fixture. It is designed to provide a soft, non-glaring light, enhancing the ambiance of your space.

Image: Multiple Hoement glass lampshades installed on pendant lights, glowing softly in a room, demonstrating their aesthetic appeal.

Image: Hoement glass lampshades integrated into a modern living space with a white armchair and blue wall, showcasing their decorative impact.

Maintenance and Care

To ensure the longevity and clarity of your Hoement Glass Lampshade, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the glass surface with a soft, damp cloth. For stubborn marks, a mild glass cleaner can be used. Ensure the cloth is lint-free to avoid streaks.
- **Drying:** Dry the lampshade immediately with a clean, dry cloth to prevent water spots.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the glass surface.
- **Regular Inspection:** Periodically check the lampshade for any signs of damage or looseness. If any damage is observed, replace the lampshade.

Troubleshooting

If you encounter any issues with your Hoement Glass Lampshade, consider the following common solutions:

- **Lampshade is Loose:** Ensure the lampshade is properly screwed onto the fixture's threads. Gently tighten until secure, but do not overtighten.
- **Lampshade Does Not Fit:** Verify that your light fixture's bulb socket or base is compatible with the threaded opening of the lampshade. This lampshade is designed for standard bulb fittings.
- **Glass Appears Cloudy/Dirty:** Clean the lampshade as per the 'Maintenance and Care' section. Ensure no residue from cleaning agents remains.
- **Lampshade is Damaged (Cracked/Chipped):** For safety, discontinue use immediately and replace the lampshade. Glass can shatter if damaged.

Specifications

Brand	Hoement
Model Number	1039J0KZP13HU0L
Material	Glass
Color	As Indicated (Clear)
Product Dimensions (L x W x H)	8 x 8 x 8 cm
Item Weight	50 g
Components Included	Lampshade

Warranty and Support

Specific warranty information for this product is not provided within this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product listing on the retailer's website or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2024 Hoement. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDSZW7LF

More documents and user manuals: **https://manuals.plus/**