

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Men's Chronograph Watch Model 2856 Instruction Manual

OLEVS 2856

OLEVS Men's Chronograph Watch Model 2856 Instruction Manual

Model: 2856

INTRODUCTION

Thank you for choosing the OLEVS Men's Chronograph Watch Model 2856. This timepiece combines classic design with modern functionality, featuring a precise quartz movement, chronograph subdials, and a durable stainless steel construction. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure its longevity and accurate performance.



Image: The OLEVS Men's Chronograph Watch Model 2856, featuring a gold-silver stainless steel band and a striking blue dial with multiple subdials.

SETUP

1. Adjusting the Watch Strap

Your OLEVS watch comes with a stainless steel bracelet. If the strap is too long, it can be adjusted by removing links. A free adjustable tool kit is typically included for this purpose. If you are unsure, it is recommended to have a professional jeweler adjust the strap to prevent damage.

2. Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (middle button on the right side) to position 2.
2. **Set the date:** Rotate the crown clockwise or counter-clockwise to set the correct date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.

3. **Set the time:** Pull the crown out further to position 3. Rotate the crown to set the hour and minute hands. Ensure the 24-hour subdial (if present) is also correctly aligned with AM/PM. Push the crown back to position 1 to start the watch.



Skeleton
Seconds Subdial



Minute
Subdial



24 Hours Moon
Phase Subdial



▼ Side Display

Start timing or pause button

Pull out the adjust the time

Chronograph reset button

Image: Side view of the watch, indicating the crown for time adjustment and the pushers for chronograph control.

OPERATING THE CHRONOGRAPH AND SUBDIALS

1. Chronograph Function

The chronograph allows you to measure elapsed time.

1. **Start:** Press the top pusher (button A) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the top pusher (button A) again to stop the chronograph. The elapsed time will be displayed.
3. **Reset:** Press the bottom pusher (button B) to reset the chronograph hands to their zero positions.

2. Reading Subdials

- **Minute Subdial:** Displays elapsed minutes during chronograph operation.
- **24-Hour / Moon Phase Subdial:** Indicates the time in a 24-hour format and may feature a moon phase indicator, showing day or night.
- **Skeleton Seconds Subdial:** A decorative subdial that shows continuous seconds movement.



OLEVS

PRODUCT PARAMETERS

Dial diameter: 42MM

Case thickness: 11.5MM

Band width: 20MM

Band length: 22CM

Watch weight: 129G

Warranty period: 2Years

**Note: Due to manual measurement, there may be slight differences between the actual size of the product and the data we provide.*

Image: A detailed view of the watch face, highlighting the minute, 24-hour/moon phase, and skeleton seconds subdials.

3. Luminous Hands and Markers

The watch features luminous hands and markers, allowing for readability in low-light conditions. These elements absorb light and glow in the dark.

MAINTENANCE

1. Water Resistance

This watch is water-resistant up to 30 meters (3ATM), suitable for daily splashing and brief immersion. It is not recommended for swimming, diving, or showering, especially with hot water, as temperature changes can affect the seals. Do not operate the crown or pushers when the watch is wet.

Excellent water resistance

Water resistant to 30M depth, easy to cope with dailysplashing and swimming activities.
(Note: All watches cannot be bathed in hot water.)



Image: An OLEVS watch demonstrating its water resistance against splashes.

2. Cleaning

To clean your watch, wipe the case and strap with a soft, dry cloth. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

Stainless steel

The straps are highly praised for their excellent performance and stylish appearance. They are strong and not easy to wear and tear.



Image: A close-up of the watch's stainless steel band, highlighting its durable construction.

3. Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Dead battery; Crown not pushed in	Replace battery (professional service recommended); Push crown fully into position 1.
Time/Date not setting	Crown not pulled out to correct position	Ensure crown is pulled out to position 2 (date) or position 3 (time).
Chronograph hands not resetting to zero	Requires calibration	Consult a watch technician for calibration.
Fogging under crystal	Moisture ingress	Indicates a breach in water resistance. Seek professional repair immediately to prevent further damage.

SPECIFICATIONS

Feature	Detail
Brand	OLEVS
Model Number	OPK-IN-G2856GG-GL (2856 Series)
Movement Type	Quartz
Display Type	Analog
Case Diameter	42 mm
Case Thickness	11.5 mm
Band Material	Stainless Steel
Band Width	20 mm
Band Length	22 cm
Crystal Material	Mineral Glass
Water Resistance Depth	30 Meters (3ATM)
Special Features	Chronograph, Luminous Hands, Date Display, 24-Hour Subdial
Item Weight	50 Grams



Image: Diagram illustrating the key dimensions of the OLEVS watch, including dial diameter, case thickness, and band width.

WARRANTY INFORMATION

This OLEVS watch comes with a 30-day return and exchange policy. For specific warranty details beyond this period, please refer to the documentation provided with your purchase or contact customer support.

CUSTOMER SUPPORT

For any questions, technical assistance, or service requests regarding your OLEVS watch, please contact the manufacturer or authorized service center.

Manufacturer: OLEVS, VALUECART PRIVATE LIMITED

Importer/Packer: VALUECART PRIVATE LIMITED

Please retain your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question