

YESGIGA 33 inch Infrared Electric Fireplace Insert

YESGIGA 33-inch Infrared Electric Fireplace Insert

Model: 33 inch Infrared Electric Fireplace Insert

[Safety](#) [Overview](#) [Setup](#) [Operation](#) [Maintenance & Support](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your YESGIGA 33-inch Infrared Electric Fireplace Insert. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

Your electric fireplace insert is designed with safety in mind, featuring CSA/UL certification for long-term service and user safety. It includes a double safety protection device: an overheat protection device that automatically cuts off power if the temperature becomes too high, and a fuse for additional protection.

WARNING: Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the unit is properly grounded.
- Do not operate the fireplace with a damaged cord or plug.
- Keep combustible materials at least 3 feet (0.9 m) away from the front of the fireplace.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening.
- Always unplug the fireplace when not in use.

PRODUCT OVERVIEW & FEATURES

The YESGIGA 33-inch Infrared Electric Fireplace Insert offers a smokeless firebox with a trim kit, designed to enhance your home decor while providing supplemental heat. Its infrared quartz heat helps maintain

natural humidity in the air, ensuring comfortable warmth without drying out the room.

Key Features:

- **CSA/UL Certified:** Ensures safety and reliability.
- **Double Safety Protection:** Overheat protection and fuse for enhanced safety.
- **Powerful Heating:** 1500W heat / 5018 BTUs per hour, providing supplemental heat for areas up to 400 sq. ft.
- **Versatile Installation:** Supports built-in wall with surround trims, insertion into a mantel, and built-in wall with U-shape trims.
- **Adjustable Flame & Ember Bed:** 5 levels of brightness and 3 levels of flame speed.
- **Timer Function:** Set operation time from 1 to 9 hours.
- **Temperature Control:** 11 temperature settings, ranging from 64°F to 82°F, with an 'ON' mode for continuous heating.
- **Flame-Only Mode:** Enjoy the 3D flame effect with or without heat.
- **Infrared Quartz Heat:** Maintains natural humidity for comfortable warmth.
- **Dual Power Connection:** Hardwired installation design or simple plug-in cord.



Figure 1: Overview of digital display, touch control panel, 3D flame effect, and power options.

Product Dimensions:



Figure 2: Detailed product and trim dimensions for installation planning.

Installation Methods:

The fireplace insert offers three primary installation methods:

1. **Built-in Wall with Surround Trims:** For a flush, integrated look within a wall.
2. **Insert to Mantel:** Designed to fit directly into an existing fireplace mantel opening.
3. **Built-in Wall with U-shape Trims:** Provides an alternative built-in option with specific trim aesthetics.

3 INSTALLATION METHODS



Method 1: Built in wall with surround trims.

Method 2: Built in wall with U shape trims.



Method 3: Insert to mantel.

Figure 3: Visual examples of the three available installation methods.

Power Connection:

Choose between two convenient power supply connection methods:

- **Hardwired Installation:** For a permanent and concealed power connection.
- **Simple Plug-in Cord:** For easy setup using a standard electrical outlet.



Figure 4: Hardwired installation details.



Figure 5: Plug-in cord connection details.



Figure 6: Rear view of the fireplace insert.

OPERATING INSTRUCTIONS

Your fireplace insert can be operated using either the touch control panel located on the unit or the included remote control.

Control Panel & Remote:

REMOTE & TOUCH CONTROL PANEL




Figure 7: Remote control and touch control panel layout.

- **Power ON/OFF:** Use the power button on the remote or touch panel to turn the unit on or off.
- **Heater ON/OFF:** Activate or deactivate the heating function independently of the flame effect.
- **Flame Effects:** Adjust flame brightness with 5 levels and flame speed with 3 levels.
- **Temperature Settings:** Select from 11 temperature settings (64°F to 82°F) or choose 'ON' for continuous heating.
- **Timer Function:** Set an automatic shut-off timer from 1 to 9 hours.

Flame & Heat Customization:

The realistic 3D flame effect can be enjoyed with or without the heating function, allowing for year-round ambiance. The flame and ember bed brightness can be adjusted to 5 different levels, and the flame speed can be set to 3 different levels to suit your preference.



Figure 8: Close-up of the realistic flame and log effect.

MAINTENANCE

To ensure the longevity and optimal performance of your electric fireplace insert, regular maintenance is recommended:

- **Cleaning:** Regularly wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.
- **Ventilation:** Ensure that the air intake and exhaust vents are clear of any obstructions to prevent overheating.
- **Log Set:** The realistic log set is designed for durability and requires no special maintenance.
- **Storage:** If storing the unit for an extended period, unplug it and store it in a dry, dust-free location.

TROUBLESHOOTING

If you encounter any issues with your fireplace insert, refer to the following common troubleshooting tips:

- **No Power:** Check if the unit is properly plugged into a working outlet. Verify the main power switch is on. Check the circuit breaker or fuse.

- **No Heat:** Ensure the heater function is activated. Check the temperature setting; it might be set lower than the room temperature.
- **Flames Not Working:** Verify the flame effect is turned on. Adjust flame brightness and speed settings.
- **Unit Overheating:** The overheat protection device may have activated. Unplug the unit, allow it to cool down, and check for any blocked vents before restarting.
- **Remote Not Working:** Check and replace batteries if necessary. Ensure there are no obstructions between the remote and the unit.

For persistent issues, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	YESGIGA
Model Name	electric fireplace
Size	33 inch
Product Dimensions	37.8"D x 9.4"W x 31.8"H
Material	Metal, Plastic, Tempered Glass
Color	Antique Black
Power Source	Electric
Heat Output	1500 Watts
Heating Coverage	400 sq ft
Ventilation Type	Vent Free
Included Components	Remote Control
Item Weight	66.4 pounds
ASIN	B0DDTYGZZT
UPC	703663919084

WARRANTY & SUPPORT

This product comes with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included in your product packaging or contact YESGIGA customer support.

For customer support, please refer to the contact information provided with your purchase or visit the manufacturer's official website.

