

119A W2090A W2091A W2092A W2093A

Generic 119A W2090A Toner Cartridge Instruction Manual

For HP 150A, 150NW, MFP 178FNW, MFP 179FNW Printers

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of Generic 119A W2090A series toner cartridges. These cartridges are designed to be compatible with specific HP printer models, ensuring reliable performance and print quality. Please read this manual carefully before installation and use.

COMPATIBILITY

This toner cartridge is compatible with the following models:

- **Toner Cartridge Models:** 119A W2090A, W2091A, W2092A, W2093A
- **Printer Models:** HP 150A, HP 150NW, HP MFP 178FNW, HP MFP 179FNW

Always confirm your printer model before purchasing to ensure compatibility. Some regional printer models may require specific chip replacements.

PRINTER COMPLATLITY



Compatible for Toner Cattridges:
119A W2090A W2091A W2092A W2093A
Compatible with Printers:
150A 150NW MFP 178FNW
MFP 179FNW



***Please confirm your printer model
before ordering**



This image illustrates the compatible toner cartridge and printer models.

SETUP AND INSTALLATION

Follow these steps to install the toner cartridge:

1. **Preparation:** Before installation, it is recommended to clean any remaining toner or paper scraps from the printer using a vacuum cleaner or a soft cloth. Avoid blowing air into the printer as this can spread toner dust.
2. **Shake the Cartridge:** Take the new toner cartridge out of its packaging and gently shake it horizontally 4-8 times. This helps to evenly distribute the toner powder inside the cartridge.
3. **Remove Protective Buckles:** Locate and remove the orange protective buckles on both sides of the toner cartridge.
4. **Remove Isolation Paper (if present):** If there is black isolation paper, slowly pull it out in the direction indicated.
5. **Pull the Seal:** Pull the sealing strip evenly and straight until it is fully removed. The length of the seal is approximately twice the length of the toner cartridge. Ensure it does not break during removal.
6. **Install into Printer:** Carefully push the toner cartridge smoothly along the guide rails on both sides of the printer device until

it clicks securely into place.

Important Note: Do not touch the drum core or the chip on the toner cartridge during installation to prevent damage and ensure optimal printing performance.

EASY TO INSTALL

Step 1

**Shake the toner 3-5 times
from side to side**



Step 2

**Remove the
anti-contamination plug**



Step 3

Pull out the seal



Step 4

Remove the protective cover



This image provides a visual guide for the toner cartridge installation steps.

OPERATING INSTRUCTIONS

Once the toner cartridge is correctly installed, your printer should automatically detect it. You can then proceed with your printing tasks as usual. The cartridge is designed for high-quality output in various scenarios.

Page Yield

The estimated page yield for these toner cartridges (at 5% A4 paper coverage) is:

- **Black Toner Cartridge (119A W2090A):** Up to 1000 pages
- **Color Toner Cartridges (119A W2091A, W2092A, W2093A):** Up to 700 pages

EXPECTED PAGE



5% coverage (A4 paper)

Black 1000 Pages

Color 700 Pages



This image illustrates the estimated page yield for black and color toner cartridges.

Print Quality

These cartridges are engineered to deliver clear text and bright colors, meeting high printing standards for various applications.

COLOR STANDARD

Professional color standards

Accurate color reproduction ability



Clear and Sharp
Black



Clear and Bright
Colors

This image highlights the clear and sharp black, and clear and bright color print quality.

PRINTOUT EXCELLEN



Name: Peacock
Protection level:
**National first-level
protected animal**

3900+

Introduction

Omnivorous. Mainly plant-based food, but also eat locusts, crickets, moths, termites, frogs, lizards and other animals. It mainly eats Sichuan pear, Huangpao fruits, young branches and leaves, buds, mushrooms, grass seeds, peas, rice and other plants and crops. It also eats grasshoppers, crickets, moths, termites, stink bugs, earthworms, lizards, frogs and other animals. food. In captivity, corn, wheat, bran, sorghum, soybeans, soybean cakes and grass are mainly grown.



Peacock distribution types

Congolese peacocks are rare in number and have a low reproduction rate. As of 2012, there were only about **2,500** peacocks in the wild, with a distribution range of only **700,000** square kilometers. Only about **150** of them are kept in captivity in zoos around the world.



Details Comparison

im

im

Do Not Fade

This image demonstrates the excellent print detail and fade resistance.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your toner cartridge and printer.

- **Storage:** Store unused toner cartridges in their original sealed packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Always handle toner cartridges carefully. Avoid touching the drum core or the electronic chip, as oils from your skin can affect print quality or cartridge recognition.
- **Printer Cleaning:** Regularly clean your printer according to its manufacturer's guidelines to prevent toner buildup and ensure smooth operation.

TROUBLESHOOTING

If you encounter issues with your toner cartridge, consider the following:

- **Printer Not Recognizing Cartridge:**
 - Ensure the cartridge is fully seated in its slot. Remove and re-install it firmly.
 - Check if the electronic chip on the cartridge is clean and free from obstructions. Gently wipe it with a dry, lint-free cloth if necessary.
 - Restart your printer and computer.
 - Some printer models or regional versions may require transferring the original chip to the new cartridge. Refer to your printer's specific instructions if this applies.
- **Poor Print Quality (Streaks, Fading, Inconsistent Color):**
 - Gently shake the toner cartridge horizontally to redistribute the toner.
 - Ensure all protective seals and covers were completely removed during installation.
 - Perform a printer head cleaning cycle through your printer's software or control panel (if applicable).
 - Check the toner level. If low, replace the cartridge.
- **Paper Jams:**
 - Ensure no paper scraps or debris are inside the printer.
 - Verify that the paper is loaded correctly and is not creased or damaged.

SPECIFICATIONS

Feature	Detail
Brand	Generic
Compatible Toner Models	119A W2090A, W2091A, W2092A, W2093A
Compatible Printer Models	HP 150A, 150NW, MFP 178FNW, MFP 179FNW
Black Page Yield (5% coverage)	Up to 1000 pages
Color Page Yield (5% coverage)	Up to 700 pages
Certifications	ISO9001, ISO14001
Item Weight	1 Kilogram (approximate)
Manufacturer	WANGDPJUE
Manufacturer Part Number	115218085

WARRANTY AND SUPPORT

While specific warranty details are not provided, we are committed to customer satisfaction. If you have any questions, concerns, or require assistance with your toner cartridge, please contact us directly. We guarantee to respond to your message within 24 hours and provide solutions to resolve your issue.

For support, please refer to the contact information provided with your purchase or on the product packaging.

USAGE SCENARIOS

These toner cartridges are suitable for a wide range of printing environments, including:

- Home use

- School and educational institutions
- Office environments
- Medical facilities
- Banks and financial institutions
- Retail and shopping centers

WIDE APPLICATION



Home



School



Office



This image illustrates the wide range of applications for this toner cartridge.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question