

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CoziBB](#) /

› [CoziBB 4-in-1 Toddler Slide and Swing Set \(Model CZ-SS01\) Instruction Manual](#)

CoziBB CZ-SS01

CoziBB 4-in-1 Toddler Slide and Swing Set

MODEL: CZ-SS01

Brand: CoziBB

1. SAFETY INFORMATION

This toy is to be assembled by an adult. It contains potentially hazardous sharp edges or points, or small parts in an unassembled state. Keep unassembled parts out of reach of children.

- Always supervise children during play.
- Ensure the playset is placed on a soft, level surface.
- Regularly check all connections and components for tightness and wear.
- Do not place the toddler slide in direct sunlight for extended periods, as this may shorten its service life.
- Maximum weight recommendation: 110 pounds.
- Recommended age range: 18-36 Months.

2. PRODUCT FEATURES

The CoziBB 4-in-1 Toddler Slide and Swing Set offers multiple play activities designed for toddlers aged 18-36 months.

- **Smooth Slide:** Features a heightened and lengthened slide (58 inches long) with four scientifically zoned areas: waiting zone, acceleration zone, deceleration zone, and extended buffer zone for a smooth and safe descent.
- **Sturdy Swing:** Includes a widened seat with T-shaped forward tilt protection for 360° surround safety. The swing offers four levels of height adjustment to accommodate your child's growth.
- **Climbing Frame:** Designed with a handle to provide effective support for children during climbing activities.
- **Basketball Hoop:** Comes with a matching soft basketball to help develop shooting skills, concentration, and physical coordination.



Image: Overview of the 4-in-1 playset features including the slide, climber, swing, and basketball hoop.

3. PACKAGE CONTENTS

Please ensure all components are present before beginning assembly:

- Slide components
- Swing components
- Basketball hoop
- Basketball (small, soft)
- Climber frame parts
- Installation tools
- Spare screws
- Instruction manual

Product Size

Designed For Children Aged 1-3 Years

Package



*Basketball



*Basketball Frame



*Giraffe Stickers



Max Load: 110lbs




Image: Visual representation of the playset's package contents, detailing each included item.

4. SETUP AND ASSEMBLY

Follow these steps for proper assembly. Refer to the detailed operating instructions provided in the package for visual guidance.

4.1. Slide Assembly

1. Connect the slide sections together using the provided fasteners. Ensure they are securely locked.
2. Attach the side panels of the slide to the main slide surface.
3. Secure all connections with the designated screws or locking mechanisms.

4.2. Climbing Ladder Assembly

1. Install the climbing pedals into the side frames of the ladder.
2. Attach the assembled ladder to the slide structure.
3. Secure all connections firmly.

4.3. Swing Assembly

1. Assemble the swing seat by connecting its base and backrest.
2. Attach the swing ropes to the swing seat and the top bar of the swing frame.
3. Connect the swing frame to the main playset structure.
4. For enhanced stability, fill the base of the swing supports with sand or water.

4.4. Basketball Hoop Assembly

1. Assemble the basketball hoop and net.
2. Attach the basketball hoop to the designated support on the playset.
3. Ensure it is securely fastened.

4.5. General Assembly Tips

- Use the provided installation tools and spare screws as needed.
- Ensure all parts click into place or are tightened securely to prevent wobbling.

Your browser does not support the video tag.

Video: Detailed assembly instructions for a toddler slide and swing set, demonstrating step-by-step construction.

Your browser does not support the video tag.

Video: Assembly guide for a toddler slide and swing set, showing how to connect various components.



Image: Demonstrates filling the playset's base with water or sand for increased stability during use.

5. OPERATING INSTRUCTIONS

This playset is designed for children aged 18-36 months. Always ensure proper supervision.

5.1. Using the Slide

- Ensure the child climbs the ladder safely, using the handholds.
- Instruct the child to sit down at the top of the slide before sliding.
- Ensure the landing area is clear before the child slides down.

Safer & Extended Slide

Heightened Guardrail More Secure




Image: Explains the scientifically designed slide zones for optimal safety and fun.

5.2. Using the Swing

- Place the child securely in the swing seat and fasten the T-bar protection.
- Adjust the swing height to one of the four available levels as the child grows.
- Gently push the swing, ensuring the child remains seated and secure.

Swing Fun & Height Adjustable



Image: Highlights the adjustable height feature and safety design of the swing.

5.3. Using the Basketball Hoop and Climber

- Encourage children to practice throwing the soft basketball into the hoop.
- Guide children to use the climbing frame, utilizing the integrated handle for support.

Basketball Hoop & Climber



Image: Shows children enjoying the basketball hoop and climbing features.

6. MAINTENANCE

- **Cleaning:** Wipe down all plastic surfaces with a damp cloth and mild soap. Rinse thoroughly and dry. Avoid harsh chemicals.
- **Inspection:** Periodically check all nuts, bolts, and connections to ensure they are tight. Replace any worn or damaged parts immediately.
- **Storage:** If storing outdoors, consider covering the playset to protect it from extreme weather conditions. For long-term storage, disassemble and store in a dry, cool place.

7. TROUBLESHOOTING

- **Playset is wobbly:** Ensure all connections are tightened. Verify that the base supports are filled with sand or water for maximum stability.
- **Parts do not fit:** Double-check the instruction manual to ensure you are using the correct parts for each step. Some parts may look similar but have subtle differences.

- **Missing parts:** Contact CoziBB customer support with your product model number and a description of the missing part.

8. SPECIFICATIONS

Attribute	Value
Brand	CoziBB
Model Number	CZ-SS01
Material	Plastic
Color	Lake Green
Age Range (Description)	18-36 Months
Maximum Weight Recommendation	110 Pounds
Item Weight	24.3 pounds
Package Dimensions	36.5 x 18.5 x 12 inches
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact CoziBB customer service. Refer to the contact details provided on the product packaging or the official CoziBB website.

