

[manuals.plus](#) /

› [OMAIC](#) /

› [OMAIC BN59-01432A Rechargeable Voice Remote for Samsung TV Instruction Manual](#)

## OMAIC BN59-01432A

# OMAIC BN59-01432A Rechargeable Voice Remote for Samsung TV Instruction Manual

Model: BN59-01432A | Brand: OMAIC

## 1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your OMAIC BN59-01432A Rechargeable Voice Remote. This remote is designed to be compatible with various Samsung Smart Frame, Curved, and QLED TVs, offering convenient control and voice command functionality.

## 2. PRODUCT FEATURES

- Sustainable Charging:** Features a USB Type-C port for recharging, reducing the need for frequent battery replacements.
- Voice Control:** Integrated voice function for convenient command input (compatible with self-voiced TVs).
- Quick Access Buttons:** Includes dedicated shortcut buttons for popular streaming services.
- Broad Compatibility:** Compatible with a wide range of Samsung Smart TV models and remote control models.
- Reliable Performance:** Tested for operation up to 45 feet, with buttons supporting 150,000 presses and a 0.1-second response time.

## 3. SETUP

### 3.1 Battery Installation & Initial Charge

The remote comes with a built-in Lithium Ion battery. Before first use, it is recommended to fully charge the remote. Connect the remote to a USB Type-C power source. Charging typically takes 1-2 hours.

# USB-C charging port

## No need to replace batteries frequently



Image: The OMAIC remote connected via its USB-C port to a wall adapter for charging. This port allows for convenient and sustainable power replenishment.

### 3.2 Pairing Instructions

To pair the remote with your Samsung TV, follow these steps:

1. Ensure your TV is powered on.
2. Press and hold the **Back** button (◀) and the **Play/Pause** button (▶) simultaneously for 5-8 seconds.
3. You will see a "Pairing Complete" message on your TV screen once successful.
4. If pairing fails, repeat the steps.



### Pair remote:

Pressing **Back** + **Play/Pause** buttons simultaneously for 10 seconds

## How to pair the remote with your TV?

Please press and hold the Back ( ) and Play/Pause ( ) buttons at the same time for 5-8 seconds and you will see the "Pairing Complete" message on your TV screen.

(If pairing fails, please repeat this step)

NOTE: Please charge the remote before first use, it takes about 1-2 hours.

Image: A visual guide illustrating the pairing process by holding down the Back and Play/Pause buttons on the remote, with a TV screen displaying 'Pairing Complete'.

## 4. OPERATING INSTRUCTIONS

### 4.1 Button Functions Overview



Image: A comprehensive diagram of the remote control, highlighting each button and its corresponding function for easy reference.

- **Power Button:** Press to turn the TV on or off. For Frame TVs, press once to switch to Art mode, press and hold to turn off the TV.
- **Voice Assistant (MIC button):** Activates the voice assistant. Press and hold to speak a command, then release.
- **123/EXTRA Button:** Accesses virtual numeric pad or color buttons. Use to enter numbers, change channels, or access extra functions.
- **Directional Pad (Up, Down, Left, Right):** Navigates menus and highlights items on the Home Screen.
- **Select Button (Center of D-Pad):** Confirms selection.
- **Return Button:** Returns to the previous menu. Press and hold to terminate a running program.
- **Home Button:** Navigates to the Home Screen.
- **Play/Pause Button:** Controls media playback. Press and hold for Game Bar in Game Mode.
- **Volume (+/-) Buttons:** Adjusts volume. Press to mute.
- **Channel (CH +/-) Buttons:** Changes channels. Press and hold for Guide screen or Channel List.

## 4.2 Voice Control

The voice function allows you to control your TV using spoken commands. Ensure your TV supports voice commands. Press and hold the MIC button, speak your command clearly, and then release the button. For example, you can say "Turn the volume up to 20".




Image: A person holding the OMAIC remote and speaking into it, with a speech bubble on the TV screen indicating a voice command like "Turn the volume up to 20".

## 4.3 Shortcut Buttons

The remote features four dedicated shortcut buttons for popular streaming services, allowing for quick access to your favorite content.

This remote control not only has **voice function**, but also has **4 shortcuts** to popular channels.

They make it easier and faster to jump to whatever channel you want.



Image: The OMAIC remote highlighting its four shortcut buttons for Netflix, TV Plus, Video, and Disney+, positioned next to a TV screen displaying various streaming app icons.

## 5. CHARGING

The OMAIC remote is equipped with a rechargeable Lithium Ion battery. To charge, connect a USB Type-C cable to the remote's charging port and to a power source. A full charge takes approximately 1-2 hours and provides up to 30 days of continuous use. The LED indicator will show charging status.

Your browser does not support the video tag.

Video: This video demonstrates the USB-C charging feature of the OMAIC Rechargeable Voice Remote, showing how to connect the cable and the remote's compact design.

## 6. COMPATIBILITY

This remote is compatible with a wide range of Samsung Smart TV models and remote control models. The voice function is specifically compatible with Samsung TVs that have built-in voice capabilities.

### 6.1 Compatible Remote Control Models:

- BN59-01432A, BN59-01455A, BP59-00149A, BN59-01456A, BN59-01312A, BN59-01266A, BN59-01385A, BN59-01391A, BN59-01330H, BN59-01330A, BN59-01363A, BN59-01357A, etc.

## 6.2 Compatible TV Models:

- QE1C, QN990C, LST9C, S90C, Q80C, Q80CD, CU8000D, Q70CD, QN85CD, QN90CD, Q60C, QN800C, QN900C, CU8000, QN850C, Q70C, QN85C, QN90C, S95C, Q80D, Q70D, Q60D, DU8000, QN90D, QN85D, S90D, S95D, QN800D, QN900D, LS03D, LS03B, LS03C, M70C, S9, M80C, M50C, LSP3B, G85SB, G7, G70B, G65B, M70B, M8, etc.

### Compatible with all Samsung Voice Model Smart TVs

The **voice function** is ONLY compatible with **self-voiced TV**. Please check if your TV set has voice function.



Image: A visual comparison of the OMAIC BN59-01432A remote alongside several other Samsung voice model smart TV remotes, illustrating its compatibility.

## 7. PERFORMANCE

The OMAIC remote control has undergone professional testing to ensure optimal performance. It can effectively operate your TV from various angles within a range of 45 feet. Each button is designed to withstand over 150,000 presses, and the remote boasts a rapid response time of just 0.1 seconds, ensuring a seamless user experience.



## Compatible with all Samsung Voice Model Smart TVs

The voice function is ONLY compatible with self-voiced TV.  
Please check if your TV set has voice function.



Image: A graphic detailing the performance stability of the remote, including its effective operating range of 45 feet, button durability of 150,000 clicks, and a quick response time of 0.2 seconds.

## 8. MAINTENANCE

- Keep the remote clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote to extreme temperatures, direct sunlight, or moisture.
- Do not drop the remote or subject it to strong impacts.
- If the remote is not used for an extended period, ensure it is fully charged before storage.

## 9. TROUBLESHOOTING

- **Remote Not Responding:** Ensure the remote is fully charged. If the battery is low, charge it using the USB-C port.
- **Pairing Issues:** If the remote does not pair automatically, try repeating the pairing steps (Section 3.2). Ensure there are no obstructions between the remote and the TV.
- **Voice Control Not Working:** Verify that your Samsung TV supports voice control. Ensure you are pressing and holding the MIC button while speaking.
- **Limited Range:** Ensure you are within the effective operating range of 45 feet and there are no significant obstacles blocking the signal.

## 10. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.5 x 1.3 x 0.3 inches

Item Weight	1.41 ounces
Item Model Number	BN59-01432A
Batteries	1 Lithium Ion battery (included, rechargeable)
Special Feature	Voice Search
Max Number of Supported Devices	18
Compatible Devices	Television

## 11. WARRANTY AND SUPPORT

The manufacturer offers 90 days of after-sales support for this product. If you encounter any issues or have questions regarding your OMAIC remote control, please contact customer support. The support team aims to reply within 24 hours and is dedicated to assisting you.

© 2026 OMAIC. All rights reserved.