

## ETENWOLF AIR 2 PRO

# ETENWOLF AIR 2 PRO Air Pump User Manual

**MODEL: AIR 2 PRO**

Your portable solution for fast inflation and deflation.

## 1. Introduction

Thank you for choosing the ETENWOLF AIR 2 PRO Air Pump. This compact and powerful device is designed for efficient inflation and deflation of various inflatable products, including air mattresses, pool floats, and vacuum storage bags. It also features a built-in LED light for added utility. Please read this manual thoroughly before use to ensure proper operation and maintenance.



The ETENWOLF AIR 2 PRO Air Pump, showcasing its small size and the various nozzles it comes with.

## 2. Safety Information

- Do not use this air pump for inflating SUPs, balloons, sports balls, car tires, or bicycles. It is specifically designed for low-pressure, high-volume inflatables.
- Keep out of reach of children.
- Do not block the air inlet or outlet during operation.
- Avoid prolonged continuous operation to prevent overheating. Allow the device to cool down if it becomes warm.
- Do not expose the pump to water or extreme temperatures.
- Use only the provided USB-C charging cable.

## 3. Package Contents

Verify that all items are present in your package:

- ETENWOLF AIR 2 PRO air pump

- 5 x Nozzles (various sizes for different inflatables)
- 1 x USB-C charging cable
- 1 x User manual (this document)

## 4. Specifications

Feature	Specification
Model Name	AIR 2 PRO
Brand	ETENWOLF
Color	White
Material	Plastic
Product Dimensions (L x W x H)	8.3" x 5.2" x 2.8"
Power Source	Battery Powered (3200 mAh Lithium Battery)
Air Flow Capacity	13 CFM (360 L/min)
Maximum Pressure	4.5 kPa (0.65 PSI)
Operation Mode	Automatic
LED Light Levels	60 lumens, 200 lumens, 600 lumens (with Strobe/SOS)
Charging Port	Type-C

# MINI AIR PUMP HIGH SPEED INFLATION



Key features and specifications of the ETENWOLF AIR 2 PRO Air Pump.

## 5. Setup

- Charging the Pump:** Before first use, fully charge the air pump using the provided USB-C cable. Connect the cable to the pump's Type-C port and a compatible USB power source (e.g., wall adapter, power bank). The charging indicator light will show charging status.
- Selecting the Correct Nozzle:** The pump comes with five different nozzles. Choose the nozzle that best fits the valve of the inflatable item.
- Attaching the Nozzle:** Firmly insert the selected nozzle into the inflation or deflation port of the air pump.

## 5 DIFFERENT NOZZLES





The five different nozzles provided, designed for various inflatable products.

## 6. Operating Instructions

### 6.1. Inflation

1. Attach the appropriate nozzle to the **inflation port** (usually the top or side where air blows out).
2. Insert the nozzle firmly into the valve of the item you wish to inflate.
3. Press the power button to start inflation. The pump will operate automatically.
4. Once the item is fully inflated, press the power button again to turn off the pump and remove the nozzle.

# 2X FASTER INFLATION & DEFLATION



The pump inflates an air mattress in approximately 1 minute and deflates in 40 seconds.

## 6.2. Deflation

1. Attach the appropriate nozzle to the **deflation port** (usually the bottom or side where air is sucked in).
2. Insert the nozzle firmly into the valve of the item you wish to deflate.
3. Press the power button to start deflation. The pump will automatically draw air out.
4. Once the item is deflated, press the power button again to turn off the pump and remove the nozzle.

## 6.3. Using as a Vacuum Storage Pump

1. Select the appropriate nozzle for your vacuum storage bag.
2. Attach the nozzle to the **deflation port** of the pump.
3. Place the nozzle over the vacuum valve of the storage bag.
4. Press the power button to start vacuuming. The pump will remove air from the bag.
5. Once the desired vacuum level is achieved, turn off the pump and seal the bag's valve.

## POWERFUL VACUUM PUMP, SAVE YOUR SPACE



The pump can effectively vacuum seal storage bags to save space.

### 6.4. LED Light Operation

The ETENWOLF AIR 2 PRO features a built-in LED light with three brightness levels and an SOS signal mode.

1. Press the light button (usually marked with a lightbulb icon) once to turn on the light at the lowest brightness (60 lumens).
2. Press the light button again to cycle through the brightness levels: 200 lumens, then 600 lumens.
3. A fourth press will activate the Strobe/SOS signal mode.
4. Press the light button a fifth time to turn off the LED light.



**3 LEVELS CAMPING LIGHTS  
WITH STOBE LIGHT AND SOS**

 60lm <b>50 hours</b>	 200lm <b>13 hours</b>	 600lm <b>4 hours</b>	 Strobe light <b>SOS signal</b>
---	--	---	--

The multi-level LED light provides illumination for various needs, including an SOS signal.

#### 6.5. Important Usage Notes

**ATTENTION: This air pump is NOT suitable for SUP, balloons, sports balls, car tires, or bicycles. Using it for these items may damage the pump or the item itself.**

# MULTIPLE USAGE SCENARIOS



Not Suitable for: Balloon, Yoga Ball, Sports Balls, Bicycle, SUP



Examples of suitable and unsuitable items for the ETENWOLF AIR 2 PRO Air Pump.

## 7. Maintenance

- Cleaning:** Wipe the exterior of the pump with a soft, dry cloth. Do not use abrasive cleaners or immerse the pump in water.
- Storage:** Store the pump and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
- Battery Care:** For optimal battery life, charge the pump at least once every three months if not in regular use.

## 8. Troubleshooting

Problem	Possible Cause	Solution
Pump does not turn on.	Low battery or no charge.	Charge the pump fully using the USB-C cable.

Problem	Possible Cause	Solution
Slow inflation/deflation.	Incorrect nozzle size or partially blocked port.	Ensure the correct nozzle is used and securely attached. Check for any obstructions in the air ports.
Pump overheats.	Prolonged continuous use.	Turn off the pump and allow it to cool down for at least 10-15 minutes before resuming use.
LED light not working.	Low battery or light button not pressed correctly.	Charge the pump. Press the light button firmly to cycle through modes.

## 9. Warranty and Support

The ETENWOLF AIR 2 PRO Air Pump comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or any questions regarding your ETENWOLF product, please contact our customer service team through the retailer's platform or visit the official ETENWOLF website for contact information. We are committed to providing excellent support for our products.