

[Manuals.plus](#) /

› [BRITA](#) /

› BRITA Cube Water Dispenser User Manual

BRITA 1055224

BRITA Cube Water Dispenser User Manual

Model: 1055224

Your guide to pure, filtered water at your desired temperature.

1. INTRODUCTION

The BRITA Cube Water Dispenser is designed to provide you with filtered hot and cold water on demand. Featuring advanced filtration and UV-C technology, it ensures clean, great-tasting water for all your needs. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the BRITA Cube Water Dispenser. Keep this manual for future reference.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Keep out of reach of children. The hot water dispensing feature can cause burns. Utilize the child safety lock.
- Only use genuine BRITA MAXTRA PRO filter cartridges.
- Unplug the appliance before cleaning or when not in use for extended periods.

3. PACKAGE CONTENTS

Verify that all components are present in the packaging:

- 1 x BRITA Cube Water Dispenser (White)
- 1 x MAXTRA PRO Extra Limescale Filter Cartridge
- 1 x Type C Power Connector
- 1 x User Manual and Installation Guide

4. PRODUCT OVERVIEW

The BRITA Cube features an intuitive control panel, a removable 4-liter water tank, and a magnetic drip tray with adjustable height.



Image: The BRITA Cube Water Dispenser, showcasing its sleek design, integrated filter, and removable drip tray.

5. SETUP

5.1 Unpacking and Initial Cleaning

Remove all packaging materials. Wipe the exterior of the dispenser with a damp cloth. Wash the water tank and drip tray with warm, soapy water, then rinse thoroughly.

5.2 Filter Installation

The BRITA Cube uses a MAXTRA PRO filter cartridge to reduce limescale and impurities.

1. Remove the new MAXTRA PRO filter cartridge from its packaging.
2. Submerge the filter in water for a few minutes to prime it.
3. Insert the filter firmly into the designated slot within the water tank.

Geniet van de pure smaak.

MAXTRA PRO filtratie verbetert de smaak van al jouw dranken aanzienlijk.




Image: A hand demonstrating the installation of a MAXTRA PRO filter cartridge into the water dispenser's tank.

5.3 Filling the Water Tank

The BRITA Cube has a 4-liter water tank with a convenient sliding lid for easy refilling.

1. Slide open the lid of the water tank.
2. Fill the tank with cold tap water. Do not exceed the maximum fill line.
3. Close the lid securely.

Wij zijn BRITA.

Een familiebedrijf
met meer dan 50 jaar
ervaring in waterfiltratie.



Image: A user filling the 4-liter water tank of the BRITA Cube from a kitchen faucet, highlighting the large capacity and ease of access.

5.4 Power Connection

Place the dispenser on a flat, stable surface. Connect the Type C power connector to the appliance and plug it into a suitable power outlet. The appliance will perform an initial self-check.

6. OPERATING INSTRUCTIONS

6.1 Temperature and Volume Selection

The BRITA Cube allows you to select your preferred water temperature and volume using the intuitive control panel.

- **Temperature Settings:** Ambient, 45°C, 65°C, 85°C, 95°C. Use the temperature control buttons to cycle through options.
- **Volume Settings:** 150 ml, 250 ml, 350 ml, 450 ml. Use the volume control buttons to select your desired cup size. The dispenser remembers your last selection.

5 seconden naar jouw vers gefilterde lievelingsdrank.

- ambient
- 45°C
- 65°C
- 85°C
- 95°C

- 150 ml
- 250 ml
- 350 ml
- 450 ml



Image: A close-up of the BRITA Cube's control panel, illustrating the touch-sensitive buttons for selecting water temperature and dispensing volume.

6.2 Dispensing Water

Once temperature and volume are set, press the dispense button to start. The BRITA Cube only heats the necessary amount of water, saving energy.



Voor je gemoedsrust:

Werkt met de innovatieve UV-C-technologie voor 99,999% bacterievrij water.

Image: The BRITA Cube dispensing hot water into a teacup, visually representing its energy-saving feature by only heating the required water volume.

6.3 Child Safety Lock

The BRITA Cube includes a child safety feature to prevent accidental hot water dispensing. Refer to the on-screen prompts or specific button combinations to activate/deactivate this lock.

6.4 Empty Water Tank Indicator

The dispenser will indicate when the water reservoir is empty, preventing dry heating and ensuring continuous operation.

7. MAINTENANCE

7.1 Cleaning the Unit

The BRITA Cube features an automatic cleaning indicator that illuminates if the unit has not been used for more than 24 hours. The unit is self-cleaning. Regularly clean the magnetic drip tray and the exterior of the dispenser with a soft, damp

cloth.

7.2 Filter Replacement

The dispenser will remind you when it's time to change the filter cartridge. Replace the MAXTRA PRO filter as indicated to maintain optimal water quality and extend the life of your dispenser.

7.3 UV-C Technology

The integrated UV-C technology ensures 99.999% bacteria-free water. This system operates automatically to purify the water as it is dispensed.



Image: A woman enjoying a drink, with an overlay illustrating the internal UV-C technology at work, ensuring bacteria-free water for peace of mind.

8. TROUBLESHOOTING

If you encounter any issues with your BRITA Cube, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water dispensed	Water tank empty; Power not connected; Child safety lock active.	Refill water tank; Check power connection; Deactivate child safety lock.
Water not heating	Incorrect temperature setting; Appliance malfunction.	Verify temperature setting; Contact customer support if issue persists.
Slow water flow	Filter cartridge clogged or needs replacement.	Replace MAXTRA PRO filter cartridge.
Unusual taste/odor	Filter cartridge needs replacement; First use.	Replace filter; Run a few cycles of water through the system during first use.

For issues not listed here, please contact BRITA customer support.

9. SPECIFICATIONS

- **Model Name:** BRITA Cube
- **Model Number:** 1055224
- **Dimensions (L x W x H):** 43.5 x 34 x 25.5 cm
- **Weight:** 4.78 kg
- **Material:** Plastic
- **Capacity:** 4 Liters
- **Power Source:** Wired
- **Installation Type:** Freestanding
- **Special Feature:** Temperature Control (Ambient, 45°C, 65°C, 85°C, 95°C)
- **Included Components:** MAXTRA PRO Extra Limescale Filter Cartridge

10. WARRANTY AND SUPPORT

Your BRITA Cube Water Dispenser comes with a manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. For technical support, spare parts, or any inquiries, please visit the official BRITA website or contact their customer service department.

By choosing BRITA, you actively contribute to reducing single-use plastics and lowering your carbon footprint.

© 2025 BRITA. All rights reserved.
For more information, visit www.brita.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DDXVYRYT>

More documents and user manuals: <https://manuals.plus/>