

[Manuals.plus](#) /

› [Rapoo](#) /

› Rapoo E9350L Bluetooth Wireless Multi-Device Keyboard Instruction Manual

Rapoo E9350L White

Rapoo E9350L Bluetooth Wireless Multi-Device Keyboard

Model: E9350L White | **Brand:** Rapoo

Your comprehensive guide to setup, operation, and maintenance.

[Overview](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

1. PRODUCT OVERVIEW

The Rapoo E9350L is an ultra-thin, ergonomic Bluetooth wireless multi-device keyboard designed for seamless connectivity across up to four devices. It features a full-size layout with a numpad, LED indicators for device connection and Caps Lock, and is compatible with Windows, iOS, Android, tablets, and smartphones. Its durable aluminum alloy base and accurate scissor key structure provide a comfortable and reliable typing experience.



Image: The Rapoo E9350L Bluetooth Wireless Multi-Device Keyboard in white, showcasing its ultra-thin design and full key layout.




Image: The Rapoo E9350L keyboard on a desk, highlighting its intelligent, compact, and comfortable design.

2. SETUP AND INITIAL USE

2.1 Charging the Keyboard

Before first use, fully charge the keyboard using the provided Type-C cable. The keyboard features a 500mAh lithium battery, which takes approximately 1 hour and 15 minutes to reach full charge, providing up to 240 hours of working time.



Image: Close-up of the keyboard's Type-C charging port, indicating fast charging capability.

2.2 Power On/Off

Locate the power switch on the keyboard, typically on the side or back. Slide it to the 'ON' position to power on the device. Slide it to 'OFF' when not in use to conserve battery.

2.3 Multi-Device Connectivity and Pairing

The Rapoo E9350L supports connection to up to four devices via Bluetooth 4.0, Bluetooth 5.0, and 2.4G wireless technology. The keyboard automatically pairs with the active device and allows for easy switching.

1. **Bluetooth Pairing:** Turn on the keyboard. Press and hold one of the device keys (e.g., F1, F2, F3, F4) until

the corresponding LED indicator blinks rapidly. On your device (computer, tablet, smartphone), enable Bluetooth and search for 'Rapoo E9350L'. Select it to pair. The LED will become solid once connected.

2. **2.4G Wireless Connection:** For devices supporting 2.4G, plug the USB receiver (if included, typically stored in the keyboard's battery compartment) into your device's USB port. The keyboard should automatically connect.
3. **Switching Devices:** Once paired with multiple devices, simply press the corresponding device key (F1, F2, F3, or F4) to switch between them. The LED indicator will show which device is currently active.




Image: Diagram illustrating the multi-device connectivity of the Rapoo E9350L keyboard, showing connections to a laptop, desktop, tablet, and smartphone.

2.4 Windows & Mac Compatibility

The E9350L supports both Windows and Mac OS dual system key functions, allowing you to adapt the keyboard layout to your operating system with a single click.

- To switch to **Mac OS** mode, press the **Fn + Q** keys. The 'Q' key will function as the Mac 'cmd' key.
- To switch to **Windows OS** mode, press the **Fn + W** keys. The 'W' key will function as the Windows 'Win' key.



WINDOWS & MAC COMPATABILITY

Designed to work the operating system of your choice with zero effort switching

Image: Visual representation of the keyboard's Windows and Mac compatibility, showing the 'Q' (Mac) and 'W' (Win) keys for switching operating systems.

3. OPERATING INSTRUCTIONS

3.1 Basic Keyboard Functions

The keyboard operates like a standard full-size keyboard. All alphanumeric keys, punctuation, and modifier keys (Shift, Ctrl, Alt) function as expected based on your selected operating system mode.

3.2 Function Keys and Multimedia Controls

The top row of keys (F1-F12) also serves as multimedia and shortcut keys. To activate their secondary functions, press the **Fn** key simultaneously with the desired function key.

- **Fn + F1:** Home
- **Fn + F2:** Email
- **Fn + F3:** Music
- **Fn + F4:** Play/Pause

- **Fn + F5:** Previous Track
- **Fn + F6:** Next Track
- **Fn + F7:** Mute
- **Fn + F8:** Volume Down
- **Fn + F9:** Volume Up
- **Fn + F10:** Search
- **Fn + F11:** My Computer
- **Fn + F12:** Calculator




Image: Close-up of the keyboard's function keys, highlighting their multimedia and shortcut icons.

3.3 Numpad Usage

The integrated numpad on the right side of the keyboard functions as a standard numeric keypad. Ensure Num Lock is enabled if numbers are not registering.



Image: The numpad section of the keyboard highlighted, indicating its functionality.

3.4 LED Indicators

The keyboard features LED indicators to provide real-time status updates:

- **Device Light:** Indicates which of the four connected devices is currently active. It also blinks during pairing mode.
- **Battery Light:** Illuminates to indicate low battery or charging status.

- **Caps Lock Indicator:** Shows when Caps Lock is active.



LED INDICATORS

Stay focused and connected to your operational status with minimal effort

Image: Overhead view of the keyboard highlighting the locations of the Device Light, Battery Light, and Caps Lock LED indicators.

4. MAINTENANCE

4.1 Cleaning

To clean your Rapoo E9350L keyboard, use a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Avoid spraying liquids directly onto the keyboard or using harsh chemicals.

4.2 Battery Care

To prolong battery life, avoid fully discharging the keyboard frequently. Recharge the keyboard when the battery indicator light suggests low power. Store the keyboard in a cool, dry place when not in use for extended periods.

4.3 Storage

When storing the keyboard, especially for long durations, ensure it is powered off. Keep it away from extreme

temperatures, direct sunlight, and high humidity to prevent damage.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not connecting/pairing.	Low battery, out of range, incorrect pairing mode, interference, device Bluetooth off.	Ensure keyboard is charged. Move closer to the device (within 30ft range). Re-enter pairing mode. Check device's Bluetooth settings. Turn off other wireless devices causing interference.
Keys not responding.	Keyboard off, low battery, connection lost, software issue.	Turn keyboard off and on again. Recharge the keyboard. Re-establish connection. Restart your computer/device.
LED indicators not working.	Keyboard off, battery fully drained, malfunction.	Ensure keyboard is powered on. Charge the keyboard. If issue persists, contact support.
Incorrect key output (e.g., Mac keys on Windows).	Wrong operating system mode selected.	Press Fn + W for Windows mode or Fn + Q for Mac mode.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Rapoo
Model Number	E9350L White
Colour	White
Connectivity Technology	Bluetooth (4.0, 5.0), RF (2.4G)
Compatible Devices	Laptop, Smart TV, Smartphone, Tablet
Keyboard Description	Membrane (Scissor Key Structure)
Product Dimensions	11.9 x 2.9 x 36.3 cm
Item Weight	366 g
Batteries	1 Lithium Ion battery (included)
Lithium Battery Energy Content	500 Milliamp Hours (mAh)
Power Source	Battery Powered
Operating System Compatibility	Windows, iOS, Android, Mac OS
Manufacturer	Shenzhen Rapoo Technology Co., Ltd.

Feature	Detail
Country of Origin	India



Image: Diagram showing the slim and compact dimensions of the Rapoo E9350L keyboard (363mm x 119mm x 5.3mm).

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Rapoo E9350L Bluetooth Wireless Multi-Device Keyboard comes with a **3-Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use conditions.

7.2 Manufacturer and Importer

- **Manufacturer:** Shenzhen Rapoo Technology Co., Ltd., 22, Jinxiu Road East, Pingshan District, Shenzhen, China

- **Importer:** Supertron Electronics Pvt Ltd

7.3 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Rapoo customer support through their official website or the retailer where the product was purchased. Always provide your product model number (E9350L White) and purchase details when seeking support.

© 2024 Rapoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question