

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› ZEBRONICS Sheer Rechargeable Wireless Mouse (Model ZEB-SHEER) Instruction Manual

ZEBRONICS ZEB-SHEER

ZEBRONICS Sheer Rechargeable Wireless Mouse

MODEL: ZEB-SHEER - INSTRUCTION MANUAL

INTRODUCTION

The ZEBRONICS Sheer is a versatile rechargeable wireless mouse designed for comfort and efficiency. Featuring a transparent body with RGB LED lights, it offers dual connectivity modes (2.4GHz and Bluetooth) and silent operation. This manual provides detailed instructions for setting up, operating, and maintaining your ZEB-SHEER mouse.

PACKAGE CONTENTS

- Mouse - 1 unit
- USB Nano Receiver - 1 unit
- Charging cable - 1 unit
- Quick User Guide - 1 unit

PRODUCT OVERVIEW

Familiarize yourself with the components of your ZEB-SHEER mouse.






Image: Top view of the ZEB-SHEER mouse, highlighting the Left Click, Right Click, Scroll Wheel, DPI button, and Dedicated Desktop Button.

High Precision



USB Nano Receiver

Image: Bottom view of the ZEB-SHEER mouse, showing the On/Off switch and the Mode Switch (2.4G, BT1, BT2).

SETUP AND CONNECTIVITY

The ZEB-SHEER mouse offers two primary connection methods: 2.4GHz wireless via USB nano receiver and Bluetooth.

1. 2.4GHz Wireless Connection

1. Locate the USB nano receiver: The receiver is stored magnetically under the top panel of the mouse. Gently lift the top cover to access it.



Image: The ZEB-SHEER mouse with its top cover removed, revealing the USB nano receiver stored within.

2. Insert the receiver: Plug the USB nano receiver into an available USB port on your computer or laptop.
3. Power on the mouse: Flip the On/Off switch on the bottom of the mouse to the 'On' position.
4. Select 2.4G mode: Use the Mode Switch on the bottom of the mouse to select '2.4G'. The mouse should automatically connect to your device.

2. Bluetooth Connection (BT1 / BT2)

The ZEB-SHEER supports two independent Bluetooth connections, allowing seamless switching between two devices.

1. Power on the mouse: Ensure the On/Off switch on the bottom of the mouse is in the 'On' position.
2. Select Bluetooth mode: Use the Mode Switch on the bottom of the mouse to select either 'BT1' or 'BT2'.
3. Enter pairing mode: Press and hold the Mode Switch for a few seconds until the LED indicator on the mouse starts blinking, indicating it is in pairing mode.
4. Pair with your device: On your computer, laptop, or Mac, go to Bluetooth settings and search for new devices. Select "ZEB-SHEER" from the list to pair.
5. Switching between devices: To switch between BT1 and BT2, simply toggle the Mode Switch to the desired

Dual Bluetooth & Connectivity Mode : Connect via USB Wireless Nano Receiver or Bluetooth



Image: The ZEB-SHEER mouse connected to both a laptop via 2.4GHz and a smartphone via Bluetooth, illustrating its dual mode capability.

OPERATING INSTRUCTIONS

DPI Adjustment

The ZEB-SHEER mouse features a 4-level DPI switch, allowing you to adjust cursor sensitivity for different tasks.

- Press the **DPI button** (located near the scroll wheel) to cycle through the available DPI settings: 800, 1200, 1600, and 2400.
- Each press will change the sensitivity, allowing you to find the optimal speed for your work or gaming.

Upto 2400 Level DPI




Image: A visual representation of the ZEB-SHEER mouse's DPI levels, ranging from 800 to 2400.

Button Functions

The mouse is equipped with 5 buttons for enhanced functionality:

- **Left Click:** Standard selection and activation.
- **Right Click:** Context menu access.
- **Scroll Wheel:** Scroll up/down, and middle click for various functions.
- **DPI Control Switch:** Adjusts cursor sensitivity.
- **Dedicated Desktop Button:** Quickly minimizes all open windows to show the desktop.

Silent Operation

The ZEB-SHEER mouse features silent click buttons, providing a quiet working environment without disruptive clicking sounds.

Charging the Mouse

The mouse has a built-in rechargeable battery and supports Type-C charging.

- Connect the provided Type-C charging cable to the charging port on the front of the mouse.
- Plug the other end of the cable into a USB power source (e.g., computer USB port, wall adapter).
- The LED indicator will show charging status.



Image: The ZEB-SHEER mouse connected to a Type-C charging cable, illustrating the charging process.

Battery Indicator

The LED indicator on the mouse provides quick updates on battery life and connectivity status.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Storage:** When not in use, store the USB nano receiver inside the mouse to prevent loss. Keep the mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Recharge the mouse regularly to maintain battery health. Avoid fully draining the battery frequently.

TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the mouse is powered on.
 - Check battery level and charge if necessary.
 - For 2.4GHz mode, ensure the USB nano receiver is securely plugged into a working USB port and the mouse is set to '2.4G' mode.
 - For Bluetooth mode, ensure Bluetooth is enabled on your device, the mouse is set to 'BT1' or 'BT2', and it is properly paired. Try re-pairing if connection is lost.
- **Cursor movement is erratic or slow:**
 - Clean the optical sensor on the bottom of the mouse.
 - Ensure you are using the mouse on a suitable surface (a mouse pad is recommended).
 - Adjust the DPI setting using the DPI button on the mouse.
- **Charging issues:**
 - Ensure the Type-C cable is correctly connected to both the mouse and the power source.
 - Try a different USB port or power adapter.
 - Verify the charging cable is not damaged.

SPECIFICATIONS

Feature	Detail
Brand	ZEBRONICS
Model Number	ZEB-SHEER
Connectivity Technology	Wireless (2.4GHz, Bluetooth)
Movement Detection Technology	Optical
DPI Levels	800, 1200, 1600, 2400 (Adjustable)
Number of Buttons	5 (Left, Right, Scroll, DPI, Dedicated Desktop)
Power Source	Battery Powered (Rechargeable)
Charging Port	Type-C
Operating System Compatibility	Linux, Windows 7, Windows XP (and newer versions)
Item Weight	72 g
Product Dimensions (LxWxH)	11 x 5.7 x 0.1 cm

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official ZEBRONICS website or contact their customer service. Keep your purchase receipt for warranty claims.

For further assistance, visit the [ZEBRONICS Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question