

TWS

Generic TWS 5.3 Wireless Bluetooth Earphones User Manual

Model: TWS

INTRODUCTION

Thank you for choosing the Generic TWS 5.3 Wireless Bluetooth Earphones. These earphones are designed to provide a high-quality audio experience with the convenience of wireless connectivity. Featuring Bluetooth 5.3 technology, an integrated microphone, and noise cancellation capabilities, they are suitable for various activities, from listening to music to making calls.

This manual provides essential information on how to set up, operate, and maintain your earphones. Please read it carefully before use to ensure proper functionality and longevity of the product.

SAFETY INFORMATION

- Do not expose the earphones or charging case to extreme temperatures, humidity, or corrosive environments.
- Avoid dropping, impacting, or disassembling the device.
- Keep the earphones away from water and liquids. If they come into contact with liquid, wipe them dry immediately.
- Do not use abrasive cleaners or harsh chemicals to clean the earphones.
- Listen at moderate volume levels to prevent hearing damage. Prolonged exposure to loud sounds can cause irreversible hearing loss.
- Keep out of reach of children and pets.

PACKAGE CONTENTS

Please check the package for the following items:

- Generic TWS 5.3 Wireless Bluetooth Earphones (1 Pair)
- Charging Case
- Charging Cable

- User Manual (This document)

PRODUCT OVERVIEW



Image: The Generic TWS 5.3 Wireless Bluetooth Earphones are shown inside their open charging case. The black earbuds are nestled in their respective slots, and the charging case features LED indicator lights on the front, indicating battery status.

The TWS 5.3 earphones consist of two earbuds (left and right) and a portable charging case. The charging case not only protects the earphones but also recharges them on the go. Each earbud is equipped with touch controls for easy management of music and calls.

Bluetooth™ 5.0



5.0 Bluetooth chip



HiFi sound quality



10m connection
distance



Light and no
oppression

Image: A single earbud is depicted being worn in an ear, illustrating its ergonomic fit. The image also highlights key features such as Bluetooth 5.0 chip, HiFi sound quality, 10-meter connection distance, and a lightweight design for comfortable wear.

SETUP

1. Charging the Earphones and Case

1. **Initial Charge:** Before first use, fully charge both the earphones and the charging case.
2. **Charging the Case:** Connect the provided charging cable to the charging port on the case and a USB power source. The LED indicators on the case will illuminate to show charging progress.
3. **Charging the Earphones:** Place the earphones into their respective slots in the charging case. Ensure they are correctly seated. The earphones will automatically begin charging. The LED indicators on the earphones or case will confirm charging status.

Note: The charging case uses a Lithium Polymer battery and acts as a portable power bank for the earphones.

2. Pairing with a Device



Bluetooth 5.0



Windows



iOS



Android

Image: This graphic illustrates the broad compatibility of the Bluetooth 5.0 earphones, showing icons for Windows, iOS, and Android operating systems, indicating seamless connection across various devices.

1. **Power On:** Take both earphones out of the charging case. They will automatically power on and attempt to pair with each other. You may hear an audible prompt.
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer, etc.), enable Bluetooth.
3. **Search for Devices:** In your device's Bluetooth settings, search for available devices. You should see "TWS" or a similar name appear in the list.
4. **Connect:** Select "TWS" to connect. Once connected, you will hear a confirmation sound, and the earphone indicator lights may change.
5. **Single Earbud Mode:** You can also use a single earbud independently. Simply take one earbud out of the case, and it will enter pairing mode.

Compatible devices include smartphones, tablets, computers (desktops, laptops, notebooks), televisions, and car audio systems with Bluetooth capabilities.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Take the earphones out of the charging case. They will power on automatically. Alternatively, press and hold the touch control area on both earbuds for a few seconds.
- **Power Off:** Place the earphones back into the charging case. They will power off.

automatically. Alternatively, press and hold the touch control area on both earbuds for a few seconds until you hear a power-off prompt.

Music Playback Controls (Touch Control)

- **Play/Pause:** Tap the touch control area on either earbud once.
- **Next Track:** Double-tap the touch control area on the **right** earbud.
- **Previous Track:** Double-tap the touch control area on the **left** earbud.
- **Volume Up:** Triple-tap the touch control area on the **right** earbud.
- **Volume Down:** Triple-tap the touch control area on the **left** earbud.

Call Management (Touch Control)

- **Answer/End Call:** Tap the touch control area on either earbud once.
- **Reject Call:** Press and hold the touch control area on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earbud for 3 seconds until you hear a prompt.

MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earphones and charging case. Do not use liquids or sprays.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earphones and charging case frequently. Charge them regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Solution
Earphones do not power on.	Ensure the earphones are charged. Place them in the charging case and check the charging indicators.
Earphones do not pair with each other.	Place both earphones back into the charging case, close the lid, then open it and take them out again. This should force them to re-pair.
Earphones do not connect to my device.	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on your device. • Make sure the earphones are in pairing mode. • Forget "TWS" from your device's Bluetooth list and try pairing again. • Ensure the earphones are sufficiently charged.
No sound or low volume.	<ul style="list-style-type: none"> • Check the volume level on both your device and the earphones. • Ensure the earphones are properly connected to your device. • Clean any debris from the earbud nozzles.
Charging case not charging.	<ul style="list-style-type: none"> • Verify the charging cable is securely connected to both the case and the power source. • Try a different charging cable or power adapter.

SPECIFICATIONS

Feature	Detail
Model Name	TWS
Connectivity Technology	Wireless, Bluetooth 5.3
Noise Control	Sound Isolation, Noise Cancellation
Microphone	Integrated
Control Method	Touch
Earbud Form Factor	In-ear (Intra-auriculares)
Impedance	2 Ohm
Power Source	Internal Battery (Lithium Polymer)
Special Features	Rechargeable Battery, Detachable Cable (for charging case), Noise Cancellation, Lightweight, Sweatproof
Product Weight	100 g
Included Components	Cable, Charging Station

WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty of **30 days** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims or technical support, please contact your retailer or the point of purchase with your proof of purchase.

Please note that the warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.