Silonn 35B

Silonn Portable Ice Maker User Manual

Model: 35B | Brand: Silonn

Introduction

Thank you for choosing the Silonn Portable Ice Maker. This compact and efficient appliance is designed to provide you with fresh ice quickly and conveniently, perfect for various settings from your home kitchen to an RV. With its rapid ice production and user-friendly features, you'll always have ice on hand for your beverages and cooling needs.



The Silonn Portable Ice Maker, ready to produce fresh ice for your drinks.

Safety Instructions

Please read all instructions carefully before operating the ice maker to ensure safe and optimal performance.

- Always connect the appliance to a grounded power outlet.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Ensure adequate ventilation around the unit. Do not block the air vents.
- Use only purified or distilled water to prevent mineral buildup and ensure ice quality.
- Keep the appliance away from heat sources and direct sunlight.
- Unplug the ice maker before cleaning or when not in use for extended periods.
- Do not use mechanical devices to defrost the ice maker. Flammable refrigerant is used. Do not puncture refrigerant tubing.

What's in the Box

- Ice maker
- Ice Scoop
- Ice Basket
- User manual

Setup

Initial Cleaning

Before first use, wipe down the interior of the ice maker, including the water tank and ice basket, with a soft cloth and mild detergent. Rinse thoroughly. It is recommended to discard the first two batches of ice produced to ensure cleanliness.

Placement

Place the ice maker on a stable, level surface. Ensure there is at least 5 inches of clearance around the unit for proper ventilation. The compact dimensions of 13.15"D x 8.98"W x 11.14"H allow it to fit seamlessly on most countertops.



The compact dimensions of the Silonn ice maker make it suitable for various spaces.

Water Filling

Open the lid and remove the ice basket. Fill the 1.8L water tank with purified or distilled water up to the 'MAX' fill line indicated inside the reservoir. Do not overfill.



The Silonn ice maker features a generous 1.8L water tank for fewer refills.

Operating Instructions

Power On/Off

Press the 'ON/OFF' button on the control panel to turn the ice maker on or off. The 'POWER' indicator light will illuminate

when the unit is active.

Ice Production Cycle

Once powered on and water is added, the ice maker will automatically begin the ice-making cycle. It produces 9 bullet-shaped ice cubes in approximately 6 minutes. The machine has a daily output capacity of up to 22 lbs.



Enjoy fresh ice in minutes with the Silonn Portable Ice Maker.

Ice Size Selection

Press the 'SELECT' button to choose between small (S) or large (L) ice cube sizes. The corresponding indicator light will illuminate.



Choose between small ice cubes for drinks like juice or coffee, and large cubes for whiskey or chilling food.

Indicator Lights

- **ADD WATER:** Illuminates when the water tank needs refilling.
- **ICE FULL:** Illuminates when the ice basket is full, and the machine will pause ice production.



The user-friendly control panel with LED indicators for easy operation.


Portability

The integrated carry handle allows for easy transportation of the ice maker, making it convenient for various locations.

Maintenance

Self-Cleaning Mode

The ice maker features a convenient self-cleaning mode. To activate, ensure the unit is powered on and has water. Press and hold the 'ON/OFF/CLEAN' button for a few seconds until the 'CLEAN' indicator light illuminates. The machine will run a cleaning cycle.



The self-cleaning function ensures fresh and clean ice with minimal effort.

Draining Water

To drain residual water from the tank, locate the drain plug at the bottom of the unit. Place a container underneath and remove the plug to allow water to flow out. Replace the plug securely after draining.

Regular Cleaning

Regularly wipe the exterior and interior surfaces with a soft, damp cloth. For thorough cleaning, you may use a mild, food-safe cleaning solution. Ensure all parts are dry before reassembling and operating the unit.

Troubleshooting

- **Ice Not Forming:** Check if the unit is plugged in and powered on. Ensure there is sufficient water in the reservoir.
- **'ADD WATER' Light On:** Refill the water tank with purified water.
- **'ICE FULL' Light On:** Remove ice from the basket. Sometimes, ice may accumulate and block the sensor, even if the basket isn't completely full. Gently push the ice back to clear the sensor.
- **Unusual Noises:** Ensure the unit is on a stable, level surface. Check for any obstructions in the ice-making mechanism.

Specifications

Brand	Silonn
Model Name	35B
Product Dimensions	13.15"D x 8.98"W x 11.14"H
Capacity	22 Pounds (daily ice production)
Water Tank Capacity	1.8 Liters
Wattage	192 watts
Ice Cube Shape	Bullet-shaped
Ice Production Time	9 cubes in 6 minutes
Country of Origin	China

Warranty and Support

For warranty information, technical support, or any questions regarding your Silonn Portable Ice Maker, please refer to the contact details provided in the packaging or visit the official Silonn website. Keep your purchase receipt for warranty claims.

© 2024 Silonn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question