

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DREAMSIDEA](#) /
- › [DREAMSIDEA Oversized Corduroy Chaise Lounge \(Left Arm, Grey\) Instruction Manual](#)

DREAMSIDEA B0DF24YG88

DREAMSIDEA Oversized Corduroy Chaise Lounge (Left Arm, Grey) Instruction Manual

Model: B0DF24YG88

1. PRODUCT OVERVIEW

The DREAMSIDEA Oversized Corduroy Chaise Lounge is designed for comfort and relaxation in your living space. This chaise lounge features a left armrest, a deep seat, and is upholstered in soft corduroy fabric. It is suitable for various indoor settings such as bedrooms and living rooms.



Image 1.1: The DREAMSIDEA Oversized Corduroy Chaise Lounge in Grey, showcasing its overall design and left armrest.

Key features include a solid wood frame for durability, high-density foam cushions with coil springs for comfort, and removable covers for easy maintenance. The design incorporates an adjustable lifting headrest for ergonomic support.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 400 pounds (approximately 181 kg). Exceeding this limit may compromise the structural integrity of the chaise lounge and lead to injury.
- **Assembly:** Always follow the assembly instructions carefully to ensure safe and stable use. Improper assembly can result in instability and potential hazards.
- **Placement:** Ensure the chaise lounge is placed on a flat, stable surface to prevent tipping.
- **Children and Pets:** Supervise children and pets around the furniture to prevent accidents.

3. SETUP AND ASSEMBLY

The DREAMSIDEA Chaise Lounge requires assembly. All necessary installation tools are included in the packaging. Please ensure all components are present before beginning assembly.

3.1. Unpacking

1. Carefully open the packaging and remove all components.
2. Lay out all parts on a clean, soft surface (e.g., a rug or blanket) to prevent scratches.
3. Verify that all parts listed in the assembly guide are present. If any parts are missing or damaged, contact customer support immediately.

3.2. Assembly Steps

Follow the detailed assembly instructions provided in the separate assembly guide included with your product. General steps typically involve:

- Attaching the solid wood legs to the base of the chaise lounge.
- Securing the backrest and armrest components to the main frame.
- Placing the cushions and pillows onto the assembled frame.



Image 3.1: Product details highlighting the wide armrest, removable pillow, and solid wood legs, which are key components during assembly.

Note: Some cushions may require up to 72 hours to fully expand and achieve their intended shape and firmness after unpacking.

4. OPERATING AND USAGE

The DREAMSIDEA Chaise Lounge is designed for versatile use, offering comfort for various activities.

4.1. Comfort Features

- **Oversized Design:** The generous dimensions (56.2"D x 42.1"W x 35"H) provide ample space for comfortable seating or lounging.
- **Cushioning:** High-density foam and coil springs within the cushions offer a supportive yet soft experience. The corduroy fabric is skin-friendly.
- **Adjustable Headrest:** The chaise lounge features an adjustable lifting headrest, allowing you to customize your comfort for reading, relaxing, or sleeping.



Image 4.1: Detail of the seat area, emphasizing the deeper seat, thicker cushion, and high-density foam for enhanced comfort.



ERGONOMIC DESIGN:

Adjustable lifting headrest
and humanization design bring
more relaxation to your body

Image 4.2: Illustration of the ergonomic design, specifically showcasing the adjustable lifting headrest for personalized comfort.

4.2. Recommended Uses

This chaise lounge is ideal for:

- Reading
- Relaxing
- Gaming
- Napping or light sleeping
- As an additional seating option in living rooms or bedrooms.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your chaise lounge.

5.1. Cleaning Instructions

- **General Cleaning:** For routine cleaning, wipe the surface with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Removable Covers:** The sofa covers for the seat frame, armrests, and backrests are removable for

easy cleaning. Refer to the care label on the covers for specific washing instructions (e.g., machine wash cold, tumble dry low, or spot clean only).

- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub, as this can spread the stain.

5.2. General Care

- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading of the fabric.
- **Heat Sources:** Keep the chaise lounge away from direct heat sources like radiators or fireplaces.
- **Rotation:** Periodically rotate and fluff cushions to maintain their shape and even out wear.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your chaise lounge.

Problem	Possible Cause	Solution
Cushions appear flat or misshapen.	Cushions require time to expand after unpacking; uneven settling.	Allow up to 72 hours for cushions to fully expand. Regularly fluff and rotate cushions to help them regain shape and distribute wear evenly.
Headrest does not adjust or is loose.	Improper installation; mechanism obstruction or defect.	Review assembly instructions for headrest installation. Ensure no fabric or debris is obstructing the adjustment mechanism. If the issue persists, contact customer support.
Chaise lounge feels unstable or wobbly.	Loose leg attachments; uneven floor surface.	Check and tighten all leg screws. Ensure the chaise lounge is on a level surface. If necessary, use furniture pads or shims to stabilize.
Squeaking noises during use.	Loose connections in the frame.	Inspect all bolted connections and tighten them securely. Avoid overtightening.

7. SPECIFICATIONS

PRODUCT SIZE

35.5"H*41.91"W*56.28"D



Weight Capacity



Image 7.1: Visual representation of the chaise lounge's dimensions and its maximum weight capacity of 400 lbs.

Feature	Detail
Brand	DREAMSIDEA
Model Number	B0DF24YG88
Product Dimensions (D x W x H)	56.2"D x 42.1"W x 35"H (142.7 cm D x 106.9 cm W x 88.9 cm H)
Seat Depth	42.5 inches (108 cm)
Seat Height	17.5 inches (44.5 cm)
Item Weight	100 Pounds (45.3 kg)
Weight Capacity	400 Pounds (181 kg)
Color	Grey
Material Type	Corduroy fabric, Engineered Wood (Frame), Foam (Fill)
Frame Material	Engineered Wood

Feature	Detail
Fill Material	Foam
Assembly Required	Yes
Included Components	Installation Tools
Special Features	Armrest, Cushion Availability, Ergonomic (Adjustable Headrest)
Room Type	Bedroom, Living Room
Indoor/Outdoor Usage	Indoor
Seating Capacity	1-2 (Oversized single seat)

8. CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact DREAMSIDEA customer service through the retailer where you purchased the product or visit the official DREAMSIDEA store page:

[Visit the DREAMSIDEA Store on Amazon](#)

Please have your model number (B0DF24YG88) and purchase date available when contacting support.

© 2025 DREAMSIDEA. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.