

MINISO 5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten

MINISO 5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten User Manual

Model: 5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten

1. INTRODUCTION

The MINISO 5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten is a delightful and versatile accessory designed to add a touch of charm to your everyday items. Made from high-quality, soft plush fabric, this pendant features Snoopy with a vibrant sunflower pattern, making it an eye-catching addition to bags, backpacks, or keys.

Key features include:

- **Charming Sunflower Design:** Adorable 5-inch plush pendant featuring Snoopy surrounded by cheerful sunflowers.
- **Soft & Cuddly Material:** Crafted from high-quality, soft fabric for a comforting touch.
- **Versatile Accessory:** Equipped with a hook for easy attachment to backpacks, purses, or keychains.
- **Ideal for All Ages:** A wonderful gift for fans of the beloved Snoopy character.
- **Great for Personalization:** Elevate your style and add a splash of color to your daily routine.

2. SAFETY INFORMATION

Please observe the following safety guidelines:

- Keep away from fire.
- This product is intended for decorative and accessory use.
- Not suitable for children under 3 years due to small parts that could pose a choking hazard.

3. PRODUCT OVERVIEW

The MINISO Snoopy Plush Pendant Keychain is designed for easy attachment and portability. Its compact size and durable hook make it a convenient and fun accessory.




Front view of the MINISO Snoopy Plush Pendant Keychain, featuring Snoopy holding a yellow sunflower, with a green plastic clip at the top.



The Snoopy plush keychain sitting upright on a white surface, showcasing its design from a slightly elevated angle.



An image illustrating the dimensions of the Snoopy plush keychain, showing a height of 12.8 cm (0.41 inch) and a width of 7.4 cm (0.24 inch).



A composite image highlighting Snoopy's 'Smart Expression' and the 'Portable hanging buckle' with keys attached, demonstrating its practical use.



Two Snoopy plush keychains displayed

together, one with the sunflower design and another wearing a blue party hat, suggesting variety or companionship.



The Snoopy plush keychain with sunflower attached to a vibrant, multi-colored crocheted bag, demonstrating its use as a decorative accessory.

4. SETUP

The MINISO Snoopy Plush Pendant Keychain requires minimal setup. It comes ready to use directly out of the packaging.

1. **Unpack:** Carefully remove the plush pendant from its packaging.
2. **Inspect:** Check the plush and the attached clip for any signs of damage or defects.
3. **Attach:** Open the green plastic clip by pressing the lever. Attach the clip to a desired loop or ring on your backpack, purse, keys, or other items. Release the lever to secure the pendant.

5. OPERATING

This product functions as a decorative pendant and keychain. Its operation is straightforward:

- **As a Keychain:** Attach the pendant to your keys to easily identify them and add a personal touch.
- **As a Bag Accessory:** Clip it onto the zipper pull, strap, or any loop on your bag or backpack to enhance its appearance.
- **Decorative Item:** Use it to adorn other personal items or simply display it as a cute collectible.

6. MAINTENANCE

To ensure the longevity and cleanliness of your MINISO Snoopy Plush Pendant Keychain, follow these maintenance guidelines:

- **Spot Cleaning:** For minor dirt or stains, gently spot clean the plush surface with a damp cloth and mild soap. Do not submerge the entire product in water.
- **Air Dry:** Allow the plush to air dry completely after cleaning. Do not use a machine dryer or direct heat, as this may damage the material.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or strong detergents, as these can discolor or damage the fabric.
- **Storage:** Store in a clean, dry place away from direct sunlight to prevent fading.

7. TROUBLESHOOTING

If you encounter any issues with your plush pendant, consider the following:

- **Pendant is Dirty:** Refer to the "Maintenance" section for cleaning instructions.
- **Clip is Stiff/Hard to Open:** Ensure no debris is lodged in the clip mechanism. Gently try to open and close it a few times. Do not force it if it feels stuck.
- **Plush Appears Flattened:** Gently fluff the plush by hand to restore its shape.

For issues not covered here, please contact MINISO customer support.

8. SPECIFICATIONS

Attribute	Detail
Product Name	MINISO 5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten
Model	5" Snoopy Colorful Life Plush Pendant Keychain, Sunflower Patten
Material	Polyester
Package Dimensions	6.85 x 3.54 x 2.44 inches
Item Weight	1.45 ounces
Manufacturer Recommended Age	0 - 18 years
Manufacturer	MINISO
First Available Date	August 23, 2024

9. WARRANTY AND SUPPORT

For information regarding product warranty or to seek further support, please refer to the official MINISO website or contact MINISO customer service directly. Keep your purchase receipt for any warranty claims.

You can visit the MINISO Store for more products and information:[MINISO Official Store](#)