

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Momcozy](#) /

› [Momcozy KleanPal Pro Baby Bottle Washer User Manual](#)

Momcozy BS03-EUU

Momcozy KleanPal Pro Baby Bottle Washer User Manual

Model: BS03-EUU

1. INTRODUCTION

The Momcozy KleanPal Pro is an advanced 3-in-1 automatic baby bottle washer designed to simplify the cleaning, sterilization, and drying process for baby bottles and accessories. This manual provides detailed instructions for safe and efficient operation, maintenance, and troubleshooting.



Image 1.1: The Momcozy KleanPal Pro Baby Bottle Washer, a compact and efficient device for bottle care.

2. SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using the appliance to avoid injury or damage.

- Always ensure the appliance is placed on a stable, flat surface.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Use only Momcozy approved cleaning tablets.
- Unplug the appliance before cleaning or when not in use.
- Do not operate if the power cord or plug is damaged.
- Steam is hot; avoid direct contact during operation.

3. PRODUCT OVERVIEW

3.1 Components

- Main Unit with Control Panel
- Transparent Lid
- Double Removable Basket (Upper and Lower)
- Water Reservoir
- Drain Hose
- Cleaning Tablets (60 included)

3.2 Control Panel

The control panel features a digital display and various buttons for program selection and operation.

9 Cleaning Settings at Your Fingertips *



*Details on each setting available below.

Image 3.1: Overview of the control panel and available cleaning settings, including Rapid Wash, Deep Wash, Sterilization and Drying, and Sterile Storage.

- **Power Button:** Turns the unit on/off.
- **Program Selection Buttons:** Rapid, Normal, Steam, Storage.
- **Start/Pause Button:** Initiates or pauses the selected program.
- **Digital Display:** Shows remaining time and status indicators (e.g., "NO WATER", "DRYING", "STEAM", "FRESH AIR").

4. SETUP

Follow these steps for initial setup before first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the Momcozy KleanPal Pro on a flat, stable surface near a power outlet and a sink for drainage.
3. **Connect Drain Hose:** Attach the drain hose to the designated port on the unit and direct the other end into a sink or

drain.



Image 4.1: Visual guide for the setup process, including plugging in, connecting the drain hose, filling the water reservoir, adding a cleaning tablet, and selecting a program.

4. **Fill Water Reservoir:** Fill the external water reservoir with distilled or purified water up to the MAX line. Avoid using tap water to prevent mineral buildup.
5. **Plug In:** Connect the power cord to a compatible 220-240V/50-60Hz power outlet.

5. OPERATING INSTRUCTIONS

5.1 Preparing Items for Cleaning

- Rinse bottles and accessories to remove large food particles.
- Place bottles upside down in the lower basket. Nipples, rings, and other small accessories can be placed in the upper basket. The double removable basket can accommodate up to 4 bottles and various accessories.
- The unit is compatible with most wide-neck and narrow-neck bottles, as well as sippy cups, silicone tableware, teething rings, pacifiers, and breast pump parts.

Washes More Than Just Bottles



Wide-neck bottles



Narrow-neck bottles



Sippy cups, tableware,
and more



Wearable & traditional
pump parts

Image 5.1: The KleanPal Pro can wash a variety of baby items, including wide-neck bottles, narrow-neck bottles, sippy cups, tableware, and pump parts.

- Add one Momcozy cleaning tablet to the designated compartment in the unit.



60 Tablettes de détergent incluses

Placez une tablette dans le compartiment pour chaque lavage. Fonctionne uniquement avec les tablettes de détergent Momcozy dédiées.

Image 5.2: Place one Momcozy detergent tablet into the compartment for each wash cycle. Only use dedicated Momcozy detergent

tablets.

- Close the transparent lid securely.

5.2 Program Selection and Operation

The Momcozy KleanPal Pro offers 9 programs, including a 72-hour sterile storage mode. Select the appropriate program based on your needs:



Lavage Uniquement

Lavage rapide (19 min): Pour les résidus de lait légers.
Lavage normal (29 min): Pour les résidus de lait importants.

Lavage + Stérilisation + Séchage

Rapide + Vapeur (74 min): Laver, stériliser et sécher.
Normal + Vapeur (84 min): Laver, stériliser et sécher.
Vapeur (55 min): Stériliser et sécher uniquement.

Lavage + Stérilisation + Séchage + Stockage

Rapide + Vapeur + Stockage (74 min + temps de stockage): Laver, stériliser, sécher et stocker.
Normal + Vapeur + Stockage (84 min + temps de stockage): Laver, stériliser, sécher et stocker.
Vapeur + Stockage (29 min + temps de stockage): Stériliser, sécher et stocker.

Stockage Uniquement

Mode stockage (72 heures): Garde les articles stériles jusqu'à 72 heures.

Image 5.3: Detailed overview of the available programs: Wash Only, Wash + Sterilization + Drying, Wash + Sterilization + Drying + Storage, and Storage Only.

- **Wash Only:**
 - **Rapid Wash (19 min):** For recently used bottles with light milk residue.
 - **Normal Wash (29 min):** For bottles with significant dried milk residue.



Image 5.4: Comparison of Rapid Wash for light residue and Normal Wash for dried milk residue.

- **Wash + Sterilization + Drying:**
 - **Rapid + Steam (74 min):** Wash, sterilize, and dry.
 - **Normal + Steam (84 min):** Wash, sterilize, and dry.
 - **Steam Only (55 min):** Sterilize and dry only.

The sterilization process uses 100°C hot steam to eliminate 99.9% of germs.

Kills 99.9% of Germs

Using natural steam, then automatically dry



Image 5.5: The unit effectively kills 99.9% of germs using natural steam, followed by automatic drying.

- **Wash + Sterilization + Drying + Storage:**

- **Rapid + Steam + Storage (74 min + storage time):**Wash, sterilize, dry, and store.
- **Normal + Steam + Storage (84 min + storage time):**Wash, sterilize, dry, and store.
- **Steam + Storage (29 min + storage time):**Sterilize, dry, and store.

- **Storage Only:**

- **Storage Mode (72 hours):** Keeps items sterile for up to 72 hours. This mode utilizes a H13 HEPA filter to remove 99.93% of airborne particles.

Up to 72 Hours of Sterile and Odorless Storage

Remove
99.93%
airborne particles
with a H13 HEPA filter*

*Replace every 3-5 months,
depending on use

Image 5.6: The unit provides up to 72 hours of sterile and odorless storage, removing 99.93% of airborne particles with its H13 HEPA filter.

After selecting your desired program, press the **Start/Pause** button to begin the cycle. The digital display will show the remaining time and current status.

Visualisez L'avancement En Un Coup D'œil



Indicateurs d'état clairs sur l'écran



Couvercle transparent et visible

Image 5.7: Clear status indicators on the screen and a transparent, visible lid allow you to monitor the cleaning progress.

6. MAINTENANCE

6.1 Cleaning the Unit

- After each use, ensure the drain hose is properly positioned to allow wastewater to drain automatically.
- Wipe down the interior and exterior of the unit with a damp cloth.
- Periodically clean the removable baskets.
- For thorough cleaning, run a "Steam Only" cycle with an empty unit to descale any mineral buildup.

6.2 HEPA Filter Replacement

The H13 HEPA filter should be replaced every 3-5 months, depending on usage, to maintain optimal air filtration during storage mode.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another device.
"NO WATER" indicator.	Water reservoir is empty or below minimum level.	Refill the water reservoir with distilled or purified water.
Bottles are not clean.	Insufficient cleaning tablet; heavy residue; improper placement.	Ensure one tablet is used; pre-rinse heavily soiled items; arrange items to allow water circulation.
Items are not dry.	Drying cycle interrupted; excessive moisture.	Ensure the drying cycle completes; remove excess water before placing items.

8. SPECIFICATIONS

Feature	Detail
Model Number	BS03-EUU

Feature	Detail
Brand	Momcozy
Material	Plastic
Dimensions (Product)	Approx. 41 cm (H) x 25 cm (W) x 34 cm (D)
Weight (Product)	Approx. 5 kg (based on package weight)
Power Compatibility	220-240 V / 50-60 Hz
Cleaning Nozzles	26 (12 internal, 14 swirling)
Sterilization Method	100°C Steam
Air Filtration	H13 HEPA Filter (removes 99.93% airborne particles)



Image 8.1: The compact dimensions of the Momcozy KleanPal Pro, measuring approximately 41 cm in height, 25 cm in width, and 34 cm in depth.

9. WARRANTY AND SUPPORT

The Momcozy KleanPal Pro Baby Bottle Washer comes with a **1-year warranty** from the date of purchase, covering manufacturing defects and malfunctions under normal use.

For technical support, warranty claims, or general inquiries, please contact Momcozy customer service through their official website or the contact information provided with your purchase. Please have your model number (BS03-EUU) and proof of purchase ready when contacting support.

For more information, visit the official Momcozy store: [Momcozy Store](#)