

SenseFlow SF101S

SenseFlow Wi-Fi Essential Oil Diffuser SF101S User Manual

Model: SF101S | Brand: SenseFlow

1. INTRODUCTION

Thank you for choosing the SenseFlow Wi-Fi Essential Oil Diffuser SF101S. This device utilizes patented PureMist technology to atomize essential oils into an ultra-fine mist without the need for water or heat, preserving the natural fragrance. It offers a quiet, waterless diffusion experience, ideal for various environments. This manual provides detailed instructions for safe and effective use of your diffuser.



Image 1: SenseFlow SF101S Diffuser and Control App Interface.

2. SAFETY INFORMATION

Please read all safety instructions before using the device. Keep this manual for future reference.

- The product packaging may contain different information than shown on our website. Always read the label, warnings, and instructions provided on the product before use or consumption.
- This device is for indoor use only.
- Do not immerse the device in water or any other liquid.
- Keep out of reach of children and pets.
- Use only SenseFlow essential oil refills with this device. Using other oils may damage the diffuser or void the warranty.
- Ensure the device is unplugged before cleaning or replacing refills.
- Do not block the mist outlet.
- If the device is damaged, do not attempt to repair it yourself. Contact customer support.
- Avoid direct contact with essential oils, especially with eyes and skin. In case of contact, rinse thoroughly with water.

3. PACKAGE CONTENTS

- 1 x SenseFlow SF101S Diffuser Unit
- 1 x 30ml Fragrance Refill (initial scent may vary)
- 1 x User Manual

4. SETUP

4.1 Inserting the Essential Oil Refill

1. Unscrew the cap from the essential oil refill bottle.
2. Carefully insert the refill bottle into the bottom of the diffuser unit. Ensure it is securely twisted into place.

PureMist™ – Tecnologia di fragranza esclusiva e brevettata

Trasforma gli oli essenziali in una nebbia ultra-fine per un'esperienza olfattiva delicata e immersiva come mai prima d'ora!



Image 2: Inserting the Essential Oil Refill.

4.2 Plugging in the Diffuser

Plug the diffuser directly into a standard wall outlet. The device is designed to be compact and discreet.



Image 3: Diffuser plugged into a wall outlet.

4.3 Connecting to the SenseFlow App

For full control and customization, download the SenseFlow app from your smartphone's app store.

1. Scan the QR code located on the essential oil refill bottle or search for "SenseFlow" in your app store.

2. Follow the in-app instructions to connect your diffuser to your Wi-Fi network.
3. Once connected, you can manage settings, schedules, and fragrance intensity.

5. OPERATION

5.1 Manual Control

The diffuser has a power button on the front. Press it to cycle through different intensity levels or to turn the device on/off. Indicator lights will show the current setting.

5.2 App Control and Features

The SenseFlow app provides advanced control over your diffuser:

- **Intensity Adjustment:** Choose from 4 levels of fragrance intensity to suit your preference and room size.
- **Scheduling:** Set custom schedules for when the diffuser turns on and off, and at what intensity.
- **Room Customization:** Assign diffusers to specific rooms and tailor the fragrance experience for each area (e.g., relaxing scents for bedrooms, energizing scents for studies).
- **Coverage:** The diffuser can effectively scent areas up to 93 square meters (1000 sq. ft.).

Un solo tocco per il controllo completo della fragranza in casa

Diffusione ultrasonica per profumare ogni angolo



Image 4: App Control and Room Coverage.

Trasforma ogni ambiente con 40 giorni di freschezza!



Fragranza continua con ricarica sostituibile da 30 ml – crea l'atmosfera perfetta e rendi ogni angolo accogliente senza sforzo.



Image 5: SenseFlow App Interface for Intensity Control.

6. MAINTENANCE

6.1 Replacing Essential Oil Refills

SenseFlow refills are designed for long-lasting aroma, typically up to 120 days depending on usage and intensity settings. When the fragrance diminishes or the bottle is empty:

1. Unplug the diffuser from the wall outlet.
2. Carefully twist and remove the empty essential oil refill bottle from the diffuser unit.
3. Dispose of the empty bottle responsibly.

4. Unscrew the cap from a new SenseFlow essential oil refill bottle.
5. Insert the new refill bottle into the diffuser unit and twist securely into place.
6. Plug the diffuser back into the wall outlet.

SenseFlow offers a variety of 100% plant-based and pet-friendly essential oil refills, free from harmful chemicals. Refills are sold separately.

Des collections infinies de nouvelles huiles essentielles pour répondre à tous vos besoins

Essence pure, arômes enchanteurs et bienfaits thérapeutiques pour un voyage sensoriel agréable.





100 % d'origine végétale



Sans agents de remplissage, sans additifs



Adapté aux animaux de compagnie

Image 6: SenseFlow Essential Oil Refills.

6.2 Cleaning

The SenseFlow SF101S diffuser utilizes PureMist technology, which is waterless and does not require regular cleaning of water tanks or internal components. If the exterior of the device becomes dusty, gently

wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

7. TROUBLESHOOTING

If you encounter any issues with your SenseFlow diffuser, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|-------------------------------------|---|---|
| No fragrance is being diffused. | <ul style="list-style-type: none">Diffuser is not powered on.Essential oil refill is empty or not properly inserted.Intensity setting is too low.Mist outlet is blocked. | <ul style="list-style-type: none">Ensure the diffuser is plugged in and powered on.Check the refill level and ensure it is securely twisted into the unit. Replace if empty.Increase the fragrance intensity via the app or manual button.Ensure nothing is obstructing the mist outlet. |
| App cannot connect to the diffuser. | <ul style="list-style-type: none">Incorrect Wi-Fi password.Diffuser is out of Wi-Fi range.Temporary app or network issue. | <ul style="list-style-type: none">Verify your Wi-Fi password.Move the diffuser closer to your Wi-Fi router.Restart the app and/or your Wi-Fi router. Try re-pairing the device through the app. |
| Device is making unusual noise. | <ul style="list-style-type: none">Normal operation sound (ultrasonic atomization).Loose refill bottle. | <ul style="list-style-type: none">A slight humming sound during operation is normal.Ensure the essential oil refill is tightly secured. |
| Device feels warm to the touch. | <ul style="list-style-type: none">Normal operating temperature.Poor ventilation. | <ul style="list-style-type: none">It is normal for the device to feel slightly warm during operation.Ensure the diffuser is not covered or placed in an enclosed space. |

8. SPECIFICATIONS

| Feature | Detail |
|----------------------------------|---|
| Model | SF101S |
| Brand | SenseFlow |
| Dimensions (LxWxH) | 9.8 x 5 x 10 cm (3.86 x 1.97 x 3.94 inches) |
| Weight | 59 grams (2.08 ounces) |
| Diffusion Technology | PureMist Ultrasonic (Waterless, Heatless) |
| Coverage Area | Up to 93 m² (1000 sq. ft.) |
| Scent Duration (per 30ml refill) | Up to 120 days (depending on intensity) |
| Connectivity | Wi-Fi (App Control) |

9. WARRANTY AND SUPPORT


For warranty information and customer support, please refer to the documentation included with your product or visit the official SenseFlow website. You can also find support contact details by scanning the QR code on your essential oil refill bottle.

Website: www.thesenseflow.com

Email Support: support@thesenseflow.com

© 2025 SenseFlow. All rights reserved.

Related Documents - SF101S

| | |
|---|--|
|  | <p>SenseFlow Essential Oil Diffuser User Manual - SF101</p> <p>Comprehensive user manual for the SenseFlow SF101 Essential Oil Diffuser, covering safety instructions, product overview, specifications, setup, operation, maintenance, troubleshooting, and warranty information.</p> |
|---|--|