

Dreo DR-HHM006 White

Dreo Humidifier User Manual

MODEL: DR-HHM006 WHITE

Product Overview

The Dreo Humidifier is an advanced ultrasonic cool mist humidifier designed to enhance air quality and comfort in your living space. With its 3-liter capacity and top-fill design, it provides up to 30 hours of continuous humidification, making it suitable for large rooms, bedrooms, nurseries, and plant care. Its whisper-quiet operation (26dB in Sleep Mode) ensures an undisturbed environment, while the integrated humidity sensor and adjustable settings allow for precise control over your indoor climate.

Key Features:

- **3L Top-Fill Tank:** Easy and convenient refilling without spills.
- **30-Hour Runtime:** Extended operation in Sleep Mode for consistent humidification.
- **26dB Quiet Operation:** Ensures a peaceful environment, ideal for sleeping or working.
- **Humidity Sensor:** Automatically maintains optimal humidity levels.
- **3600 Rotating Nozzle:** Provides wide and even mist distribution.
- **Night Light:** Adjustable ambient lighting for added comfort.
- **Aroma Pad Tray:** Allows for the use of essential oils to create a soothing atmosphere.
- **Ultrasonic Technology:** Produces a fine 55m mist for effective humidification without dampening surfaces.

Safety Instructions

Please read all instructions carefully before using this humidifier to ensure safe and optimal performance. Keep this manual for future reference.

- Always place the humidifier on a firm, flat, water-resistant surface away from direct sunlight and heat sources.
- Do not place the humidifier directly on carpet, towels, or other absorbent surfaces.
- Keep the humidifier out of reach of children and pets.
- Use only clean, cool tap water. Distilled or demineralized water is recommended to prevent white dust.

- Do not add essential oils directly into the water tank; use the designated aroma pad tray.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not submerge the base unit in water or other liquids.
- Regular cleaning is essential to prevent mold and bacteria growth.

Product Components

Familiarize yourself with the main components of your Drezo Humidifier:



Image: Front view of the Drezo Humidifier, showcasing its transparent water tank, internal mist column, and digital control panel.

- **Water Tank:** Transparent 3L capacity for water.
- **Base Unit:** Contains the ultrasonic atomizer, control panel, and power connection.
- **Mist Nozzle:** 360° rotatable for directing mist.
- **Control Panel/Display:** Digital screen with touch controls for settings.
- **Aroma Pad Tray:** Small tray located on the side for essential oils.
- **Power Cord:** For connecting the unit to an electrical outlet.

Setup

Follow these steps for the initial setup of your humidifier:

1. **Unpack:** Carefully remove all packaging materials and place the humidifier on a stable, flat surface.
2. **Fill Water Tank:** Remove the top cover. Fill the 3L water tank directly from the top opening with clean, cool tap water. Do not exceed the MAX fill line. Replace the top cover securely.



Image: A hand pouring water into the top-fill opening of the humidifier, demonstrating the ease of refilling.

3. **Optional: Add Essential Oils:** Locate the aroma pad tray on the side of the base unit. Add a few drops of your preferred essential oil onto the aroma pad. Do not add oils directly into the water tank.



Image: A close-up view showing the aroma pad tray pulled out from the humidifier's base, with essential oil bottles nearby.

4. **Connect Power:** Plug the power cord into a standard electrical outlet. The display will illuminate, indicating the unit is in standby mode.

Operating Instructions

Learn how to use your Dreo Humidifier's various functions:

1. **Power On/Off:** Touch the power button on the digital display to turn the humidifier on or off.
2. **Adjust Mist Level:** Use the mist level button to cycle through different mist output settings (Low, Medium, High). The current setting will be displayed.
3. **Auto Mode & Humidity Control:** The humidifier features a built-in humidity sensor. Press the 'Auto' button to activate Auto Mode. The unit will automatically adjust mist output to maintain a comfortable humidity level (typically between 40-60%). You can also manually set your desired humidity percentage.

DREO | Humidifier

Perfect Humidity Control with Auto Mode




Image: The humidifier operating in a room, with an overlay illustrating the ambient light indicator for humidity levels (Wet, Comfort, Dry).

Check Your Room Humidity in Real-time



Humidity Detection Precision




Image: A detailed view highlighting the humidifier's high-precision humidistat and its accuracy in detecting room humidity.

4. **Night Light Function:** Press the light bulb icon on the control panel to turn the night light on or off. This feature provides a soft glow for nighttime use.

All-night Freshness Ultimate Quietness



Image: The humidifier with its night light active, placed in a child's room, highlighting its ultra-quiet operation at 26dB.

- 5. Timer Function:** Use the timer button to set an operating duration (e.g., 1-12 hours). The humidifier will automatically turn off once the set time expires.
- 6. 3600 Nozzle:** Rotate the mist nozzle on top of the unit to direct the mist flow in any desired direction.



Image: A diagram illustrating the 360° adjustable nozzle, indicating its ability to rotate and direct mist.

Official Product Video: Dreo 3L Humidifier Overview

Your browser does not support the video tag.

Video: An official overview of the Dreo 3L Humidifier, demonstrating its features and operation. This video is 56 seconds long.

Maintenance

Regular cleaning and maintenance are crucial for the longevity and hygienic operation of your humidifier.

- **Daily Maintenance:** Empty and rinse the water tank and base unit daily. Refill with fresh water.
- **Weekly Cleaning:**
 - a. Unplug the humidifier and disassemble the water tank from the base.
 - b. Pour out any remaining water from both the tank and the base.



Image: A hand wiping the interior of the humidifier's water tank, illustrating the ease of cleaning.

- c. Clean the water tank and base with a soft brush or cloth and a mild descaling solution (e.g., a mixture of white vinegar and water).
 - d. Rinse all components thoroughly with clean water until no vinegar smell remains.
 - e. Ensure the ultrasonic atomizer and air outlet are free from mineral deposits.
 - f. Dry all parts completely before reassembling.
- **Cartridge Replacement:** The humidifier is compatible with Demineralization and Clean Mist cartridges (sold separately). Replace these cartridges as recommended by the manufacturer to prevent limescale buildup and ensure clean mist output.

Troubleshooting

If you encounter issues with your humidifier, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|------------------------|--|--|
| No Mist Output | Low water level; Water tank not properly seated; Ultrasonic atomizer dirty; Float misplaced. | Refill water tank; Ensure tank is correctly aligned; Clean atomizer; Check and correctly position the float. |
| White Dust Around Unit | Hard water used. | Use distilled or demineralized water; Install a demineralization cartridge. |
| Unusual Odor | Stagnant water; Dirty tank/base. | Clean the humidifier thoroughly; Change water daily. |
| Unit Leaking Water | Water tank not sealed properly; Unit placed on an uneven surface. | Ensure water tank cap is tight; Place unit on a flat, stable surface. |

Specifications

| | |
|-------------------|-----------------|
| Brand | Dreo |
| Model Name | DR-HHM006 White |
| Color | White |

| | |
|---------------------|------------------------|
| Product Dimensions | 7.6"D x 10.2"W x 7.6"H |
| Item Weight | 4 pounds |
| Water Tank Capacity | 3 Liters |
| Max Runtime | 30 Hours |
| Noise Level | 26dB (Sleep Mode) |
| Coverage Area | Up to 300 Square Feet |
| Operation Mode | Ultrasonic |
| Control Method | Touch |
| Voltage | 120 Volts (AC) |
| Wattage | 29 watts |

DREO | Humidifiers HM306

10.24"

● Height

7.68"

● Width

7.68"

● Depth




Image: Technical drawing of the Dreo Humidifier with its precise dimensions (height, width, depth) clearly indicated.

Warranty and Support

Dreo provides a 12-month warranty for this product, covering manufacturing defects. For any product inquiries, technical support, or warranty claims, please contact Dreo customer support. Ensure you have your model number and purchase details ready.

For detailed instructions and further assistance, you may also refer to the official User Manual PDF:

[Download User Manual \(PDF\)](#)