

Effireli YK-RC802NU YAI1

Effireli RC802NU YAI1 Replacement Remote Control User Manual

Model: YK-RC802NU YAI1

INTRODUCTION

This manual provides comprehensive instructions for the Effireli RC802NU YAI1 Replacement Remote Control. Designed for ease of use, this remote requires no programming or setup, allowing you to operate your compatible Ffalcon TV models immediately. Please read this manual thoroughly to ensure proper usage and to familiarize yourself with all functions.

Compatible Ffalcon TV Models:

- 50UF2, 55UF2, 65UF2
- 43S625
- 55UF1, 65UF1, 50UF1
- 40SF1, 32SF1
- UF2 series

Note: If your specific model number is not listed or your original remote appears different, please contact the manufacturer for compatibility confirmation.

PRODUCT OVERVIEW

The Effireli RC802NU YAI1 remote control is a direct replacement, offering all the essential functions of your original Ffalcon TV remote. Below is an image of the remote with a description of its key buttons.



Image: Effireli RC802NU YAI1 Replacement Remote Control. This image displays the full remote control, a sleek black device with clearly labeled buttons.

Button Functions:

Power Button (Top right, red icon): Turns the TV on or off.

Mute Button (Top left, speaker with cross icon): Mutes or unmutes the TV audio.

Number Buttons (0-9): Directly select channels or input numerical values.

PRE-CH (Previous Channel): Returns to the previously viewed channel.

LIST: Displays a list of channels or available content.

Volume Up/Down (+/-): Adjusts the TV volume.

Info Button (i): Displays information about the current program or input.

Settings/Gear Icon: Accesses the TV's settings menu.

Channel Up/Down (P+/P-): Changes channels sequentially.

Home Button (House icon): Navigates to the TV's home screen or smart TV interface.

Menu Button (Three lines icon): Opens the main menu.

Navigation Arrows (Up, Down, Left, Right): Used to navigate through menus and options.

OK Button: Confirms selections in menus.

Back/Return Button (Curved arrow): Returns to the previous screen or menu.

Exit Button: Exits the current menu or application.

GUIDE Button: Opens the electronic program guide (EPG).

TEXT Button: Accesses teletext services.

LANG (Language) Button: Changes audio language or subtitle language.

SUBT. (Subtitles) Button: Toggles subtitles on or off.

Color Buttons (Red, Green, Yellow, Blue): Functionality varies by TV model and context, often used for interactive features.

Media Control Buttons (Rewind, Play/Pause, Fast Forward, Stop, Record): Controls media playback.

NETFLIX Button: Direct access to the Netflix application.

Stan. Button: Direct access to the Stan application.

SETUP

The Effireli RC802NU YAI1 replacement remote control is designed for immediate use with compatible Ffalcon TV models without any complex programming. Simply insert batteries, and it's ready to operate.

Inserting Batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.

Important: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.

OPERATING INSTRUCTIONS

Once batteries are installed, the remote is ready to control your Ffalcon TV. Point the remote directly at the TV's infrared receiver for optimal performance.

Basic Functions:

- **Power On/Off:** Press the **Power** button once.
- **Channel Selection:** Use the **Number Buttons** to enter a channel number directly, or use **Channel Up/Down (P+/P-)** to browse.
- **Volume Adjustment:** Press **Volume Up (+)** to increase volume, and **Volume Down (-)** to decrease.
- **Mute Audio:** Press the **Mute** button to silence the TV. Press again to restore sound.
- **Menu Navigation:** Use the **Navigation Arrows** to move through on-screen menus and press **OK** to confirm selections.
- **Accessing Smart Features:** Use the **Home** button to go to the smart TV interface or dedicated app buttons like **NETFLIX** and **Stan.** for quick access.

MAINTENANCE

Proper care will extend the life of your remote control.

- **Cleaning:** Wipe the remote with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Do not use abrasive cleaners or solvents.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Dispose of used batteries according to local regulations.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

TROUBLESHOOTING

If you experience issues with your remote control, try the following solutions:

- **Remote not responding:**
 - Ensure there is a clear line of sight between the remote and the TV's infrared sensor.
 - Check if the batteries are inserted correctly with the correct polarity (+/-).
 - Replace the batteries with fresh ones.
 - Confirm that the TV is powered on.
- **Buttons not working:**
 - Clean the remote's surface and buttons to remove any dirt or debris that might be obstructing them.
 - If only specific buttons are not working, it might indicate a fault with the remote.
- **Remote works intermittently:**
 - This often indicates low battery power. Replace the batteries.

- Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

If these steps do not resolve the issue, please refer to the warranty and support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	YK-RC802NU YAI1
Brand	Effireli
Color	Black
Special Feature	No Programming Required
Max Number of Supported Devices	1 (Television)
Compatible Devices	Ffalcon Televisions (Specific models listed in Introduction)
Item Weight	2.65 ounces
Package Dimensions	9.02 x 1.89 x 0.79 inches

WARRANTY AND SUPPORT

Your Effireli RC802NU YAI1 Replacement Remote Control comes with the following:

- **30-Day Money-Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **12-Month Warranty:** Covers manufacturing defects. Returns and exchanges are accepted within this warranty period.

For warranty claims, technical support, or any questions regarding your remote control, please contact the seller directly through the platform where you made your purchase. Please have your order details and model number ready for faster assistance.



© 2025 Effireli. All rights reserved.

This manual is for informational purposes only.