Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Effireli RLA502A700B

Effireli RLA502A700B Replacement Remote Control User Manual

Model: RLA502A700B

Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your Effireli RLA502A700B replacement remote control for Mitsubishi Air Conditioners. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install them:

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.




Image: Back view of the remote control, illustrating the battery compartment for installation.

2. Initial Use

This replacement remote control requires no programming or complex setup. Simply install the batteries, point the remote towards your Mitsubishi Air Conditioner, and it is ready for immediate use.

Operating Instructions

To operate your air conditioner, direct the remote control transmitter towards the air conditioner's receiver. The remote features various buttons for different functions:



Image: Front view of the remote control with the protective flap open, displaying all function buttons and the LCD screen.

Basic Functions:

- **ON/OFF:** Press to turn the air conditioner on or off.
- **MODE:** Cycles through operating modes such as Cool, Heat, Dry, Fan, Auto.
- **TEMP ▲/▼:** Adjusts the desired temperature setting.
- **FAN SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).

Advanced Functions:

- **HI ECO:** Activates or deactivates the High Economy mode for energy saving.
- **L/R (Louver/Swing):** Controls the horizontal louver swing.
- **AIR FLOW:** Adjusts the vertical airflow direction.

- **SILENT:** Activates a quiet operation mode.
- **3D AUTO:** Engages the 3D auto airflow function for comprehensive air distribution.
- **NIGHT SETBACK:** Sets the unit to maintain a comfortable temperature during sleep.
- **ON TIMER:** Sets a time for the air conditioner to turn on automatically.
- **OFF TIMER:** Sets a time for the air conditioner to turn off automatically.
- **WEEKLY:** Accesses weekly timer settings for programmed operation.
- **SLEEP:** Activates the sleep mode, which gradually adjusts temperature for comfort.
- **CANCEL:** Cancels active timer settings.
- **SET:** Confirms timer or other settings.
- **CLEAN:** Initiates a self-cleaning function for the indoor unit.
- **TIME SETUP:** Used to set the current time on the remote control display.
- **P/C (Power/Current):** Displays or adjusts power consumption settings.
- **ACL (All Clear):** Resets the remote control to factory default settings. Use a pointed object to press this button if abnormal indications occur.

Maintenance

Battery Replacement

Replace batteries when the remote control's display becomes dim or when the air conditioner no longer responds to commands. Always replace both batteries simultaneously with new ones of the same type.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed and have sufficient power. Replace if necessary.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm you are pointing the remote directly at the air conditioner.
- **Abnormal indication on display:**
  - If the remote control display shows an abnormal indication, press the**ACL** (All Clear) switch using a pointed object (e.g., a pen tip) to reset the remote.
- **Multiple air conditioners changing settings simultaneously:**
  - This remote control transmits a standard signal. If you have multiple air conditioning units in the same room, they may all respond to the same signal, leading to simultaneous changes in settings. This remote does not feature a function to change emission frequencies for individual unit control.

Specifications

- **Item Model Number:** YK-RLA502A700B
- **Brand:** Effireli
- **Special Feature:** No Programming Required
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** Air Conditioner
- **Package Dimensions:** 6.5 x 2.36 x 0.79 inches
- **Item Weight:** 3.53 ounces



Image: Multiple views of the remote control, showcasing its design from the front, side, and back.

Warranty and Support

This product comes with a 30-day money-back guarantee and a 12-month warranty covering manufacturing defects. Returns and exchanges are accepted within the warranty period.
For compatibility inquiries or if your specific air conditioner model is not listed in the product description, please contact the seller directly for assistance.

© 2024 Effireli. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DF31SB7Y

More documents and user manuals: **https://manuals.plus/**