

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nuwave](#) /

› [Nuwave Oven Pro Plus Air Fryer Instruction Manual \(Model 20665\)](#)

Nuwave 20665

Nuwave Oven Pro Plus Air Fryer Instruction Manual

Model: 20665

1. INTRODUCTION

Welcome to the Nuwave Oven Pro Plus Air Fryer instruction manual. This appliance combines conduction, convection, and infrared cooking technologies to provide efficient and versatile meal preparation. Designed for ease of use, it allows for cooking from fresh or frozen states without preheating or defrosting, offering a convenient solution for various culinary needs.



Image 1.1: The Nuwave Oven Pro Plus Air Fryer, demonstrating its cooking capabilities with a whole chicken.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions thoroughly before operating the Nuwave Oven Pro Plus Air Fryer. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- **Electrical Safety:** Ensure the appliance is connected to a grounded outlet. Do not immerse the Power Head in water or other liquids.
- **Hot Surfaces:** The Power Dome, cooking racks, and other internal surfaces become extremely hot during operation. Always use oven mitts or heat-resistant gloves when handling hot components.
- **Supervision:** Close supervision is necessary when the appliance is used by or near children.
- **Ventilation:** Ensure adequate space around the appliance for proper ventilation during operation. Do not block air vents.
- **Intended Use:** Use the appliance only for its intended purpose as described in this manual.

- **Damage:** Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been dropped. Contact customer support for assistance.

3. WHAT'S INCLUDED

Your Nuwave Oven Pro Plus Air Fryer package includes the following components:

- **Power Head:** Contains the heating elements and digital controls.
- **Power Dome:** Transparent, BPA-free, shatterproof dome for visible cooking.
- **1"/3" Reversible Cooking Rack:** Allows for different cooking heights.
- **Base & Liner Pan:** The main cooking chamber and a non-stick liner pan.
- **Dome Holder:** A stand to safely rest the Power Dome when removed.
- **Quick & Easy Cooking Guide:** A supplementary guide for common recipes.
- **Owner's Manual:** This comprehensive instruction manual.

Convenient and Versatile


Small, lightweight and portable



DORM



RV



BOAT



HOME

Image 3.1: Diagram illustrating the various components included with the Nuwave Oven Pro Plus.

4. SETUP

Follow these steps to set up your Nuwave Oven Pro Plus Air Fryer before first use:

- 1. Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
- 2. Placement:** Place the Base on a stable, level, heat-resistant surface. Ensure there is at least 6 inches of clearance on all sides and above the appliance for proper air circulation.
- 3. Assemble:**

- Insert the Liner Pan into the Base.
- Place the Reversible Cooking Rack into the Liner Pan at your desired height (1-inch or 3-inch).
- Carefully place the Power Dome onto the Base, ensuring it sits securely.
- Position the Power Head securely on top of the Power Dome.

4. **Initial Cleaning:** Before first use, wash the Liner Pan, Cooking Rack, and Power Dome with warm, soapy water. Wipe the Power Head with a damp cloth. Ensure all parts are completely dry before assembly and use.

5. OPERATING INSTRUCTIONS

The Nuwave Oven Pro Plus offers intuitive controls for various cooking functions.

5.1 Basic Operation

1. **Power On:** Plug the appliance into a 120V grounded outlet. Press the **POWER** button to turn on the unit.
2. **Set Temperature:** Press the **TEMP** button, then use the numeric keypad to enter your desired temperature (50°F to 350°F).
3. **Set Time:** Press the **TIME** button, then use the numeric keypad to enter your desired cooking time.
4. **Start Cooking:** Press the **START/PAUSE** button to begin cooking.
5. **Adjust On-the-Fly:** During cooking, you can adjust the temperature or time by pressing the respective button and entering new values. The appliance will adjust accordingly.

5.2 Using Presets

The Nuwave Oven Pro Plus features 100 pre-programmed menu presets for common dishes. To use a preset:

1. Press the **MENU** button.
2. Use the numeric keypad to select the desired preset number.
3. Press **START/PAUSE** to begin cooking with the preset settings.

100 Guided Recipes

Anyone Can Cook like a Pro



Image 5.1: The digital control panel of the Nuwave Oven Pro Plus, highlighting temperature and time settings.

5.3 Cooking Functions

This versatile appliance supports multiple cooking methods:

- **Air Fry:** For crispy results with minimal oil.
- **Roast:** Ideal for meats and vegetables.
- **Broil:** For browning and crisping the top layer of food.
- **Sear:** To create a flavorful crust on meats.

- **Bake:** For cakes, cookies, and other baked goods.
- **Dehydrate:** For drying fruits, vegetables, and making jerky.
- **Grill:** For grilling various foods.



Image 5.2: Examples of food items that can be prepared using the Nuwave Oven Pro Plus, demonstrating its capacity and versatility.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your Nuwave Oven Pro Plus Air Fryer.

6.1 Cleaning the Power Dome, Liner Pan, and Cooking Rack

These components are dishwasher safe for convenient cleaning.

1. Ensure the appliance is unplugged and completely cooled before cleaning.
2. Remove the Power Head, Power Dome, Cooking Rack, and Liner Pan.
3. Place the Power Dome, Liner Pan, and Cooking Rack in the dishwasher or wash by hand with warm, soapy water.
4. For stubborn food residue, soak the components in warm, soapy water before scrubbing.
5. Rinse thoroughly and dry completely before reassembly or storage.

6.2 Cleaning the Power Head and Base

The Power Head and Base are not dishwasher safe and should be wiped clean.

1. Ensure the appliance is unplugged and completely cooled.
2. Wipe the exterior of the Power Head and Base with a damp cloth. For tougher stains, use a mild, non-abrasive cleaner.
3. Do not immerse the Power Head or Base in water or any other liquid.
4. Ensure all surfaces are dry before plugging in or storing the appliance.




Image 6.1: The Power Dome, Liner Pan, and Cooking Rack are designed for easy cleaning and are dishwasher safe.

7. TROUBLESHOOTING

If you encounter issues with your Nuwave Oven Pro Plus Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; Power Head not seated correctly.	Ensure the power cord is securely plugged into a working outlet. Check that the Power Head is properly seated on the Power Dome.

Problem	Possible Cause	Solution
Display shows "ERR 2".	Indicates a potential issue with the Power Head or its connection.	Unplug the unit, wait a few minutes, then plug it back in and ensure the Power Head is correctly positioned. If the error persists, contact customer support.
Food not cooking evenly.	Overcrowding the cooking rack; incorrect temperature/time settings.	Avoid overcrowding the cooking rack to allow for proper air circulation. Adjust temperature and time settings as needed. Consider rotating food halfway through cooking.
Smoke coming from the appliance.	Excess fat drippings; food residue on heating elements.	Ensure the Liner Pan is clean. Trim excess fat from food. If smoke persists, unplug immediately and allow to cool before inspecting.

8. SPECIFICATIONS

Feature	Specification
Model Name	Pro Plus 2
Model Number	20665
Product Dimensions	14.5"D x 15.5"W x 12.88"H
Capacity	10 Pounds
Output Wattage	1500 Watts
Voltage	120 Volts
Control Method	Touch
Min Temperature Setting	50 Degrees Fahrenheit
Max Temperature Setting	350 Degrees Fahrenheit
Material	PFAS Free
Dishwasher Safe Parts	Yes (Power Dome, Liner Pan, Cooking Rack)
Special Feature	360 Surround Cooking
UPC	652185902312

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product packaging. Nuwave provides customer support for any questions or issues you may have regarding your Nuwave Oven Pro Plus Air Fryer. For assistance, please visit the official Nuwave website or contact their customer service department using the contact information provided in your product documentation.

Related Documents - 20665

 Owner's Manual & Complete Recipe Book	<p><u>NuWave Brio 3Q Digital Air Fryer Owner's Manual & Recipe Book</u> Comprehensive guide for the NuWave Brio 3Q Digital Air Fryer, covering operation, safety, troubleshooting, and including a full recipe book for healthy cooking.</p>
 Owner's Manual & Complete Recipe Book	<p><u>NuWave Brio Healthy Digital 10Q Air Fryer Owner's Manual and Recipe Book</u> Comprehensive guide for the NuWave Brio Healthy Digital 10Q Air Fryer, including operating instructions, safety precautions, maintenance, troubleshooting, and a complete recipe book. Learn how to use your air fryer for optimal results and explore various cooking options.</p>
 Owner's Manual & Complete Recipe Book	<p><u>NuWave Bravo™ XL Smart Oven: Owner's Manual & Recipe Book</u> Discover the NuWave Bravo™ XL Smart Oven, a versatile kitchen appliance combining air frying, toasting, and convection oven functions. This comprehensive guide includes operating instructions, safety tips, care guidelines, troubleshooting, and a collection of recipes to maximize your cooking experience.</p>
 Owner's Manual & Complete Recipe Book	<p><u>NuWave Brio Digital Air Fryer: Owner's Manual & Recipe Book for Healthy Cooking</u> Master your NuWave Brio Digital Air Fryer with this official owner's manual and recipe book. Find detailed operating instructions, safety guidelines, troubleshooting tips, and a collection of delicious recipes for everyday meals and special occasions.</p>
 Owner's Manual & Complete Recipe Book	<p><u>NuWave PIC Pro Chef Owner's Manual and Recipe Book</u> Comprehensive owner's manual and recipe book for the NuWave PIC Pro Chef induction cooktop, detailing operation, safety, maintenance, troubleshooting, and including a variety of recipes.</p>



[NuWave Brio Gourmet Accessory Kit: Recipes and Usage Guide](#)

Explore delicious recipes and essential care instructions for the NuWave Brio Gourmet Accessory Kit, featuring the Non-Stick Baking Pan and Stainless Steel Reversible Rack. Enhance your air frying experience with this comprehensive guide.