

[Manuals.plus](#) /

› [UPERFECT](#) /

› Uperfect Portable Monitor USteam E6 Pro User Manual

UPERFECT M185E06

Uperfect Portable Monitor USteam E6 Pro User Manual

Model: M185E06

1. INTRODUCTION

Thank you for choosing the Uperfect Portable Monitor USteam E6 Pro. This 18.5-inch portable monitor features a 1920x1080 resolution and a 120Hz refresh rate, designed to enhance your productivity and entertainment experience on the go. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.




Image: The Uperfect USteam E6 Pro portable monitor, showcasing its sleek design and portability.

2. SETUP

2.1 Unpacking

Carefully remove all components from the packaging. Ensure all items listed in the packing list (if provided with the physical product) are present and undamaged.

2.2 Physical Connection

The Uperfect USteam E6 Pro monitor supports various connections including HDMI and USB-C. Identify the appropriate ports on your monitor and source device.



Image: Side view of the Uperfect USteam E6 Pro monitor, highlighting the various input and power ports available for connection.

1. **Power Connection:** Connect the monitor to a power source using the provided power adapter or a compatible USB-C cable if your source device supports power delivery.
2. **Video Input:**
 - **USB-C:** For devices with a full-featured USB-C port (supporting DisplayPort Alternate Mode and power delivery), connect a single USB-C to USB-C cable between the monitor and your device.
 - **HDMI:** For devices with an HDMI output, connect an HDMI cable from your device to the monitor's HDMI port. You will also need to connect a USB-C cable for power.
3. **Audio Output:** If desired, connect headphones or external speakers to the monitor's audio jack.

2.3 Initial Power On

Once connected, press the power button on the monitor. The monitor should automatically detect the input signal. If not, you may need to manually select the input source using the monitor's OSD (On-Screen Display) menu.

3. OPERATING THE MONITOR

3.1 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various settings of the monitor. Typically, buttons on the side or back of the monitor are used to navigate the menu.

- **Brightness/Contrast:** Adjust display luminosity and color depth.
- **Color Settings:** Modify color temperature, gamma, and individual RGB levels.
- **Input Source:** Manually select between USB-C and HDMI inputs.
- **Audio:** Control volume and mute settings for the built-in speakers or connected headphones.
- **Advanced Settings:** Access features like FreeSync, HDR mode, and aspect ratio.

3.2 Usage Scenarios

The Uperfect USteam E6 Pro is versatile for various applications:

- **Extended Desktop:** Connect to a laptop or desktop to expand your workspace.
- **Mirror Display:** Duplicate your primary screen for presentations or shared viewing.
- **Gaming:** Utilize the 120Hz refresh rate for smoother gaming experiences.
- **Mobile Device Connectivity:** Connect to compatible smartphones or tablets for a larger display.



Image: The portable monitor connected to a device, displaying a typical desktop interface, demonstrating its use as an extended display.




Image: The portable monitor displaying a game library, indicating its suitability for gaming with a connected controller.



Image: The portable monitor displaying an action-packed game scene, showcasing its high-resolution and refresh rate capabilities for immersive gaming.

4. MAINTENANCE

4.1 Cleaning the Monitor

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a non-abrasive screen cleaner. Avoid using alcohol, ammonia, or abrasive cleaners.

To clean the casing, use a soft, dry cloth. Do not use liquid cleaners directly on the monitor.

4.2 Storage

When not in use, store the monitor in a cool, dry place away from direct sunlight and extreme temperatures. Use the protective sleeve or original packaging to prevent scratches and dust accumulation.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
No display/No signal	- Power cable not connected. - Incorrect input source selected. - Faulty video cable. - Source device not outputting signal.	- Ensure power cable is securely connected. - Check power adapter is working. - Select correct input source via OSD menu. - Try a different video cable. - Ensure source device is powered on and configured to output to external display.
Flickering screen	- Loose video cable connection. - Interference from other devices. - Refresh rate mismatch.	- Reconnect video cable firmly. - Move monitor away from other electronic devices. - Adjust refresh rate on source device or monitor OSD.
No audio	- Volume too low or muted. - Incorrect audio output selected on source device. - Faulty audio cable (if external speakers).	- Increase volume on monitor and source device. - Check audio output settings on your computer/device. - Ensure external speakers are connected correctly and powered.

6. SPECIFICATIONS

Feature	Detail
Brand	UPERFECT
Model Number	M185E06
Screen Size	18.5 Inches
Resolution	1920x1080 (FHD 1080p)
Refresh Rate	120Hz
Aspect Ratio	16:9

Feature	Detail
Image Contrast Ratio	1000:1
Color	Black
Item Weight	2.2 pounds (approx. 1 kg)
Connectivity	USB-C (full-featured), HDMI
Manufacturer	Uperfect
First Available Date	August 25, 2024



Sicherheitshinweise

gemäß GPSR (General Product Safety Regulation)

Uperfect USteam E6 Pro, 18,5" Portabler Monitor, 1920x1080, 120Hz, IPS, Touchscreen, HDMI + USB-C

Artikelnummer	UPE-M185E06
Hersteller	Uperfect
EAN	5906168438301
Zolltarifnummer	85285210
Herkunftsland	China
Gewicht (in kg)	2.418

Warnhinweise und Sicherheitsinformationen:

- Gerät nur in trockenen Innenräumen verwenden, um Schäden durch Feuchtigkeit zu vermeiden.
- Von offenen Flammen und direkter Sonneneinstrahlung fernhalten.
- Netzstecker und Kabel regelmäßig auf Beschädigungen überprüfen.
- Gerät bei sichtbaren Schäden oder ungewöhnlichen Geräuschen nicht weiter verwenden.
- Bei Reinigung vom Stromnetz trennen und nur mit einem trockenen oder leicht angefeuchteten Tuch reinigen.
- Keine schweren Gegenstände auf das Gerät stellen, um Beschädigungen zu verhindern.
- Produkt nur in Übereinstimmung mit den Anweisungen des Herstellers verwenden.
- Bei Entsorgung geltende Umweltvorschriften beachten; nicht im Hausmüll entsorgen.
- Gerät bei speziellen Sammelstellen oder beim Fachhändler zur Wiederverwertung abgeben.
- Batterie oder Akkus in entnehmbaren Komponenten vorher entfernen und separat entsorgen, falls vorhanden.

Herstellerangaben

Shenzhen Dushang Technology Co., Ltd.
711, Building 2, TOD Technology Center, Bantian Street
CN - Longgang District Shenzhen, Guangdong 518100
help@uprfectmonitor.com
<https://www.uprfectmonitor.de>

WEEE-Nummer: 75851971

Verantwortliche Person für die EU

INNPRO Robert B??dowski sp. z o.o.
Rudzka 65c Street
PL - 44-200 Rybnik
contact@innpro.eu
<https://www.innpro.eu>

7. SAFETY INFORMATION

Please read the following safety instructions carefully before using the monitor to prevent damage or injury.

- The device should only be used in dry indoor environments. Avoid exposure to moisture.
- Keep away from open flames and direct sunlight to prevent damage.
- Regularly check the power plug and cable for damage. Do not use if damaged.
- Do not use the device if it has visible damage or unusual odors.
- For cleaning, disconnect from the power supply and wipe with a dry or slightly damp cloth. Do not use wet cloths.
- Do not place heavy objects on the device to prevent damage.
- Observe all environmental regulations for disposal; do not dispose of with household waste.
- The device should be disposed of at special collection points or returned to a specialist dealer for recycling.
- Remove batteries or other embedded components before disposal, if present.



Image: Original safety instructions document provided with the product (German language).

8. WARRANTY AND SUPPORT

For warranty information and technical support, please contact Uperfect customer service. Details regarding your product's warranty period and coverage can typically be found on the manufacturer's official website or in the product packaging.

Manufacturer Information:

Manufacturer: Shenzhen Dushang Technology Co., Ltd.

Address: 411, Building 2, TCD Technology Center, Bantian Street, CN - Longgang District Shenzhen, Guangdong 518100

Email: help@uperfectmonitor.com

Website: <https://www.uperfectmonitor.de>

WEEE-Number: 75851971

Responsible Person for the EU:

Company: INNPRO Robert B??dowski sp. z o.o.

Address: Rudzka 65c Street, PL - 44-200 Rybnik

Email: contact@innpro.eu

Website: <https://www.innpro.eu>