Baseus MZ10 (A00025700123-Z1)

Baseus True Wireless Earbuds MZ10 User Manual

Model: A00025700123-Z1

1. PRODUCT OVERVIEW

The Baseus True Wireless Earbuds MZ10 are designed to provide a superior audio experience with advanced features such as active noise cancellation and ultra-low latency. These in-ear earbuds offer comfortable wear and intuitive touch controls for seamless interaction with your audio and calls.

Image: Baseus True Wireless Earbuds MZ10 in their open charging case, showcasing the sleek design and compact form factor.

Image: Close-up view of an individual Baseus MZ10 earbud, highlighting the ergonomic in-ear design and the stem with touch control area.

2. WHAT'S IN THE BOX

Verify that all items are present in your package:

- Baseus True Wireless Earbuds MZ10 (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual (This document)

Image: All components included in the Baseus MZ10 retail package, neatly arranged.

3. SETUP

3.1 Charging

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The indicator light on the charging case will illuminate to show charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.
4. Once fully charged, the indicator light will change or turn off. Disconnect the charging cable.

3.2 Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds or case.
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices and select "Baseus Bowie MZ10" from the list.
5. Once connected, a voice prompt will confirm successful pairing, and the indicator light will stop flashing.
6. For subsequent use, the earbuds will automatically connect to the last paired device when removed from the case.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The Baseus MZ10 earbuds feature intuitive touch controls on the stem of each earbud. The functions may vary slightly depending on the specific model version.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold (2s)	Press and Hold (2s)
Activate Voice Assistant	Press and Hold (3s)	Press and Hold (3s)
Toggle ANC/Transparency Mode	Long Press (2s)	Long Press (2s)
Game Mode On/Off	Quadruple Tap	Quadruple Tap

4.2 Call Management

- **Answering a Call:** Single tap either earbud.
- **Ending a Call:** Single tap either earbud during a call.
- **Rejecting a Call:** Press and hold either earbud for 2 seconds.

4.3 Music Playback

- **Play/Pause:** Single tap either earbud.
- **Next Track:** Double tap either earbud.
- **Previous Track:** Triple tap either earbud.

4.4 Gaming Mode

The MZ10 features an ultra-low latency gaming mode (0.06 seconds) for a more synchronized audio-visual experience during gaming. To activate or deactivate this mode, quadruple tap either earbud.

5. MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials. Gently remove earwax buildup from the ear tips and speaker mesh using a small brush or cotton swab.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust, dirt, and damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** The earbuds are not waterproof. Avoid exposure to water, sweat, or high humidity.

6. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close the lid, wait a few seconds, then open the lid again to re-enter pairing mode. On your device, forget the "Baseus Bowie MZ10" from your Bluetooth list and try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case. Close the lid and then open it again. Check if both earbuds are connected. If the issue persists, try resetting the earbuds (refer to manufacturer's specific reset instructions if available, usually involves a long press on the case button).
- **No sound:** Check the volume level on your connected device. Ensure the earbuds are properly seated in your ears. Verify that the earbuds are connected to the correct Bluetooth device.
- **Charging issues:** Ensure the charging cable is securely connected to both the case and the power source. Try a different USB-C cable or power adapter. Clean the charging contacts on the earbuds and inside the case.
- **Poor sound quality:** Ensure the ear tips are the correct size for a good seal in your ear canal. Clean any debris from the earbud speakers. Move closer to your connected device to avoid interference.

7. SPECIFICATIONS

Feature	Specification
Model Name	MZ10 (A00025700123-Z1)
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.2
Ear Placement	In-Ear
Headphones Form Factor	In-Ear
Driver Size	10mm Diaphragm
Microphones	4 Microphones with Noise Cancellation
Noise Control	Active Noise Cancellation (ANC) up to 25dB
Latency	0.06 seconds (Ultra-low latency mode)
Impedance	100 Ohms
Color	Black
Manufacturer	Baseus
Item Dimensions (Shipping)	14 x 11 x 4 cm
Item Weight (Shipping)	160 grams

8. WARRANTY AND SUPPORT

Baseus products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your

product or visit the official Baseus website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Baseus customer support through their official channels. Please have your product model number (A00025700123-Z1) and purchase details ready when contacting support.