

[manuals.plus](#) /› [TCL](#) /› [TCL 75P79B 75-inch 4K LCD Digital TV User Manual](#)**TCL 75P79B**

TCL 75P79B 75-inch 4K LCD Digital TV User Manual

Model: 75P79B

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your TCL 75P79B 75-inch 4K LCD Digital TV. Please read all instructions carefully before operating the television and retain this manual for future reference.

Safety Information

- Ensure the television is placed on a stable surface or securely mounted to a wall to prevent tipping.
- Do not expose the TV to rain or moisture to avoid fire or electric shock.
- Keep ventilation openings clear to prevent overheating.
- Only use accessories specified by the manufacturer.
- Disconnect the power cord during lightning storms or when unused for long periods.

2. PACKAGE CONTENTS

Verify that all items are present in the packaging. If any items are missing or damaged, contact your retailer.

- TCL 75P79B 75-inch 4K LCD Digital TV
- Remote Control (with batteries)
- Power Cord
- TV Stand (2 pieces)
- Screws for TV Stand
- User Manual (this document)

3. SETUP

3.1 Attaching the TV Stand

If you are not wall-mounting the TV, attach the included stand following these steps:

1. Carefully place the TV face-down on a soft, flat surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.

3.2 Connecting Power

Connect the power cord to the TV's power input, then plug the other end into a suitable AC 100V 50/60Hz wall outlet.

3.3 Connecting External Devices

Use the appropriate cables to connect your external devices (e.g., Blu-ray player, game console, antenna) to the TV's input ports.

- **HDMI:** For high-definition video and audio. Your TV has 1 HDMI port.
- **Antenna/Cable:** Connect your terrestrial, BS, or CS digital antenna cable for broadcast channels.

3.4 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your preferred language.
- Connect to your Wi-Fi network (see Section 5.1).
- Scan for available digital channels.



Image: Front view of the TCL 75P79B 75-inch 4K LCD Digital TV with its stand attached. This image illustrates the TV's display and the placement of the stand.

4. OPERATING

4.1 Remote Control Overview

The remote control allows you to access all TV functions. Familiarize yourself with the button layout:

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Input/Source:** Selects the input source (HDMI, Antenna, etc.).
- **Navigation Buttons (Up/Down/Left/Right):** Used to navigate menus.
- **OK/Enter:** Confirms selections.
- **Back/Return:** Returns to the previous screen.
- **Menu/Settings:** Accesses the main settings menu.

4.2 Basic Functions

- **Turning On/Off:** Press the Power button on the remote or the TV.
- **Changing Channels:** Use the Channel Up/Down buttons or enter the channel number directly.
- **Adjusting Volume:** Use the Volume Up/Down buttons.

- **Selecting Input Source:** Press the Input/Source button and select the desired input from the list.

5. SMART TV FEATURES

Your TCL 75P79B TV includes smart features for enhanced connectivity and entertainment.

5.1 Wi-Fi Connection

To access internet services, connect your TV to a Wi-Fi network:

1. Go to **Settings > Network > Wi-Fi**
2. Select your desired Wi-Fi network from the list.
3. Enter the network password if prompted.
4. The TV supports 2.4G+5G Wi-Fi (802.11a/b/g/n/ac).

5.2 Bluetooth Pairing

You can connect Bluetooth devices like headphones or speakers to your TV:

1. Go to **Settings > Remotes & Accessories > Bluetooth**
2. Enable Bluetooth on the TV.
3. Put your Bluetooth device into pairing mode.
4. Select your device from the list on the TV screen to pair.
5. The TV supports Bluetooth V5.0.

5.3 Internet Services

Access various online content and streaming services. The TV supports services like HikariTV.

6. MAINTENANCE

6.1 Cleaning the Screen

- Turn off the TV and unplug the power cord.
- Gently wipe the screen with a soft, lint-free cloth.
- For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.

6.2 General Care

- Keep the TV away from direct sunlight and heat sources.
- Avoid placing heavy objects on top of the TV.
- Do not block the ventilation openings.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Check if the power cord is securely plugged into the TV and the wall outlet. Ensure the outlet has power.
No picture, but sound is present	Verify the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Increase the volume. Check if mute is activated. Verify audio cable connections.
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Ensure your router is on and within range. Re-enter the Wi-Fi password. Try restarting the TV and router.

8. SPECIFICATIONS

Detailed technical specifications for the TCL 75P79B 75-inch 4K LCD Digital TV:

- **Screen Size:** 75 inches (75V type)
- **Display Type:** LCD
- **Backlight:** Direct LED
- **Resolution:** 3840 x 2160 (4K UHD)
- **Aspect Ratio:** 16:9
- **Refresh Rate:** 120 Hz
- **Response Speed:** 8.5 ms
- **HDR Support:** HDR10+
- **Audio Output (Speaker):** 30W (15W x 2), 2.0 Channel Speakers
- **Power Supply:** AC 100V, 50/60Hz
- **Power Consumption:** 245W
- **Annual Power Consumption:** 200 kWh/year
- **Product Dimensions (without stand):** 1666 x 958 x 70 mm (Width x Height x Depth)
- **Product Dimensions (with stand):** 1666 x 1035 x 347 mm (Width x Height x Depth)
- **Weight (with stand):** 23.2 kg
- **Wireless Connectivity:**
 - **Wi-Fi:** 2.4G + 5G (802.11a/b/g/n/ac)
 - **Bluetooth:** V5.0
- **HDMI Ports:** 1

- **Internet Services Supported:** HikariTV
- **Wall Mount Compatible:** Table mount (VESA compatible, specific dimensions not provided in source)

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official TCL website. For technical support, troubleshooting assistance, or service requests, please contact TCL customer support through their official channels.

TCL Official Website: www.tcl.com

© 2024 TCL. All rights reserved.