

Kircuit UR9TM0011, URTM006, URTM007, URTM012, URTM013, URTM019, URTM020, URTM021, URTM022, URTM023, URTM025, URTM028, URFD001

Kircuit AC Power Cord User Manual

For UREVO Treadmill Models: UR9TM0011, URTM006, URTM007, URTM012, URTM013, URTM019, URTM020, URTM021, URTM022, URTM023, URTM025, URTM028, URFD001

INTRODUCTION

Thank you for choosing the Kircuit AC Power Cord. This power cord is designed to provide reliable electrical connection for your compatible UREVO treadmill models. This manual provides essential information for the safe and effective use of your new power cord, including setup, operation, maintenance, and troubleshooting.

SETUP INSTRUCTIONS

Follow these steps to properly connect your Kircuit AC Power Cord to your UREVO treadmill and a power source.

1. **Inspect the Cord:** Before connecting, visually inspect the power cord for any signs of damage, such as cuts, frayed wires, or bent prongs. Do not use a damaged cord.
2. **Ensure Power Off:** Make sure your UREVO treadmill is turned off and unplugged from any existing power source.
3. **Connect to Treadmill:** Locate the AC power input port on your UREVO treadmill. Firmly insert the treadmill-side connector of the Kircuit AC Power Cord into this port. Ensure it is fully seated.
4. **Connect to Power Outlet:** Plug the other end of the AC Power Cord into a standard, grounded electrical wall outlet. Ensure the outlet meets the voltage requirements of your treadmill.
5. **Verify Connection:** Confirm both ends of the power cord are securely connected before attempting to power on your treadmill.

OPERATING THE POWER CORD

The Kircuit AC Power Cord is a passive component designed to transmit electrical power. Its operation is straightforward once properly connected.

- **Power On Treadmill:** After connecting the power cord, you may now turn on your UREVO treadmill using its designated power switch.
- **Safety Precautions:**

- Do not overload electrical outlets.
- Keep the power cord away from heat sources, water, and sharp objects.
- Avoid bending or kinking the cord excessively.
- Always grasp the plug, not the cord, when disconnecting from the outlet.

MAINTENANCE

Proper care and maintenance will extend the life of your Kircuit AC Power Cord.

- **Cleaning:** Disconnect the power cord from both the treadmill and the wall outlet before cleaning. Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or wrapping around sharp objects, which can damage the internal wires. Store in a cool, dry place.
- **Regular Inspection:** Periodically inspect the entire length of the cord, including the plugs, for any signs of wear, damage, or overheating. Replace the cord immediately if any damage is observed.

TROUBLESHOOTING

If you experience issues with your treadmill's power, consider the following troubleshooting steps related to the power cord.

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not fully connected.	Ensure both ends of the power cord are securely plugged into the treadmill and the wall outlet.
Treadmill does not power on.	Wall outlet is not supplying power.	Test the wall outlet with another device. Check the circuit breaker or fuse.
Power cord feels warm.	Overload or internal damage.	Immediately unplug the cord. Do not use it. Replace with a new, compatible cord.
Visible damage to the cord.	Physical wear and tear.	Immediately unplug the cord. Do not use it. Replace with a new, compatible cord.

SPECIFICATIONS

Key technical specifications for the Kircuit AC Power Cord.

- **Brand:** Kircuit
- **Color:** Black
- **Connector Gender:** Male-to-Male
- **Voltage:** 100 Volts (AC)
- **Compatible UREVO Treadmill Models:** UR9TM0011, URTM006, URTM007, URTM012, URTM013, URTM019, URTM020, URTM021, URTM022, URTM023, URTM025, URTM028, URFD001

WARRANTY INFORMATION

Kircuit products are manufactured to high-quality standards. This power cord comes with a limited warranty against defects in materials and workmanship under normal use. Please refer to the product packaging or retailer's website for specific warranty terms and duration. The warranty does not cover damage caused by misuse,

accident, unauthorized modification, or improper installation.

CUSTOMER SUPPORT

If you have any questions or require assistance with your Kircuit AC Power Cord, please contact your retailer or visit the Kircuit official website for support resources. When contacting support, please have your product details and purchase information available.