

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [PUPPY KITTY](#) /
- › [PUPPY KITTY JY-830 Cat Fountain Replacement Pump Instruction Manual](#)

PUPPY KITTY JY-830

PUPPY KITTY JY-830 Cat Fountain Replacement Pump Instruction Manual

Model: JY-830 | Brand: PUPPY KITTY

1. PRODUCT OVERVIEW

This manual provides instructions for the PUPPY KITTY JY-830 replacement pump, designed for use with compatible cat water fountains. This pump ensures continuous water circulation, promoting hydration for your pet.

Compatibility: This replacement pump is **ONLY** compatible with PUPPY KITTY W7 cat fountains (ASINs: B0CHYMKN4L and B0DJVHYDNJ).



Image 1: The PUPPY KITTY JY-830 replacement pump, showing its compact design and USB power cable.

2. PACKAGE CONTENTS

The package includes:

- 1 x PUPPY KITTY JY-830 Replacement Water Pump

3. SETUP INSTRUCTIONS

1. **Prepare the Fountain:** Ensure your cat water fountain is clean and empty.
2. **Position the Pump:** Place the JY-830 pump at the designated location within the fountain's water reservoir. The pump typically attaches to the bottom using suction cups.
3. **Connect Tubing:** Connect the fountain's water outlet tube to the pump's nozzle.
4. **Fill with Water:** Fill the fountain with clean water up to the maximum fill line.
5. **Connect Power:** Plug the USB power cable of the pump into a compatible 100-240V power adapter (not included) and then into a wall outlet.
6. **Verify Operation:** The pump should begin circulating water immediately. If not, refer to the Troubleshooting section.

4. OPERATING THE PUMP

Once properly installed and powered, the PUPPY KITTY JY-830 pump operates continuously to circulate water in your pet fountain. It is designed for ultra-quiet operation, with noise levels below 30 decibels.

Ensure the water level in the fountain is always above the minimum mark to prevent the pump from running dry, which can cause damage and reduce its lifespan.

5. MAINTENANCE AND CLEANING

Regular cleaning of the pump is essential to maintain its performance and extend its lifespan. It is recommended to clean the pump every 2 weeks.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump not working	<ul style="list-style-type: none">• No power supply• Impeller blocked by debris• Low water level	<ul style="list-style-type: none">• Check power connection and outlet.• Clean the pump thoroughly as per Maintenance section.• Ensure water level is above the minimum mark.
Reduced water flow	<ul style="list-style-type: none">• Clogged filter or impeller• Mineral buildup	<ul style="list-style-type: none">• Clean the pump and filter sponge.• Descale with a vinegar solution if mineral buildup is severe.
Pump making unusual noise	<ul style="list-style-type: none">• Impeller obstructed• Running dry	<ul style="list-style-type: none">• Clean the impeller and its housing.• Add water to the fountain.

If issues persist after troubleshooting, please contact customer support.

7. SPECIFICATIONS

Model Number	JY-830
Brand	PUPPY KITTY
Power Type	Electric Cable (USB)
Voltage	DC 5V (compatible with 100-240V adapters)
Noise Level	Below 30 dB
Dimensions (Package)	8.2 x 6.5 x 4.99 cm
Weight (Package)	110 grams
UPC	885319680927

8. WARRANTY AND SUPPORT

PUPPY KITTY provides spare parts availability for 10 years for this product.

For further assistance, troubleshooting, or warranty inquiries, please contact PUPPY KITTY customer support through your purchase platform or the official brand website.

9. IMPORTANT NOTES

- Always unplug the pump before cleaning or performing any maintenance.
- Do not run the pump dry; ensure the fountain always has sufficient water.
- This pump is designed for indoor use with pet water fountains only.

10. VIDEO RESOURCES

No official product videos from the seller were found for this specific replacement pump.

