

- Manuals.plus /
- › Marsail /
- › Marsail TZESD10B-N1 Electric Standing Desk User Manual

Marsail TZESD10B-N1

Marsail TZESD10B-N1 Electric Standing Desk User Manual

Model: TZESD10B-N1

1. INTRODUCTION

Thank you for choosing the Marsail Electric Standing Desk. This adjustable height desk is designed to enhance your workspace by allowing seamless transitions between sitting and standing positions. It features a robust construction, quiet operation, and convenient memory presets for personalized comfort.



Image 1.1: Marsail Electric Standing Desk setup with multiple devices.

2. SAFETY INFORMATION

- **Caution:** Ensure the desk is not overloaded with more than 176 lbs to maintain stability and prevent damage.
- Use the advanced anti-collision sensor to avoid bumps and scratches during height adjustments.
- Keep children and pets away from the desk during operation.
- Ensure all cables are properly managed to prevent entanglement during movement.
- Do not attempt to disassemble or repair the motor or control box yourself. Contact qualified personnel for service.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Desktop Surface

- Leg Frames and Feet
- Motor and Control Box
- Control Panel
- Cable Clip
- Headphone Hook
- Installation Instruction Manual
- Assembly Hardware (screws, wrench, etc.)

4. ASSEMBLY INSTRUCTIONS

The Marsail standing desk is designed for user-friendly assembly with fewer steps. While some tools are included, additional basic tools may be required. It is recommended for one person to assemble the desk.



Image 4.1: Visual guide for quick assembly.

1. Unpack all components and verify against the package contents list.
2. Attach the lifting columns to the desktop following the provided diagrams in the separate installation manual.
3. Secure the feet to the bottom of the lifting columns.
4. Install the control box and connect all motor and control panel cables.
5. Mount the control panel, headphone hook, and cable clips as desired.
6. Ensure all connections are secure and the desk is stable before plugging it into a power outlet.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The Marsail standing desk features advanced 2-stage lifting columns, allowing height adjustments from 28.3 inches to 46.5 inches. The desk operates smoothly at a rate of 1 inch per second with minimal noise, typically under 50 dB.



Image 5.1: Quiet motor operation of the Marsail Standing Desk.

- Press the **Up arrow (▲)** button to raise the desk.
- Press the **Down arrow (▼)** button to lower the desk.
- Release the button at your desired height.

5.2 Control Panel Overview

Convenient Controller

Set and adjust 3 custom height with ease




Image 5.2: Marsail Desk Control Panel.

- **Digital Display:** Shows the current desk height.
- **Up/Down Arrows:** Manually adjust the desk height.
- **Memory Presets (1, 2, 3, 4):** Store and recall preferred height settings.

5.3 Anti-Collision System

The desk is equipped with an anti-collision sensor. If the desk encounters an obstacle during adjustment, it will

automatically stop and reverse slightly to prevent damage.




Image 5.3: Smart Anti-Collision System and cable management features.

6. MEMORY PRESETS

The desk allows you to save up to 4 custom height settings for quick and easy adjustments.



Image 6.1: Desk shown at three different custom height settings.

6.1 Saving a Height Setting

1. Adjust the desk to your desired height using the Up/Down arrows.
2. Press the '**M**' button (if available, or hold the desired number button).
3. Immediately press one of the number buttons (**1**, **2**, **3**, or **4**) to save the current height to that preset. The display may flash to confirm.

6.2 Recalling a Height Setting

- Simply press the desired number button (**1**, **2**, **3**, or **4**). The desk will automatically move to the saved height.

7. MAINTENANCE

- Regularly wipe the desktop surface with a soft, damp cloth. Avoid abrasive cleaners.
- Check all screws and connections periodically to ensure they remain tight.
- Keep the motor and control box free from dust and moisture.
- Ensure the power cord is not pinched or damaged.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, motor cable loose, overload.	Check all cable connections. Ensure desk is not overloaded (max 176 lbs). Unplug and replug the power cord.
Desk moves unevenly or makes unusual noises.	Loose screws, obstruction, damaged component.	Check all assembly screws. Ensure no obstructions are present. If problem persists, contact support.
Display shows error code (e.g., 'E01', 'RST').	Motor error, reset required.	Perform a reset: Press and hold the 'Down' button until the desk reaches its lowest point and slightly rises, or refer to the specific reset procedure in your detailed manual. If the error persists, contact support.
Anti-collision system triggers frequently.	Sensitivity too high, actual obstruction.	Ensure no objects are in the desk's path. Refer to the detailed manual for anti-collision sensitivity adjustment (if available).

9. SPECIFICATIONS



Image 9.1: Marsail Electric Standing Desk Dimensions.

Feature	Detail
Brand	Marsail
Model Number	TZESD10B-N1

Feature	Detail
Product Dimensions	48"D x 28.35"W x 24"H (Note: 24"H likely refers to desktop thickness or a specific component, actual height is adjustable)
Adjustable Height Range	28.3 inches to 46.5 inches
Color	Dark Black
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Maximum Weight Capacity	176 Pounds
Motor Noise Level	Under 50 dB
Assembly Required	Yes
Included Components	Cable Clip, Headphone Hook, Installation Instruction Manual

10. WARRANTY AND SUPPORT

The Marsail Electric Standing Desk comes with a**Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact the seller or Marsail customer service through the platform where you purchased the product. Provide your model number (TZESD10B-N1) and purchase details for faster service.

© 2025 Marsail. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DF7D64HL>

More documents and user manuals: <https://manuals.plus/>