

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [FanttikOutdoor](#) /
- › [FanttikOutdoor Zeta C6 Pro Instant Cabin Camping Tent User Manual](#)

FanttikOutdoor Zeta C6 Pro

FanttikOutdoor Zeta C6 Pro Instant Cabin Camping Tent User Manual

MODEL: ZETA C6 PRO

Brand: FanttikOutdoor

1. SAFETY INSTRUCTIONS

Read and understand all instructions before setting up and using this tent. Failure to follow these instructions can result in serious injury or death.

- **Fire Safety:** Keep all flame and heat sources away from this tent fabric. The tent fabric is not fireproof. It will burn if left in continuous contact with any flame source.
- **Ventilation:** Ensure adequate ventilation to prevent suffocation. Do not use fuel-burning appliances inside the tent.
- **Weather Conditions:** Avoid setting up the tent under trees during thunderstorms or in extreme wind conditions. Always secure the tent with all provided stakes and guy lines.
- **Site Selection:** Choose a flat, dry area away from sharp objects, steep slopes, and potential flood zones.
- **Children's Safety:** Keep children away from the tent during setup and takedown. Do not allow children to play with tent components.

2. PACKAGE CONTENTS

Verify that all components are present before beginning setup.

- 1 x Instant Cabin Tent

- 1 x Carry Bag
- 1 x Peg Bag
- 1 x Gear Loft
- 1 x Welcome Mat
- 1 x Rainfly
- 9 x Stakes

PACKAGING DETAILS

6
PERSON

1 x Instant Cabin Tent



1 x Carry Bag



42.9 inch

7.5 inch



1 x Peg Bag



1 x Gear Loft



1 x Welcome Mat



1 x Rainfly



9 x Stake

Figure 2.1: Detailed view of all items included in the FanttikOutdoor Zeta C6 Pro Instant Cabin Tent package, including the tent, carry bag, rainfly, stakes, gear loft, and welcome mat.

3. SETUP INSTRUCTIONS

The FanttikOutdoor Zeta C6 Pro Instant Cabin Tent features a rapid setup design, allowing for quick deployment.

1. **Unpack the Tent:** Remove the tent from its carry bag and lay it flat on the chosen campsite.
2. **Extend Roof Poles:** With a partner, stand in a diagonal position. Carefully extend all roof poles until they are fully locked. *Caution: Ensure all roof poles are extended before extending leg poles to prevent damage to the pole frame.*
3. **Extend Leg Poles:** Extend each telescoping leg pole downwards until it clicks and locks into place. Repeat for all four corners.
4. **Stake the Tent:** Secure the tent to the ground by staking down each corner of the inner tent.
5. **Attach Welcome Mat:** Clip the welcome mat to the designated loops at the tent entrance.
6. **Attach Rainfly:** Drape the rainfly over the tent. Secure it by clipping the corners to the tent poles and staking down the guy lines. Adjust the guy lines for optimal tension.
7. **Install Gear Loft:** Inside the tent, attach the gear loft to the loops on the ceiling for overhead storage.



Figure 3.1: Visual guide illustrating the four-step instant setup process for the FanttikOutdoor Zeta C6 Pro tent, from unpacking to full erection.



INSTANT SET-UP IN 60S

Figure 3.2: Two individuals demonstrating the quick setup of the FantikOutdoor Zeta C6 Pro tent, highlighting the ease of extending the pre-installed poles.

Setup Videos:

Your browser does not support the video tag.

Video 3.1: A detailed guide on how to set up the FantikOutdoor Zeta C8 Pro Instant Cabin Tent. The setup process is similar for the C6 Pro model.

Your browser does not support the video tag.

Video 3.2: A beginner's guide to easy tent setup, demonstrating the simplicity of deploying the FantikOutdoor Instant Cabin Tent.

4. OPERATING INSTRUCTIONS

4.1. Ventilation

The tent features an advanced ventilation system to ensure comfort in various conditions.

- **Mesh Windows:** The tent has mesh windows on all 4 sides, allowing for cross-ventilation and visibility.
- **Floor Vents:** Additional vents at the floor level promote airflow, keeping the interior cooler.
- **Mesh Ceiling:** A mesh screen design at the ceiling enhances ventilation and offers views of the night sky.



Figure 4.1: Illustration of the advanced venting system in the FanttikOutdoor Zeta C6 Pro tent, highlighting mesh windows and ceiling for optimal airflow.

4.2. Weather Protection

The tent is designed to withstand various weather conditions, providing a dry and stable shelter.

- **Windproof Design:** A stable foundation with strong camping pegs and adjustable camping ropes keeps the tent firm against strong winds.
- **Waterproof Fabric:** Made of high-quality waterproof fabric with a 2000mm water resistance technology, preventing leaks and accumulation.
- **Rainfly:** The included rainfly provides an additional layer of protection against rain.
- **Sealed Seams:** Heat-sealed, taped seams with inverted stitching offer multi-layer protection against moisture.



Figure 4.2: Diagram detailing the weather protection features of the FanttikOutdoor Zeta C6 Pro tent, including the

water-resistant rainfly, fabric, floor, and guy lines.

4.3. Interior Features

The tent offers a spacious and functional interior for a comfortable camping experience.

- **Spacious Interior:** Measuring 120 inches x 108 inches with a maximum height of 66 inches, it comfortably fits a Queen air mattress and allows standing upright.
- **Power Cord Entrance:** A dedicated power cord entrance enables connection to an external power source.
- **Built-in Storage:** Mesh pockets inside facilitate easy storage of small items.
- **Easy-Pull Zippers:** Top-of-the-line SBS zippers provide smooth and quiet operation.



Figure 4.3: Close-up views of the FanttikOutdoor Zeta C6 Pro tent's interior features, including the gear loft, cable port, built-in storage bag, and easy-pull zipper.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your tent.

- **Cleaning:** Hand wash the tent with mild soap and water. Do not use harsh detergents or bleach.
- **Drying:** Always ensure the tent is completely dry before packing it away to prevent mold and mildew.
- **Storage:** Store the tent in its carry bag in a cool, dry place away from direct sunlight.
- **Zipper Care:** Keep zippers clean and free of debris. Lubricate with a silicone-based spray if they become stiff.

Packing Video:

Your browser does not support the video tag.

Video 5.1: Instructions on how to efficiently dismantle and pack away the FanttikOutdoor Instant Cabin Tent.

6. TROUBLESHOOTING

- **Condensation Inside Tent:** Ensure proper ventilation by opening mesh windows and floor vents. Condensation is natural in certain conditions.
- **Zippers Sticking:** Apply a silicone-based lubricant to the zipper teeth. Avoid forcing zippers to prevent damage.
- **Tent Instability in Wind:** Verify all stakes are securely driven into the ground and guy lines are properly tensioned. Ensure the tent is oriented to minimize wind exposure.
- **Water Leakage:** Check for proper rainfly placement and ensure all seams are intact. Re-apply seam sealer if necessary.

7. SPECIFICATIONS

Feature	Specification
Brand	FanttikOutdoor
Model Name	Zeta C6 Pro
Product Dimensions	120"L x 108"W x 66"H
Item Weight	16.8 Pounds
Occupancy	6 Person
Seasons	3 Season
Material	Polyester
Water Resistance Technology	2000mm
Assembly Time	60 Seconds
Number of Doors	1
Number of Windows	4



Figure 7.1: Key dimensions of the FanttikOutdoor Zeta C6 Pro tent, showing length, width, and height for reference.

8. WARRANTY & SUPPORT

This FanttikOutdoor Zeta C6 Pro Instant Cabin Camping Tent comes with a **1 Year Limited Warranty**.

For warranty claims, technical support, or any inquiries, please contact FanttikOutdoor customer service through their official website or the retailer where the product was purchased.