



Manuals.plus /

› MINISO /

› MINISO Kuromi Square Lunch Bag User Manual

MINISO 001

MINISO Kuromi Square Lunch Bag User Manual

1. INTRODUCTION

This user manual provides essential information for the proper use, care, and maintenance of your MINISO Kuromi Square Lunch Bag. Designed for convenience and style, this lunch bag is ideal for keeping your meals fresh and organized. Please read this manual thoroughly before first use to ensure optimal performance and longevity of your product.

2. PRODUCT OVERVIEW

The MINISO Kuromi Square Lunch Bag features a distinctive design with the Kuromi character, combining aesthetic appeal with practical functionality. It offers ample space for meals and snacks, an insulated interior for temperature retention, and a durable, easy-to-clean construction.



Figure 2.1: Front view of the MINISO Kuromi Square Lunch Bag. This image displays the bag's light purple exterior, adorned with a charming Kuromi character accessory, small heart motifs, and subtle skull patterns. The bag is equipped with a robust handle for easy carrying.



Figure 2.2: Rear view of the MINISO Kuromi Square Lunch Bag. This perspective highlights the bag's unadorned light purple back panel and provides a clear view of how the handles are attached and constructed, emphasizing its simple yet functional design.

Key Features:

- **Edgy & Adorable Design:** Features the Kuromi character, combining cuteness with a touch of attitude.
- **Spacious & Organized:** Square design provides ample space for meals, snacks, and drinks, suitable for bento boxes.
- **Insulated for Freshness:** Interior insulation helps maintain food temperature (warm or cool).
- **Durable & Easy to Clean:** Constructed from high-quality materials for daily use and simple cleaning.
- **Portable & Convenient:** Lightweight with a sturdy handle for easy transport.

3. SETUP

3.1 Unpacking and Initial Inspection

1. Carefully remove the lunch bag from its packaging.
2. Inspect the bag for any signs of damage or manufacturing defects. If any issues are found, please contact customer support.
3. Remove any desiccant packets or internal packaging materials.
4. Before first use, it is recommended to wipe the interior and exterior surfaces with a damp cloth and allow it to air dry.

4. OPERATING INSTRUCTIONS

4.1 Packing Your Lunch Bag

- Open the main zipper compartment.
- Place your food containers, snacks, and beverages inside. The square design is optimized for various container shapes.
- For optimal temperature retention, consider using ice packs for cold items or insulated containers for warm items.
- Ensure the zipper is fully closed to maintain insulation and prevent spills.

4.2 Carrying the Lunch Bag

- Use the sturdy top handle for comfortable carrying.
- The lightweight design makes it easy to transport whether you are going to school, work, or an outing.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your MINISO Kuromi Square Lunch Bag.

- **Cleaning:** Wipe the interior and exterior surfaces with a damp cloth using mild soap if necessary. Do not machine wash or submerge in water.
- **Drying:** Allow the bag to air dry completely after cleaning to prevent mold or mildew.
- **Storage:** Store the bag in a cool, dry place when not in use.
- **Avoid Scratching:** As per product care instructions, avoid scratching the bag with hard or sharp objects.
- **Sunlight Exposure:** Avoid direct and strong sunlight exposure for prolonged periods to prevent material degradation and color fading.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your lunch bag.

6.1 Food Not Staying Fresh/Warm/Cold

- **Check Zipper:** Ensure the zipper is fully closed and sealed.
- **Use Ice Packs/Insulated Containers:** For extended temperature retention, use appropriate accessories like ice packs for cold items or thermos containers for hot items.
- **Avoid Overfilling:** Overfilling can prevent proper closure and compromise insulation.

6.2 Zipper Issues

- **Stuck Zipper:** Gently try to move the slider back and forth. Do not force it. Check for fabric caught in the teeth.
- **Difficulty Closing:** Ensure the bag is not overfilled, which can put strain on the zipper.

6.3 Odor Inside the Bag

- **Thorough Cleaning:** Clean the interior thoroughly with a damp cloth and mild soap.
- **Air Dry:** Ensure the bag is completely air-dried in a well-ventilated area after cleaning.
- **Baking Soda:** For persistent odors, place an open container of baking soda inside the bag overnight.

7. SPECIFICATIONS

Feature	Detail
Brand	MINISO
Model Number	001
Colour	Blue (as per product details, though images show purple)
Material	Body: 100% polyester; Coated part: PVC (polyvinyl chloride)
Dimensions (L x W x H)	23L x 12W x 20H Centimeters
Item Weight	154 Grams
Capacity	5500 Milliliters
Closure Type	Zipper
Special Feature	Lightweight
Included Components	Body (1 piece)

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your MINISO Kuromi Square Lunch Bag, please contact MINISO customer service. Please refer to your purchase receipt or the official MINISO website for specific warranty information and contact details.

You can visit the official MINISO store on Amazon for more information:[MINISO Store](#)