Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- GLOBE /
- > GLOBE Electric 61000147 62-inch Floor Lamp User Manual

GLOBE 61000147

GLOBE Electric 61000147 62-inch Floor Lamp User Manual

Model: 61000147 | Brand: GLOBE Electric

Introduction

This manual provides comprehensive instructions for the safe and efficient use of your GLOBE Electric 61000147 62-inch Floor Lamp. Please read this guide thoroughly before assembly and operation, and retain it for future reference. This floor lamp features a matte brass finish and an off-white fabric shade, designed for indoor use.



Image: The GLOBE Electric 61000147 62-inch Floor Lamp.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury to persons, please adhere to the following safety guidelines:

- Ensure the power is OFF before installing or replacing the bulb.
- Do not connect electricity until your fixture is fully assembled.
- This product is intended for indoor use only. Do not expose to water or moisture.
- Use only the specified bulb type and wattage (1x E26/Medium Base 60W Max Bulb).
- Do not use with a dimmer switch unless the bulb is specifically rated for dimmable use.
- Keep flammable materials away from the light source.
- Always unplug the lamp from the electrical outlet before cleaning or performing any maintenance.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before proceeding with assembly. If any parts are missing or damaged, contact customer support.

- · Lamp Base
- Lamp Pole (multiple sections, pre-wired)
- Lamp Shade (off-white fabric)
- Shade Support Ring
- Assembly Tool (if included)



Image: Product packaging showing the GLOBE Electric 61000147 floor lamp.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your floor lamp. No specialized tools are typically required, though a Phillips head screwdriver may be helpful for some connections.

1. Unpack Components: Carefully remove all parts from the packaging. Lay them out on a clean, flat

surface to ensure all pieces are accounted for.

- 2. **Assemble Lamp Pole:** Gently thread the lamp pole sections together, ensuring the electrical cord passes freely through each section. Twist clockwise until securely tightened. Do not overtighten.
- 3. **Attach Pole to Base:** Insert the assembled lamp pole into the lamp base. Secure it by tightening any screws provided, usually located on the side of the base. Some models may require a small tool (often included) or a Phillips screwdriver.
- 4. **Assemble Fabric Shade:** The fabric shade is designed for compact packaging. To assemble, gently push the center wire of the shade inwards and then flip the shade around to expand it into its conical shape. Ensure the shade is fully expanded and taut.
- 5. **Install Shade:** Place the assembled fabric shade onto the lamp's bulb holder. The shade is designed to rest securely on the socket or a designated shade support ring.
- 6. **Install Bulb:** Screw one E26/Medium Base 60W Max bulb (sold separately) into the lamp socket. Do not exceed the maximum wattage.



Image: Detailed diagram illustrating key components and features of the lamp, including the shade, bulb type, height, finish, and switch location.



Image: Close-up of the matte brass lamp base.



Image: Close-up of the off-white fabric shade and the lamp's neck.

OPERATING INSTRUCTIONS

- 1. Connect to Power: Plug the lamp's 6-foot clear cord into a standard 120V electrical outlet.
- 2. **Turn On/Off:** Locate the rotary switch on the lamp socket. Rotate the switch clockwise to turn the lamp ON, and counter-clockwise to turn it OFF.



Image: The floor lamp illuminated, demonstrating its operational state.

MAINTENANCE

- Cleaning: Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe the matte brass finish. For the fabric shade, use a lint roller or a soft brush to remove dust. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it. Unscrew the old bulb and screw in a new E26/Medium Base 60W Max bulb.
- Cord Care: Regularly inspect the power cord for any signs of damage. Do not use the lamp if the cord is frayed or damaged.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	 Lamp not plugged in. Bulb is loose or burnt out. Power outlet is not functioning. Rotary switch is faulty. 	 Ensure the power cord is securely plugged into a working outlet. Tighten the bulb or replace it with a new one. Test the outlet with another appliance. Check circuit breaker. Contact customer support if the switch is suspected to be faulty.
Light flickers.	 Loose bulb. Incorrect bulb type. Unstable power supply. 	 Tighten the bulb. Ensure the bulb is E26/Medium Base and within 60W max. Try plugging the lamp into a different outlet.
Shade appears uneven.	Shade not fully expanded or seated correctly.	Gently adjust the fabric shade to ensure it is fully expanded and rests evenly on the bulb holder.

PRODUCT SPECIFICATIONS

Model Number: 61000147

Brand: GLOBE Electric

Dimensions (D x W x H): 19"D x 19"W x 62"H (48.3cm D x 48.3cm W x 157.5cm H)

Item Weight: 11.2 Pounds (5.08 kg)

Finish Type: Matte Brass

Base Material: Metal

Shade Material: Polyester Fabric (Off-White)

Bulb Base: E26 (Medium Base)

Max Wattage: 60 Watts Voltage: 120 Volts

Light Source Type: Compatible with LED and Incandescent Bulbs

Switch Type: Rotary Switch (on socket)

Cord Length: 6 feet (1.82 m)

Indoor/Outdoor Usage: Indoor Only

Number of Light Sources: 1



Image: Dimensional diagram of the floor lamp.

WARRANTY AND SUPPORT

This product is sold without an explicit manufacturer's warranty as per available information. For any questions, missing parts, or technical assistance, please contact GLOBE Electric customer support directly or visit their official website.

GLOBE Electric Store: Visit the GLOBE Electric Store on Amazon

Related Documents - 61000147



Globe SMART FLOOR LAMP User Manual and Setup Guide

Comprehensive guide for the Globe SMART FLOOR LAMP, including safety instructions, features, specifications, assembly, and connecting to the Globe Suite app and voice assistants like Google Home and Amazon Alexa.



Globe SMART 4 LIGHT TRACK BAR Installation and Safety Guide

Comprehensive guide for the Globe SMART 4 LIGHT TRACK BAR, including safety instructions, electrical installation, features, specifications, and app connectivity for smart home integration. This document is primarily in English with supplementary French content.



Globe Streamwatch Xtreme Prepaid User Manual and Setup Guide

Comprehensive user manual for the Globe Streamwatch Xtreme Prepaid device. Learn how to connect to the internet, stream content on your TV, access apps via Google Play, and find troubleshooting solutions. Includes setup guides and device information.



Globe Smart Switch User Guide

User guide for the Globe Smart Switch, detailing installation, setup via the Globe Suite™ app, features like remote control, scheduling, and voice assistant integration. Learn how to enhance your home with smart lighting control.



Globe Running Boards Assembly Guide for Haul LT Bicycle

Step-by-step instructions and safety information for assembling Globe Running Boards onto your Globe Haul LT bicycle, including parts lists, torque specifications, and weight limits.



Globe Motion Activated Security Light Installation and Operation Guide

Comprehensive guide for installing, operating, and troubleshooting the Globe Motion Activated Security Light. Features include specifications, safety precautions, step-by-step installation instructions, and maintenance tips.