



Manuals.plus /

› HOMCOM /

› HOMCOM Dining Chairs (Set of 4, Model 83A-091V01BK) Instruction Manual

## HOMCOM 83A-091V01BK

# HOMCOM Dining Chairs (Set of 4, Model 83A-091V01BK) Instruction Manual

Model: 83A-091V01BK

Safety Information      Setup & Assembly      Operating Instructions      Maintenance & Care  
Troubleshooting      Specifications      Warranty & Support

## 1. SAFETY INFORMATION

Please read and understand all instructions carefully before assembling and using the HOMCOM Dining Chairs. Retain this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of **264 lbs (120 kg)** per chair. Exceeding this limit may result in damage to the chair or personal injury.
- **Indoor Use Only:** This product is designed exclusively for indoor use. Do not use these chairs outdoors, as exposure to elements can damage the material and compromise structural integrity.
- **Assembly Safety:** Keep all small parts, hardware, and packaging materials away from children and pets during assembly to prevent choking hazards.
- **Stable Surface:** Always place the chairs on a stable, level surface to prevent tipping.
- **Regular Inspection:** Periodically check all screws, bolts, and connections to ensure they remain securely tightened. Re-tighten as necessary to maintain stability and safety.
- **Proper Use:** Do not stand on the chairs or use them as a step stool. Avoid sudden impacts or excessive force.

## 2. SETUP & ASSEMBLY

Assembly is required for these dining chairs. Please follow the steps below carefully.

### 2.1 Unpacking

Carefully open the package and remove all components. Place them on a soft, clean surface (e.g., a carpet or blanket) to prevent scratches during assembly. Verify that all parts and hardware are present according to the included parts list (not provided in this manual, refer to your product packaging).



Image: The product arrives in a single package. Ensure all contents are present upon opening.

## 2.2 Assembly Steps (General Guide)

1. **Identify Components:** Separate and identify all chair legs, seat frames, backrests, and hardware (screws, washers, Allen wrench).
2. **Attach Legs to Seat Frame:** Securely attach the chair legs to the seat frame using the provided hardware. *Do not fully tighten screws at this stage.*
3. **Attach Backrest:** Connect the backrest to the seat frame and rear legs. Ensure proper alignment. *Again, do not fully tighten screws yet.*
4. **Assemble Crossbars/Stretchers:** If applicable, attach any crossbars or stretchers between the legs for added stability.
5. **Final Tightening:** Once all parts are loosely assembled and aligned, place the chair on a flat surface. Sit on the chair briefly to ensure it is level and stable. Then, systematically tighten all screws and bolts firmly using the provided Allen wrench.
6. **Repeat for all chairs:** Follow these steps for each chair in the set.



Image: The assembled HOMCOM dining chairs in a kitchen environment, ready for use.

## 3. OPERATING INSTRUCTIONS

---

The HOMCOM Dining Chairs are designed for comfortable and functional seating in various indoor settings.

- **Intended Use:** These chairs are suitable for dining rooms, living rooms, cafes, or any indoor area requiring additional seating.
- **Seating:** Sit centrally on the chair with your weight evenly distributed. Avoid leaning excessively to one side or placing all weight on the edge of the seat.
- **Space-Saving Design:** The armless design allows these chairs to be easily pushed under most standard dining tables when not in use, optimizing floor space.
- **Movement:** When moving the chairs, lift them rather than dragging them across the floor to prevent damage to the chair legs and your flooring.



Image: The dining chairs complement a dining area, demonstrating their functional placement.

## 4. MAINTENANCE & CARE

---

Proper care will extend the life and appearance of your HOMCOM Dining Chairs.

- **Cleaning:** Wipe the chairs clean with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, damp cloth and then drying thoroughly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or chemical solvents, as these can damage the finish of the pine wood.
- **Spill Management:** Wipe up spills immediately to prevent staining or water damage to the wood.
- **Regular Inspection:** As mentioned in the safety section, regularly check and re-tighten all screws and bolts to ensure the chairs remain stable and safe for use.
- **Environmental Conditions:** Avoid placing the chairs in direct sunlight or near heat sources, which can cause the wood to dry out, crack, or fade. Maintain a consistent room temperature and humidity.

## 5. TROUBLESHOOTING

---

If you encounter any issues with your dining chairs, refer to the following common solutions:

- **Wobbling Chair:** If a chair feels unstable or wobbles, it is likely due to uneven leg lengths or loose

connections. To fix this:

- a. Loosen all screws on the chair slightly.
  - b. Place the chair on a flat, level surface.
  - c. Sit on the chair to apply even pressure and allow it to settle into a level position.
  - d. While seated or maintaining pressure, re-tighten all screws firmly.
- **Loose Parts:** If any part of the chair feels loose or detached, immediately stop using the chair. Inspect all connections and re-tighten any loose fasteners. If a part is broken or missing, contact customer support for assistance.
  - **Squeaking Noises:** Squeaking often indicates loose joints. Follow the steps for a wobbling chair to re-tighten all connections. Applying a small amount of furniture wax or lubricant to the joints (if accessible and appropriate for wood) might also help, but ensure it does not stain the wood.

## 6. SPECIFICATIONS

---

Detailed specifications for the HOMCOM Dining Chairs (Model 83A-091V01BK):

Feature	Detail
Brand	HOMCOM
Model Number	83A-091V01BK
Color	Black
Material	Pine Wood
Overall Dimensions	15.2" W x 18.7" D x 39" H (38.6 cm W x 47.5 cm D x 99.1 cm H)
Seat Size	15.2" W x 17.1" D x 17.7" H (38.6 cm W x 43.4 cm D x 45 cm H)
Back Style	Slat Back
Arm Style	Armless
Maximum Weight Capacity	264 lbs (120 kg)
Item Weight	37.5 lbs (17 kg) for the set
Assembly Required	Yes
Recommended Uses	Dining
Indoor/Outdoor Usage	Indoor
Product Care Instructions	Wipe Clean
UPC	196393038116

## 7. WARRANTY & SUPPORT

---

### 7.1 Warranty Information

No explicit warranty information is provided within this instruction manual. For details regarding the product

warranty, please refer to your purchase documentation, the retailer's website, or contact HOMCOM customer service directly.

## **7.2 Customer Support**

Should you require assistance with assembly, have questions about product functionality, or need to report missing or damaged parts, please contact HOMCOM customer service. You can typically find contact information through the retailer where you purchased the product or on the official HOMCOM website.

When contacting support, please have your model number (**83A-091V01BK**) and proof of purchase readily available.