

Baseus A00051801213-00

Baseus Bowie M2s Pro Wireless Earbuds User Manual

Model: A00051801213-00

1. INTRODUCTION

Thank you for choosing the Baseus Bowie M2s Pro Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as deep noise cancellation, high-resolution spatial audio, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.



Image: The Baseus Bowie M2s Pro earbuds are shown resting in their open charging case, highlighting their compact and sleek design.

2. SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using this product to prevent injury or damage.

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping, impacting, or disassembling the device.
- Use only the provided charging cable and a certified power adapter.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.
- Keep out of reach of children and pets.

3. SETUP

3.1. Unboxing and Initial Charge

Carefully remove all components from the packaging. Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the charging case to a USB power source using the included USB-C cable.
3. The indicator light on the case will show charging status and turn solid when fully charged.



Image: The Baseus Bowie M2s Pro earbuds are securely placed within their charging case, ready for charging or storage.

3.2. Pairing with Your Device

The earbuds support smart connection, allowing pairing with two devices simultaneously.

1. Open the charging case. The earbuds will automatically enter pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Baseus Bowie M2s Pro" in the list of available Bluetooth devices.
4. Select it to connect. Once connected, the indicator light will turn off or show a steady light.
5. For dual device connection, pair with the first device, then disconnect Bluetooth on the first device. Pair with the second device. Reconnect Bluetooth on the first device. The earbuds should now be connected to both.

4. OPERATING INSTRUCTIONS

4.1. Touch Controls

The Baseus Bowie M2s Pro earbuds feature intuitive touch controls on each earbud.

Action	Left Earbud	Right Earbud
Play/Pause	Double-tap	Double-tap
Next Track	Triple-tap	Triple-tap
Answer/End Call	Double-tap	Double-tap
Reject Call	Long press (2s)	Long press (2s)
ANC/Transparency Mode	Long press (1s)	Long press (1s)
Activate Voice Assistant	Quadruple-tap	Quadruple-tap

4.2. Active Noise Cancellation (ANC) and Transparency Mode

The earbuds feature deep 52dB hybrid ANC to reduce ambient noise and a transparency mode to stay aware of your surroundings.

- To cycle through ANC On, Transparency Mode, and ANC Off, long-press either earbud for 1 second.
- The earbuds also feature AI Wind Noise Reduction, which uses a 4-mic ENC algorithm to effectively enhance vocal clarity and mitigate wind noise during calls.




Image: An illustrative diagram demonstrating the AI Wind Noise Reduction technology within the earbuds, showing sound waves and internal components.

4.3. Spatial Audio and High-Resolution Audio

Experience immersive sound with spatial audio and high-fidelity audio playback.

- The earbuds support Hi-Res Audio Wireless and LHDC 5.0 for superior sound quality.
- Spatial audio provides a 3D soundstage for an enhanced listening experience, ideal for music, movies, and games.

4.4. Battery Life and Charging

The Baseus Bowie M2s Pro offers up to 35 hours of total playback with the charging case.

- Earbuds provide approximately 7 hours of playback on a single charge (actual time may vary with volume and ANC usage).
- To charge the earbuds, place them in the charging case.
- To charge the case, connect it to a power source using the USB-C cable.

Perfectly Adapt to Surroundings

There are 3 different types of noise cancellation modes and 10 levels of adjustment so that the noise cancellation will be custom to you and your surroundings.

Daily commute

Blocking out subway and engine noises



Indoors

Blocking out human voices and other noises



Outdoors

Minimizing wind noise during running or other activities



Custom settings

10 levels of noise cancellation for different environments




Image: A visual representation of the battery life, showing 7 hours for the earbuds on a single charge and 35 hours total playback with the charging case.

4.5. Baseus App Customization

Download the Baseus app for additional customization options and features.

- Customize touch controls.
- Adjust sound profiles and equalizer settings.
- Fine-tune noise cancellation levels (10 levels of adjustment).
- Update firmware.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge regularly to maintain battery health.

6. TROUBLESHOOTING

If you encounter issues with your Baseus Bowie M2s Pro earbuds, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Earbuds not pairing	Out of range, low battery, pairing mode not active.	Ensure earbuds are charged and in pairing mode. Move closer to device. Restart Bluetooth on device.
No sound from one earbud	Low battery, connection issue.	Place both earbuds back in case, close, then reopen. Re-pair if necessary. Ensure both are charged.
Poor sound quality	Improper fit, dirty ear tips, interference.	Adjust earbud fit. Clean ear tips. Move away from sources of interference.
Charging issues	Dirty charging contacts, faulty cable/adaptor.	Clean charging contacts on earbuds and case. Try a different USB-C cable and power adaptor.
ANC not effective	Improper fit, wrong mode selected.	Ensure a snug fit with correct ear tip size. Cycle through ANC modes to ensure it's active.

If the problem persists, please contact Baseus customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Baseus Bowie M2S Pro
Item Model Number	A00051801213-00
Brand	Baseus
Color	White
Ear Placement	In-Ear
Headphones Form Factor	In-Ear
Noise Control	Active Noise Cancellation (ANC)
Frequency Response	20 kHz
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Battery Type	2 Lithium Ion batteries (Included)
Total Playtime	Up to 35 hours (with charging case)
Included Components	Cable
Package Dimensions	14 x 11 x 4 cm
Item Weight	200 grams

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Baseus website. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: www.baseus.com

