

## Nubeo NB-6024

# Nubeo Space Magellan Chronograph Watch NB-6024 User Manual

Welcome to your Nubeo timepiece. This manual provides essential information for the proper use and care of your watch.

## 1. PRODUCT OVERVIEW

---

The Nubeo Space Magellan Chronograph Watch NB-6024 is a limited edition timepiece featuring a unique design inspired by space and sea. It is powered by a Japanese TMI VK series hybrid meca-quartz chronograph movement, combining the precision of quartz with the character of a mechanical watch.

### Key Features:

- 48mm Stainless Steel Case
- 26mm Rubber Strap (includes an extra strap)
- Anti-Reflection Coating Mineral Lens
- Water Resistance up to 5 ATM (50 meters)
- Japanese TMI VK series hybrid meca-quartz chronograph movement



A front view of the Nubeo Space Magellan Chronograph Watch NB-6024, showcasing its black case, white rubber strap, and the detailed dial with "Space Invaders" motif.

## 2. COMPONENTS

Familiarize yourself with the main components of your Nubeo watch for optimal operation.

- **Crown:** Located on the side of the watch, used for setting time.
- **Pushers (A & B):** Buttons adjacent to the crown, used to operate the chronograph functions.
- **Dial:** The watch face displaying time, chronograph sub-dials, and design elements.
- **Hands:** Hour, minute, and chronograph hands for timekeeping and measurement.
- **Strap:** The 26mm rubber strap designed for comfortable wear.



An overhead view of the Nubeo Space Magellan Chronograph Watch NB-6024, highlighting its design and the texture of the rubber strap against a dark background.

### 3. SETUP

---

#### Setting the Time:

1. Pull the crown out to position 2 (the outermost position).
2. Rotate the crown to move the hour and minute hands to the desired time.
3. Push the crown back to position 1 (normal operating position) to start the watch.

#### Adjusting the Strap:

The watch is fitted with a durable rubber strap. To adjust the fit, locate the buckle and adjust the pin to the desired hole for a comfortable and secure fit on your wrist. An extra strap is included for replacement or alternative styling.



A close-up view of the watch's case back, revealing engravings such as "MECA-QUARTZ", "ALL STAINLESS STEEL", "WATER RESISTANT 5 ATM", "LIMITED EDITION", and the Nubeo logo.

## 4. OPERATING THE CHRONOGRAPH

The chronograph function allows for precise timing of events. Your watch features two pushers for this operation.

### Starting and Stopping the Chronograph:

1. Press pusher **A** (the top pusher) to start the chronograph. The chronograph second hand will begin to move.
2. Press pusher **A** again to stop the chronograph. The elapsed time will be displayed on the sub-dials.

### Resetting the Chronograph:

1. After stopping the chronograph, press pusher **B** (the bottom pusher) to reset all chronograph hands to their zero positions.
2. If the chronograph is running, pressing pusher **B** will stop and reset it simultaneously.



An angled view of the Nubeo Space Magellan Chronograph Watch NB-6024, showing the side profile of the case, the crown, and the chronograph pushers.

## 5. MAINTENANCE AND CARE

---

### **Water Resistance:**

This watch is water resistant up to 5 ATM (50 meters). This rating indicates suitability for everyday use, including showering and swimming in shallow water. It is *not* suitable for diving, snorkeling, or high-impact water sports. Always ensure the crown is fully pushed in before any contact with water.

### **Cleaning:**

To clean your watch, gently wipe the case and strap with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the watch's finish or seals.

### **Battery:**

The watch operates on 1 unknown battery (included). When the battery requires replacement, it is recommended to have this service performed by a qualified watch technician to ensure proper sealing and maintain the watch's water resistance.



The Nubeo Space Magellan Chronograph Watch NB-6024 displayed in a low-light setting, showcasing the luminous elements on the dial and hands, which glow green.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Nubeo watch, please refer to the following common troubleshooting steps:

### Watch Not Running:

- Ensure the crown is fully pushed in to position 1.
- The battery may need replacement. Contact a qualified watch technician for assistance.

### Chronograph Hands Not Resetting to Zero:

- This may indicate a need for calibration. Consult a watch technician for proper adjustment.

### Water Inside the Watch:

- Immediately take the watch to a qualified watch technician for inspection and repair to prevent further damage to the movement.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	NB-6024
Case Diameter	48mm
Case Material	Stainless Steel
Strap Material	Rubber (26mm)
Movement	Japanese TMI VK series hybrid meca-quartz chronograph
Lens	Anti-Reflection Coating Mineral
Water Resistance	5 ATM (50 meters)
Battery	1 Unknown battery (included)
Package Dimensions	21.4 x 17.2 x 9 cm
Weight	150 g



The Nubeo Space Magellan Chronograph Watch NB-6024 packaging, featuring a "Space Invaders" themed box and a blue protective hard case.

## 8. WARRANTY

Your Nubeo Space Magellan Chronograph Watch NB-6024 comes with a **2-year International Warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for all warranty claims. For detailed warranty terms and conditions, please refer to the official Nubeo website or contact customer support.

## 9. CUSTOMER SUPPORT

For any questions, technical assistance, or service requests regarding your Nubeo watch, please visit the official Nubeo website or contact their customer service department for prompt support.