Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Casaottima SPCB01011504USCP

Casaottima 48-Inch Reversible L-Shaped Computer Desk Instruction Manual

Brand: Casaottima | Model: SPCB01011504USCP

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Casaottima 48-inch Reversible L-Shaped Computer Desk. Designed for versatility and efficiency, this desk features a reversible configuration, integrated storage shelves, and a dedicated PC stand, making it suitable for various home office, gaming, or study environments. Please read these instructions carefully before beginning assembly to ensure proper setup and safe use of your new desk.

Safety Information

Always assemble the desk according to the provided instructions. Ensure the desk is stable and secure before use. Do not exceed the weight limit of the desk. Keep the desk away from heat sources and moisture to prevent damage. Always unplug any electronic devices from the power source before making any adjustments or repairs to the desk or its components.

Package Contents

Before assembly, verify that all components listed in your product's packaging insert are present and undamaged. Typically, your package will include:

- Desktop panels (main and L-extension)
- Metal frame components (legs, support bars)
- Storage shelves and PC stand panels
- Hardware pack (screws, bolts, nuts, washers, Allen wrench)
- Adjustable foot pads
- Headphone hook
- Instruction manual

If any parts are missing or damaged, please contact Casaottima customer support for assistance.


Assembly Instructions

Assembly typically requires two people. Please follow the steps below carefully. The desk's L-shape can be configured to the left or right side during assembly to suit your space.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your package to identify each piece.
2. **Assemble the Main Frame:** Begin by attaching the main desktop support bars to the leg frames using the provided hardware. Do not fully tighten screws until all parts are aligned.
3. **Attach Desktop Panels:** Secure the main desktop panel to the assembled frame. Ensure it is correctly oriented.
4. **Configure Reversible L-Section:** Decide whether you want the L-shaped extension on the left or right side. Assemble the corresponding frame and attach the L-shaped desktop panel. Connect this section to the main desk frame.
5. **Install Storage Shelves and PC Stand:** Attach the two-tier storage shelves and the PC stand to the designated frame section. Ensure they are level and secure.
6. **Install Headphone Hook:** Attach the headphone hook to the desired location on the desk frame.
7. **Tighten All Screws:** Once all components are in place and aligned, systematically tighten all screws and bolts to ensure the desk is stable and secure.
8. **Attach Adjustable Foot Pads:** Screw the adjustable foot pads into the bottom of each leg. Adjust them as needed to level the desk on uneven floors.



This image displays the Casaottima L-shaped computer desk in a typical setup, highlighting its spacious desktop for a monitor and laptop, along with integrated storage shelves. The reversible design is indicated by two smaller desk outlines at the bottom.




This diagram provides precise measurements for the Casaottima L-shaped desk, including its 47.2-inch main length, 31.5-inch return length, 29.8-inch height, and the dimensions of the two-tier storage shelves.



A detailed view of the desk's black wood grain surface, showcasing its texture and finish.



A close-up image of the metal headphone hook, designed for convenient storage of headphones or small bags, located on the side of the desk frame.



This image highlights the X-shaped metal crossbar, which enhances the desk's stability and durability.



A detailed view of one of the desk's adjustable foot pads, designed to stabilize the desk on uneven floors and protect surfaces from scratches.

Operating Instructions

The Casaottima L-Shaped Computer Desk is designed for functional use in various settings.

- **Desktop Usage:** Utilize the spacious desktop for your computer monitors, laptop, keyboard, mouse, and other work or gaming essentials. The 48-inch surface provides ample room for productivity.
- **Storage Shelves:** The two-tier open shelves are ideal for storing books, files, office supplies, or decorative items. Organize your space efficiently to keep your desktop clear.
- **PC Stand:** The dedicated PC stand provides a secure and elevated space for your computer tower, protecting it from dust and allowing for better airflow.
- **Headphone Hook:** Use the integrated headphone hook to conveniently hang your headphones or a small bag, keeping them within reach and off the desktop.
- **Adjustable Feet:** If your floor is uneven, adjust the leveling foot pads at the bottom of each leg to ensure the desk remains stable and wobble-free.



A view of the Casaottima L-shaped desk placed in a corner of a room, featuring a computer monitor, laptop, and organized storage shelves. The desk's black finish complements the modern room decor.



This comparative image illustrates the superior storage capacity of the Casaottima desk, featuring two open shelves and a dedicated PC stand, contrasted with a typical desk offering minimal under-desk storage.

Maintenance

To ensure the longevity and appearance of your Casaottima desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood and metal components.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Overloading:** Do not place excessively heavy items on the desk or shelves beyond their intended capacity.

Troubleshooting

If you encounter any issues with your desk, consider the following common solutions:

- **Wobbling Desk:** Ensure all screws are fully tightened. Adjust the leveling foot pads on the bottom of the legs to compensate for uneven flooring.
- **Missing Parts:** If you find any parts missing upon unboxing, refer to the package contents list and contact Casaottima customer support for replacements.
- **Assembly Difficulties:** Review the assembly instructions carefully. Ensure all components are oriented correctly. If issues persist, contact customer support.

Specifications

Brand	Casaottima
Product Dimensions	31.5"D x 47.2"W x 29.8"H
Color	Black
Style	Modern
Base Material	Metal

Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	L shaped, Reversible, Storage Shelves, PC Stand, Headphone Hook, Adjustable Leg Pads
Room Type	Office, Bedroom, Gaming Room
Recommended Uses	Gaming, Writing, Study, Home Office
Included Components	Headphone Hook
Model Number	SPCB01011504USCP
Item Weight	28.55 Pounds
Size	48 Inch
Number Of Shelves	3 (2 open shelves, 1 PC stand)
Required Assembly	Yes
Recommended People for Assembly	2
Tools Recommended For Assembly	Screw Driver (not included)

Official Product Videos

No official product videos are available for embedding at this time.

Warranty and Support

The Casaottima L-Shaped Computer Desk comes with a limited warranty. For specific warranty details, please refer to the documentation included with your product or visit the official Casaottima website. For customer support, assistance with assembly, or to report missing/damaged parts, please contact Casaottima customer service through the retailer where the product was purchased or via the contact information provided on the Casaottima brand store page.
Visit the Casaottima Store: Casaottima Store on Amazon

© 2025 Casaottima. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFCBFKV4

More documents and user manuals: **https://manuals.plus/**