

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YITAHOME](#) /

› [YITAHOME Storage Tower with 4 Drawers - Instruction Manual](#)

YITAHOME MAYIHZLewq

YITAHOME Storage Tower with 4 Drawers - Instruction Manual

Model: MAYIHZLewq

INTRODUCTION

Thank you for choosing the YITAHOME Storage Tower with 4 Drawers. This versatile fabric dresser is designed to provide efficient storage in various spaces such as bedrooms, living rooms, hallways, entryways, and closets. Featuring a sturdy steel frame, easy-pull fabric bins, and a wooden top, this unit combines functionality with a clean aesthetic. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your product.



Image: The YITAHOME 4-Drawer Storage Tower in Cool Black, shown in a bedroom setting next to a bed.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.


- **Anti-Tipping Safety:** It is highly recommended to anchor the storage tower to the wall using the provided anti-tipping hardware. This is especially important in households with children or pets to prevent accidental tipping and potential injury.
- **Weight Capacity:** Do not overload the drawers or the top surface. Each drawer has a capacity of approximately 6.6 lbs (3 kg). The wooden tabletop has a capacity of approximately 35 lbs (15.8 kg). Exceeding these limits can compromise stability and cause damage.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all parts are securely fastened before use.
- **Placement:** Place the storage tower on a level and stable surface. Adjust the plastic feet as needed to ensure stability on uneven ground.
- **Children:** Keep small parts and packaging materials away from children during assembly.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Instruction Manual
- Metal Frame Components
- Wooden Top Panel
- Fabric Drawers (4 units)
- Drawer Handles
- Adjustable Plastic Feet
- Assembly Tools (e.g., screwdriver, wrench)
- Anti-Tipping Hardware

SOLID CONSTRUCTION



Wooden Tabletop



Anti-Tipping



Adjustable Feet

Image: Illustration of the metal frame components, wooden tabletop, anti-tipping mechanism, and adjustable feet.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your YITAHOME Storage Tower. It is recommended to have a second person assist with assembly for easier handling.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean,

soft surface to prevent damage.

2. **Assemble the Frame:** Connect the metal frame components according to the diagrams in the included instruction manual. Ensure all screws are tightened securely but do not overtighten.
3. **Attach Adjustable Feet:** Screw the adjustable plastic feet into the bottom of the metal frame. These can be adjusted later to level the unit.
4. **Install Wooden Top:** Place the wooden top panel onto the assembled metal frame and secure it using the provided screws.
5. **Prepare Drawers:** Unfold each fabric drawer. Insert the solid hardboard base into the bottom of each drawer to give it shape and stability.
6. **Attach Drawer Handles:** Secure the plastic handles to the front of each fabric drawer using the provided screws.
7. **Insert Drawers:** Slide the assembled fabric drawers into the designated slots in the metal frame.
8. **Install Anti-Tipping Hardware:** For safety, attach the anti-tipping hardware to the back of the storage tower and secure it to a wall stud. Refer to the specific instructions provided with the anti-tipping kit.
9. **Level the Unit:** Adjust the plastic feet at the bottom of the frame to ensure the storage tower is stable and level on your floor.



Image: The YITAHOME 4-Drawer Storage Tower fully assembled and placed in a bedroom.

OPERATING INSTRUCTIONS

Your YITAHOME Storage Tower is designed for easy and efficient storage.

- **Using the Drawers:** Gently pull the plastic handles to open the fabric drawers. Push them back in until they are fully closed. The non-woven synthetic fabric drawers are designed for smooth operation.
- **Storage Capacity:** The drawers are suitable for storing clothing items such as dresses (approx. 40-60), pants (approx. 20-40), and socks (approx. 50 pairs). Avoid placing excessively heavy or sharp objects that could damage the fabric or exceed the weight limit.
- **Top Surface:** The wooden top surface can be used to display decorative items, lamps, or potted plants. Ensure items placed on top do not exceed the 35 lbs (15.8 kg) weight limit.



Image: The YITAHOME 4-Drawer Storage Tower with one drawer partially open, demonstrating its storage capacity for various items.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the YITAHOME Storage Tower.

MAINTENANCE

Proper care will extend the life and appearance of your storage tower.

- **Cleaning the Frame and Top:** Wipe the metal frame and wooden top with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Cleaning Fabric Drawers:** The non-woven synthetic fabric drawers can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely before reinserting. Do not machine wash or tumble dry.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your YITAHOME Storage Tower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit is wobbly or unstable.	Uneven floor; loose connections.	Adjust the plastic feet at the bottom until the unit is stable. Check and tighten all frame screws. Ensure the unit is placed on a flat surface.
Drawers do not slide smoothly.	Drawer overloaded; fabric snagging; frame misalignment.	Reduce the weight in the drawer. Check for any fabric snags or obstructions. Ensure the frame is assembled correctly and not warped.
Drawer handles are loose.	Screws need tightening.	Use a screwdriver to tighten the screws securing the handles to the drawers.
Missing parts during assembly.	Packaging error.	Review the package contents list. Contact YITAHOME customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Number	MAYIHZLewq
Product Dimensions	11.8"D x 17.7"W x 37.4"H (30cm D x 45cm W x 95cm H)
Drawer Dimensions	15.7" L x 11.0" W x 8.3" H (40cm L x 28cm W x 21.1cm H)
Color	Cool Black
Material	Wood, Metal & Fabric (Non-Woven Synthetic Fabric)
Number of Drawers	4
Item Weight	14.33 Pounds (6.5 kg)

Feature	Detail
Assembly Required	Yes
Product Care Instructions	Wipe with Damp Cloth
Top Surface Capacity	35 lbs (15.8 kg)
Drawer Capacity (each)	6.6 lbs (3 kg)

PRODUCT DIMENSIONS

Takes little space, provides large storage space!




Image: Diagram showing the overall dimensions of the YITAHOME 4-Drawer Storage Tower, including width, depth, and height.

WARRANTY INFORMATION

The YITAHOME Storage Tower comes with a limited warranty. Please refer to the specific warranty documentation included with your purchase for details regarding coverage, terms, and conditions. Typically, this warranty covers manufacturing defects under normal use.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your YITAHOME Storage Tower, please contact YITAHOME customer support. Have your model number (MAYIHZLewq) and purchase information ready

when contacting support.

You can often find support contact information on the YITAHOME official website or through the retailer where you purchased the product.

Visit the official YITAHOME store: [YITAHOME Store](#)