

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Spurgehom](#) /

› Spurgehom Handheld Steam Cleaner User Manual

Spurgehom 202-WH

Spurgehom Handheld Steam Cleaner

USER MANUAL

Important Safety Instructions

Please read all instructions carefully before using the Spurgehom Handheld Steam Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the power cord is fully unwound before use to prevent overheating.
- Do not leave the steam cleaner unattended while it is powered on or operating.
- Keep the appliance out of reach of children and pets.
- Do not direct steam at people, animals, or electrical appliances. Steam is extremely hot and can cause burns.
- Use only clean tap water in the water tank. Do not add detergents, perfumes, or other chemicals, as this can damage the appliance or create hazardous fumes.
- Unplug the steam cleaner from the power outlet before filling or emptying the water tank, or when attaching/detaching accessories.
- Allow the appliance to cool completely before storing.
- Do not immerse the steam cleaner in water or any other liquid.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

Product Overview

The Spurgehom Handheld Steam Cleaner is designed for versatile and effective cleaning using high-temperature, high-pressure steam. It features a rapid heat-up time and adjustable steam settings to tackle various cleaning tasks around your home.



Figure 1: Spurgehom Handheld Steam Cleaner with all included accessories. This image displays the complete Spurgehom Handheld Steam Cleaner kit, including the main unit, handheld sprayer, power cord, extension rod, high-pressure nozzle, brass brush, large nylon brush, standard nylon brush, window scraper, and a towel cover.



Figure 2: Diagram of Spurgehom Handheld Steam Cleaner components. A detailed diagram highlighting the key components: the handheld sprayer, 1.5-meter power cord, large capacity water tank, 2-meter steamer tube, high pressure nozzle, large nylon brush, brass brush, standard nylon brush, and extension rod.

Key Features:

- **High Temperature & Pressure Steam:** Heats up in 15 seconds, reaching 212°F/100°C and 3BAR high-pressure steam with 2500W power for effective dirt removal.
- **1000ML Water Tank:** Large capacity tank ensures sufficient steam for extended cleaning tasks.
- **Touch Button Control:** Smart touch screen with 6 gears adjustment for varying steam output and water content.
- **Portable Design:** Lightweight with a 2m steam pipe and 1.5m extra-long power cord for easy maneuverability.
- **Versatile Attachments:** Includes brass brush, nylon brush, window scraper, high pressure nozzle, extension rod, and towel cover for diverse cleaning applications.

High-Temp High Pressure Steam Cleaner



Figure 3: Key features of the Spurgehom High-Temp High Pressure Steam Cleaner. This graphic summarizes the main features: Deep Clean capability, 1L Water Tank, 2500W Powerful motor, 3BAR High Pressure, 15S Heating Time, Multiple Brush Heads, 6 Gears Adjustable, and 212°F/100°C High Temperature.

Setup

- 1. Unpack the Cleaner:** Carefully remove all components from the packaging. Ensure all accessories listed in the "Product Overview" section are present.
- 2. Place on a Stable Surface:** Position the main steam cleaner unit on a flat, stable, and heat-resistant surface.
- 3. Fill the Water Tank:**
 - Ensure the unit is unplugged from the power outlet.
 - Locate the water inlet on top of the unit.
 - Carefully pour clean tap water into the 1000ml water tank. Do not overfill.
 - Close the water inlet cap securely.



Figure 4: Filling the 1000ml water tank and touch panel controls.

4. **Attach the Handheld Sprayer:** Connect the 2-meter steam pipe from the main unit to the handheld sprayer, ensuring a secure connection.
5. **Select and Attach Desired Accessory:** Choose the appropriate cleaning accessory (e.g., high pressure nozzle, brass brush, nylon brush, window scraper) for your task and securely attach it to the handheld sprayer.

Operating Instructions

1. **Power On:** Plug the 1.5-meter power cord into a grounded electrical outlet. The unit will begin to heat up.
2. **Heating Time:** The steam cleaner heats up rapidly in approximately 15 seconds. Wait for the indicator light (if present, or refer to manual for specific indicator) to signal readiness.
3. **Adjust Steam Output:** Use the touch button control panel to select one of the 6 available gear settings. Higher settings provide more steam and higher pressure.



Figure 5: Rapid heating and adjustable steam settings.

4. **Begin Cleaning:** Direct the steam nozzle towards the surface to be cleaned. Move the nozzle slowly over the area to allow the steam to penetrate and loosen dirt.



Figure 6: High-pressure steam in action.

5. Using Different Attachments:

- **High Pressure Nozzle:** Ideal for concentrated steam on stubborn spots or in crevices.
- **Brass Brush:** Use for very tough, baked-on grime on durable surfaces (e.g., oven racks, BBQ grills).
- **Nylon Brush (Large/Standard):** Suitable for general scrubbing on various surfaces like grout, tiles, or sinks.
- **Window Scraper:** Attach with the extension rod for streak-free cleaning of windows, mirrors, and smooth surfaces. Use with the towel cover for delicate surfaces.



Figure 7: Wide application of the steam cleaner with various attachments.

6. **Refilling Water During Operation:** If the water tank runs low during use, unplug the unit, allow it to cool slightly, and then refill as per step 3 in the "Setup" section.
7. **Power Off:** When finished cleaning, unplug the steam cleaner from the power outlet.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Spurgehom Handheld Steam Cleaner.

1. **Empty Water Tank:** After each use, and once the unit has cooled down, carefully empty any remaining water from the tank. This prevents mineral buildup.
2. **Clean Accessories:** Wash all removable accessories (brushes, nozzles, towel cover) with warm, soapy water. Rinse thoroughly and allow them to air dry completely before storing.
3. **Wipe Down Unit:** Wipe the exterior of the main unit and handheld sprayer with a damp cloth. Do not use abrasive cleaners or solvents.
4. **Descaling (Monthly/As Needed):** Depending on water hardness, mineral deposits may build up inside the unit.
 - Mix a solution of equal parts white vinegar and distilled water.
 - Pour the solution into the water tank (do not fill completely).

- Allow it to sit for 30 minutes to an hour (do not heat).
- Empty the solution and rinse the tank thoroughly with clean water several times.
- Run a tank of clean water through the unit to flush out any remaining vinegar residue.

5. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the power cord is neatly wrapped.

Troubleshooting

Problem	Possible Cause	Solution
No steam or very little steam.	<ul style="list-style-type: none"> • Water tank is empty or low. • Unit not heated sufficiently. • Mineral buildup (scale) in the unit. • Nozzle/attachment blocked. 	<ul style="list-style-type: none"> • Refill water tank. • Allow 15 seconds for heating. • Perform descaling procedure (see Maintenance). • Clean or replace the nozzle/attachment.
Water leaking from nozzle.	<ul style="list-style-type: none"> • Unit not fully heated. • Overfilled water tank. • Condensation during initial use. 	<ul style="list-style-type: none"> • Wait for the unit to reach full temperature. • Ensure water tank is not overfilled. • This is normal for the first few seconds of operation.
Unit not turning on.	<ul style="list-style-type: none"> • Not plugged in correctly. • Power outlet malfunction. • Internal fault. 	<ul style="list-style-type: none"> • Check power cord connection. • Try a different power outlet. • Contact customer support if problem persists.

Specifications

Feature	Detail
Brand	Spurgehom
Model Name	202-WH
Wattage	2500 watts
Tank Volume	1 Liters (1000 Milliliters)
Maximum Temperature	212°F (100°C)
Steam Pressure	3 BAR
Heat-Up Time	15 seconds
Power Source	Corded Electric

Feature	Detail
Form Factor	Handheld
Item Weight	4.49 pounds
Package Dimensions	11.34 x 7.64 x 6.57 inches
Included Components	Steam cleaner, brass brush, nylon brush, window scraper, high pressure nozzle, power cord, extension rod, towel cover

Warranty and Support

Spurgehom is committed to providing high-quality products. For warranty information, technical support, or any questions regarding your steam cleaner, please contact Spurgehom customer service.

Please retain your proof of purchase for warranty claims.

For the most up-to-date contact information, please visit the official Spurgehom website or refer to the contact details provided with your product packaging.

Online Support: [Visit the Spurgehom Store on Amazon](#)