

ATYME AMGM5HD-Parent

ATYME 320AM5DVD 32-inch HD LED TV DVD Combo User Manual

Model: AMGM5HD-Parent

INTRODUCTION

Thank you for purchasing the ATYME 320AM5DVD 32-inch HD LED TV DVD Combo. This television combines a high-definition display with a convenient built-in DVD player, offering versatile entertainment options. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new TV. Please read it thoroughly before use to ensure proper functionality and longevity of your device.

PACKAGE CONTENTS

Before proceeding with the setup, please verify that all items listed below are included in your package:

- ATYME 320AM5DVD 32-inch HD LED TV
- Remote Control (x1)
- Remote Batteries (x2)
- User Manual (this document)
- TV Feet (for stand installation)
- Warranty Card



Image: Contents of the product package, showing the TV, remote, batteries, manual, and feet.

SETUP AND INSTALLATION

Attaching the Stand / Wall Mounting

Your ATYME TV can be placed on a flat surface using the included feet or mounted on a wall using a compatible VESA mount (sold separately).

- **For Stand Installation:** Carefully place the TV screen-down on a soft, clean surface. Align the TV feet with the designated slots on the bottom of the TV and secure them with the provided screws. Ensure the feet are firmly attached before placing the TV upright.
- **For Wall Mounting:** This TV supports standard VESA mounting. Refer to your wall mount's instructions for proper installation. Ensure the wall mount is compatible with the TV's VESA pattern and weight.

WALL-MOUNT OR STAND

Whatever you want



Image: Illustration of the TV's versatility for stand placement or wall mounting.

Connecting External Devices

The ATYME 320AM5DVD offers various input and output ports for connecting external devices.

- **HDMI:** Connect high-definition devices such as Blu-ray players, game consoles, or cable/satellite boxes to the HDMI ports. This TV features two HDMI 1.4 ports, one of which supports ARC (Audio Return Channel).
- **USB:** Insert a USB drive to play compatible media files.
- **VGA:** Connect a computer using a VGA cable for use as a monitor.
- **Composite (CVBS)/Audio:** Use for older devices with composite video and stereo audio outputs.
- **Antenna/Cable:** Connect an antenna for over-the-air broadcasts or a cable TV connection.
- **Optical Audio Out:** Connect to a soundbar or home theater system for digital audio output.
- **Headphone Analog Audio Out:** Connect headphones or external speakers.



Image: Connectivity diagram showing available ports and compatible devices.




Image: The TV connected to multiple external devices, highlighting its input capabilities.

Powering On

After connecting all desired devices and ensuring the TV is securely placed, plug the power cord into a wall outlet. Press the power button on the TV or the remote control to turn on the television.

OPERATING INSTRUCTIONS

Using the Remote Control

The included remote control allows you to access all functions of your ATYME TV. Insert the two AAA batteries (included) into the remote control, observing polarity.

Navigating Menus

Use the directional buttons on the remote to navigate through the on-screen menus. The 'OK' or 'Enter' button confirms selections, and the 'Back' or 'Exit' button returns to the previous screen or exits the menu.

Picture and Sound Settings

Access the 'Picture' menu to adjust settings such as brightness, contrast, color, and sharpness. The 'Sound' menu allows you to modify volume, bass, treble, and select sound modes. The TV features a Wide Color Controller for an enhanced color spectrum.

DVD Player Operation

To use the built-in DVD player, gently insert a DVD disc into the slot located on the side of the TV. The TV will automatically switch to DVD mode or prompt you to select it. Use the remote control for playback functions such as Play, Pause, Stop, Fast Forward, and Rewind.



Image: The ATYME TV with a DVD disc, illustrating the integrated DVD player.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your ATYME TV, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals or abrasive materials.
- **Cleaning the Cabinet:** Use a soft, dry cloth to clean the TV cabinet.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block the ventilation openings.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, discontinue use and contact customer support.
- **Storage:** If storing the TV for an extended period, disconnect it from power and store it in a cool, dry place, preferably in its original packaging.

TROUBLESHOOTING

If you encounter issues with your ATYME TV, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Power	Ensure the power cord is securely plugged into the TV and a working electrical outlet. Check if the power outlet is active.
No Picture / Poor Picture Quality	Verify that the correct input source is selected. Check all cable connections (HDMI, VGA, etc.) are secure. Adjust picture settings (brightness, contrast). If using an antenna, check signal strength.
No Sound / Poor Sound Quality	Check the volume level and ensure the TV is not muted. If using external speakers or a soundbar, ensure they are properly connected and powered on. Adjust sound settings in the TV menu.
Remote Control Not Working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.

Problem	Possible Cause / Solution
DVD Not Playing	Ensure the disc is inserted correctly with the label side facing up. Check if the disc is clean and free of scratches. Verify the disc format is compatible with the built-in DVD player.
Cannot Connect to PC as Monitor	Ensure the VGA cable is securely connected. Adjust display settings on your computer (resolution, aspect ratio) to match the TV's capabilities (1366x768 resolution).

If the problem persists after trying these solutions, please contact ATYME customer support for further assistance.

TECHNICAL SPECIFICATIONS

Detailed specifications for the ATYME 320AM5DVD TV:

- **Model:** AMGM5HD-Parent
- **Display Size:** 32 inches (Visible screen diagonal: 82 cm)
- **Display Type:** LED (Rear-lit)
- **Resolution:** 1366x768 (720P HD)
- **Refresh Rate:** 60Hz
- **Response Time:** 8.5 ms
- **Contrast Ratio:** 3000:1
- **Aspect Ratio:** 16:9
- **Audio:** Dual Channel 8W Speakers
- **Inputs:**
 - HDMI 1.4 (x2, one with ARC)
 - USB (x1)
 - VGA (x1)
 - PC Audio (x1)
 - Composite (CVBS)/Audio (x2)
 - Antenna/Cable (x1)
- **Outputs:**
 - Optical Audio (x1)
 - Headphone Analog Audio (x1)
- **Special Features:** Built-in DVD Player, Flat Panel, Wide Color Controller
- **Power Consumption:** On-mode: <60W, Standby: 0.5W
- **Product Dimensions (D x W x H):** 4.8 x 30.7 x 18.82 inches
- **Item Weight:** 9.5 pounds
- **Mounting:** Standard VESA compatible

Federal law prohibits removal of this label before consumer purchase.

ENERGY GUIDE

Television

ATYME Corporation, Inc.
320AM5DVD

Estimated Yearly Energy Cost

\$10

Cost Range of
Similar Models
(30" – 34")

\$25

—

—

—

\$11

- Based on 12 cents per kWh and 5 hours use per day
- Estimated yearly electricity use of this model: 80kWh
- **Your cost depends on your utility rates and use.**

Visit ftc.gov/energy

Image: Energy Guide label for the ATYME 320AM5DVD.

WARRANTY AND SUPPORT

Your ATYME 320AM5DVD TV comes with a standard warranty. Please refer to the included Warranty Card for specific terms and conditions, including the warranty period and coverage details. Keep your purchase receipt as proof of purchase.

Return Policy

This product is typically eligible for returns within 30 days of purchase, subject to the retailer's return policy. Please consult the



retailer where you purchased the TV for their specific return procedures.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact ATYME customer support. Contact information can typically be found on the warranty card or the official ATYME website. Consider purchasing an extended protection plan for additional coverage beyond the standard warranty. Options such as 2-Year or 3-Year Protection Plans may be available from your retailer.

© 2025 ATYME Corporation. All rights reserved.

Related Documents

	<p>ATYME 320AX5HD User Manual: Setup, Operation, and Troubleshooting Guide</p> <p>Comprehensive user manual for the ATYME 320AX5HD television, providing detailed instructions on setup, connecting devices, using the remote control, navigating menus, troubleshooting common issues, and product specifications.</p>
	<p>Atyme 32" HDTV Quick Start Guide and Warranty Policy</p> <p>This document provides a quick start guide for setting up your Atyme 32" HDTV and outlines the Atyme Corporation Warranty Policy for products purchased in the USA. It includes setup instructions, connection diagrams, and FCC compliance information.</p>