Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsonite 152024-A382

Samsonite UpLIFT Lightweight Softside Carry-On Luggage User Manual

Model: 152024-A382

1. Product Overview

The Samsonite UpLIFT Softside Carry-On Luggage is designed for lightweight and versatile travel. It features a durable polyester construction with a focus on balancing durability and style. The outer and inner lining are made from 100% post-consumer recycled PET bottles, contributing to sustainability.



Image 1.1: Samsonite UpLIFT Lightweight Softside Carry-On Luggage, Elemental Blue.

Key Features:

- **Lightweight Design:** Weighs only 5.7 lbs, meeting carry-on size restrictions for light travel.
- **RightHeight Handle System:** Multi-stop adjustments for customized handle height.
- **Interior Organization:** Includes a mesh-dual access pocket, seatbelt webbing cross straps, and a removable 3-1-1 wet pouch.
- **Effortless Mobility:** Patented spinner wheels optimized for shock absorption and noise reduction.
- **Retractable ID Tag:** For easy identification.
- **Expandable Capacity:** Expansion zipper provides an additional 0.75 inches of packing space.
- **Durable Construction:** Body fabric made from 100% post-consumer recycled PET bottles.
- **10-Year Limited Warranty:** Against defects in materials and workmanship.

2. Initial Setup

2.1 Adjusting the Handle

The RightHeight handle system allows you to adjust the telescopic handle to multiple stopping points for optimal comfort. To extend the handle, press the button located on the top of the handle and pull upwards. Release the button at your desired height. To retract, press the button and push the handle downwards until fully collapsed.



Image 2.1: The RightHeight handle system offers multiple height adjustments.

2.2 Utilizing Expansion

For additional packing capacity, locate the expansion zipper around the perimeter of the main compartment. Unzip this zipper to expand the luggage by an additional 0.75 inches. This feature is useful when you need extra space for souvenirs or bulkier items.



Image 2.2: The expansion zipper provides extra storage capacity.

3. Operating Instructions

3.1 Interior Organization

The main compartment features several organizational elements:

- **Mesh Divider with Pocket:** Helps separate contents and provides additional storage for smaller items.
- **Elastic Compression Straps:** Secure your belongings and maximize packing space by compressing clothes.
- **Removable 3-1-1 Wet Pouch:** Ideal for storing liquids, keeping them separate from your clothing and compliant with TSA regulations.



Image 3.1: Interior features for maximizing packing potential.

3.2 Exterior Pockets and Features

- **Dual-Access Front Pocket:** Provides quick access to items without fully opening the main compartment.
- **Built-In USB Charging System:** (Note: Power bank not included) Connect your power bank inside the luggage to the integrated USB port for convenient charging of your devices on the go.
- **Retractable ID Tag:** Located on the back or side of the luggage for easy identification.



Image 3.2: Built-in USB charging system for device convenience.

3.3 Mobility

The luggage is equipped with Samsonite's patented spinner wheels, designed for 360-degree rotation. These wheels are optimized for shock absorption and noise reduction, ensuring smooth and effortless maneuverability through airports and various terrains.



Image 3.3: Patented 360° spinner wheels for smooth movement.

4. Care and Maintenance

4.1 Cleaning Instructions

To clean your polyester softside luggage, use a soft cloth dampened with mild soap and water. Gently wipe down the exterior surfaces. For stubborn stains, a specialized fabric cleaner may be used, following the product instructions. Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric and finish. Allow the luggage to air dry completely before storage.

4.2 Storage

Store your luggage in a cool, dry place away from direct sunlight when not in use. Ensure it is clean and dry to prevent mold or mildew growth. Avoid placing heavy objects on top of the luggage for extended periods to maintain its shape.

5. Troubleshooting

If you encounter any issues with your Samsonite UpLIFT luggage, please refer to the following common solutions:

- **Stuck Handle:** Ensure no fabric or items are obstructing the telescopic handle mechanism. Press the release button firmly and try extending/retracting the handle.
- **Wheels Not Rolling Smoothly:** Check for debris (hair, lint, dirt) caught in the wheel axles. Clean the wheels gently. If a wheel is damaged, contact customer support.
- **Zipper Issues:** If a zipper is stuck, try gently moving the slider back and forth. Avoid forcing it. Lubricating with a wax-based product can sometimes help.
- **General Damage:** For any other damage or manufacturing defects, please refer to the warranty information and contact Samsonite customer support.

6. Product Specifications

Feature	Detail
Brand Name	Samsonite
Model Number	152024-A382
Size	Carry-On
Color	Elemental Blue
Material Type	Polyester
Shell Type	Soft
Item Weight	5.7 pounds
Item Dimensions (L x W x H)	13.7"L x 7.8"W x 20.2"H (Interior packing dimensions)
Overall Dimensions (with wheels)	23.5 in. x 15 in. x 10.25 in.
Wheel Type	Spinner (8 wheels)
Handle Type	Telescopic Extendable Handle (RightHeight System)
Water Resistance Level	Water Resistant
Lock Type	Combination Lock
Number of Pockets	3
UPC	840359610341

7. Warranty and Customer Support

7.1 10-Year Limited Warranty

This Samsonite UpLIFT Lightweight Softside Carry-On Luggage comes with a**10-year limited warranty** against defects in materials and workmanship. This warranty covers manufacturing defects and does not cover damage caused by misuse, neglect, accidents, abrasion, extreme temperatures, solvents, acids, normal wear and tear, or transport damage (e.g., by airlines). For warranty claims, please retain your proof of purchase.

7.2 Customer Support

For further assistance, warranty claims, or to inquire about replacement parts, please visit the official Samsonite website or contact their customer service department. You can find more information and contact details on the Samsonite Store on Amazon.

© 2026 Samsonite. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFD22NG1

More documents and user manuals: **https://manuals.plus/**