

TVB

Generic TV Bingo and Horseracing Game (Model TVB) Instruction Manual

Your Guide to Setup and Operation

[Introduction](#) [Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)
[Warranty & Support](#)

1. INTRODUCTION

The Generic TV Bingo and Horseracing Game (Model TVB) is a game arcade designed for group play, featuring two distinct games: TV Bingo and Horse Race TV. This device connects to your television via an HDMI cable, providing an interactive gaming experience. It is recommended for use with television screens 40 inches and larger.



2 Games in 1!
Play Bingo and Horse Racing
on your large-screen TV

Large, easy-to-read display with clear audio announcements

Manually or automatically draw bingo numbers

Figure 1: The TV Bingo and Horseracing Game device, remote control, and example game screens.

2. SETUP

Follow these steps to set up your TV Bingo and Horseracing Game device:

1. **Unpack the Device:** Carefully remove the game arcade and its components from the packaging. Ensure all included items, such as the remote control and HDMI cable, are present.
2. **Connect to TV:** Locate an available HDMI port on your television. Plug one end of the included HDMI cable into the game arcade and the other end into the HDMI port on your TV.
3. **Power On:** Connect the game arcade to a power source using the provided USB cable. The device will power on automatically.
4. **Select Input:** Using your TV remote, select the corresponding HDMI input channel to display the game interface.



Figure 2: Connecting the game device to a TV's HDMI port.

3. OPERATING INSTRUCTIONS

The game arcade offers two primary games: TV Bingo and Horse Race TV. Use the included remote control to navigate menus and control gameplay.

3.1. TV Bingo Game

The TV Bingo game draws, calls, and displays randomly selected bingo numbers directly on your TV screen. The interface is designed for clarity and ease of reading.

- **Number Drawing:** Numbers can be drawn manually using the remote or automatically with a selectable timer.
- **Masterboard:** A digital masterboard displays all called numbers. The last four drawn numbers are also shown for quick reference.
- **Audio Announcements:** Numbers are audibly announced through your TV's audio system. You can select between a male or female announcer voice.
- **Bingo Cards:** Physical bingo cards are not included with the device.



Figure 3: The TV Bingo game screen displaying called numbers.

3.2. Horse Race TV Game

Experience live-action horseracing on your TV with the Horse Race TV game. This game supports any number of players.

- **Horse Selection:** Players can select from six horses to win, place, or show.
- **Race Progression:** Horses advance randomly, one or two positions per call, until the first, second, and third place winners cross the finish line.
- **Scoring:** Each winning horse has a point value that can be recorded on an accompanying racing form (master form included on USB drive).
- **Audio & Visual Cues:** The game includes crowd sounds, audio announcements, and a leaderboard to display horse status for visual and hearing impaired users.
- **Race Duration:** Each race typically lasts about two minutes.
- **Horse Race Bingo:** An alternative mode allows players to stamp the winning horse for each race on a unique bingo card. PDF files for 25-set bingo cards are included on the USB drive.





Figure 4: The Horse Race TV game screen during a race.

Pick Your Horses

	WIN	PLACE	SHOW
Race 1	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 2	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 3	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 4	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 5	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 6	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 7	<input type="text"/>	<input type="text"/>	<input type="text"/>
Race 8	<input type="text"/>	<input type="text"/>	<input type="text"/>



To re-order, call (888) 978-4932

Figure 5: Example racing form for tracking horse selections and winnings.

3.3. Product Demonstration Video

Watch this video for a short demonstration of both the TV Bingo and Horse Race TV games.

Your browser does not support the video tag.

Video 1: A short demonstration of the TV Bingo and Horse Race Game features.

4. MAINTENANCE

To ensure the longevity and optimal performance of your game arcade, follow these general maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device and remote control. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Handle the HDMI and USB cables carefully to prevent damage. Avoid sharp bends or excessive pulling.

5. TROUBLESHOOTING

If you encounter issues with your TV Bingo and Horseracing Game, refer to the following common troubleshooting steps:

- **No Display on TV:**
 - Ensure the HDMI cable is securely connected to both the game arcade and the TV.
 - Verify that your TV is set to the correct HDMI input source.
 - Check if the device is receiving power (indicated by any LED lights on the unit).
- **No Sound:**
 - Confirm your TV's volume is not muted or set too low.
 - Check the audio settings within the game menu.
- **Remote Control Not Responding:**
 - Ensure there are no obstructions between the remote and the game arcade.
 - Replace the batteries in the remote control if necessary.
- **Game Freezes or Crashes:**
 - Restart the game arcade by disconnecting and reconnecting the power.
 - If the issue persists, contact customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	Generic
Model Number	TVB
Manufacturer	Briteworx
Item Dimensions	4 x 4 x 1 inches
Item Weight	0.5 Pounds
Material Type	Plastic
Power Source	USB
Included Components	Remote Control
Number of Players	Up to 50
Operation Mode	Manual
Assembly Required	No

7. WARRANTY & SUPPORT

The TV Bingo and Horseracing Game includes a 1st year warranty and support from Briteworx. After the initial year, additional years of warranty and game updates can be purchased annually. These extended plans may include software and product updates, phone support, and device replacement if needed. The annual extended warranty is not required for the product to continue functioning, as the game arcade is designed for long-term use.

