

[manuals.plus](#) /› [Groove](#) /› [Groove Electronics 4-in-1 Wireless Earbuds User Manual](#)**Groove 4-1 Wireless Earbuds Travel Kit- Black**

Groove Electronics 4-in-1 Wireless Earbuds User Manual

MODEL: 4-1 WIRELESS EARBUDS TRAVEL KIT- BLACK

Introduction

Thank you for choosing the Groove Electronics 4-in-1 Wireless Earbuds. This comprehensive kit is designed to enhance your audio experience and keep you powered on the go. Featuring advanced Bluetooth 5.3, IPX7 waterproofing, and an impressive 80 hours of total playtime with the charging case, these earbuds deliver superior sound and convenience for your active lifestyle. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.



Image: Groove Electronics Wireless Earbuds being used in various active scenarios like driving, traveling, everyday use, and sports, highlighting their versatility.

Package Contents

Your Groove Electronics 4-in-1 Wireless Earbuds kit includes the following items:

- Wireless Earbuds (Left and Right)
- Charging Case
- Dual Port 25W Quick Charge Adapter
- Wireless Phone Charging Pad
- Protective Carrying Case
- USB-C Charging Cable
- Ear Cushions (various sizes)



Image: A complete view of the Groove Electronics 4-in-1 Wireless Earbuds kit, showing the earbuds, charging case, wireless charging pad, dual port adapter, USB-C cable, protective case, and ear cushions.

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the charging case and the other end to the provided Dual Port 25W Quick Charge Adapter. Plug the adapter into a power outlet. The LED display on the charging case will indicate the charging status. A full charge provides up to 14 hours of playtime for the earbuds and up to 80 hours total with the charging case.

**ENJOY UNINTERRUPTED MUSIC
AND CALLS FOR UP TO 80 HOURS**

**80 HOURS WITH
CHARGING CASE**



**14 HOURS SINGLE
CHARGE**



Image: Illustration showing the charging case with an LED display indicating 100% charge, emphasizing the 80 hours of total playtime and 14 hours single charge.

25W DUAL PORT QUICK CHARGING

- CHARGE PHONE & EARPHONE CASE AT THE SAME TIME
- TYPE-C + USB-A UNIVERSAL CHARGING PORTS



Image: Setup showing the 25W dual port quick charger adapter plugged into a wall outlet, charging both the earbud case and a smartphone via the wireless charging pad simultaneously.

2. Bluetooth Pairing

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Look for "GROOVE-X31" (or similar model name) in the list of available devices and select it to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.

The earbuds feature Bluetooth 5.3 for a stable and extended connection range of up to 100 feet.

LIGHTNING FAST BLUETOOTH PAIRING FOR SEAMLESS CONNECTIVITY



Image: A visual representation of the earbuds pairing with a smartphone via Bluetooth 5.3, showing the Bluetooth icon and a connection status on the phone screen.

Operating Instructions

Wearing the Earbuds

The Groove Electronics earbuds are designed with ear hooks for a secure and comfortable fit, ideal for active use. Choose the appropriate ear cushion size for optimal comfort and sound quality. Gently place the earbud into your ear canal and adjust the ear hook over your ear until it feels snug and stable.

Stay Organized & Charged While “On The Go” With The 4-IN-1 Wireless Active LIFESTYLE Earphones & Charging Kit



Image: The Groove Electronics earbuds and charging case displayed on a tray, along with the wireless charging pad, dual port adapter, USB-C cable, and protective carrying case, illustrating the complete travel kit.

Button Controls

The earbuds feature intuitive push-button controls for easy management of music and calls:

Action	Control
Play/Pause	Single press (L/R)
Switch Song (Next/Previous)	Double press (L/R)
Voice Assistant (Siri)	Triple press (L/R)
Answer/Hang up Call	Single press (L/R)
Adjust Volume	Press and hold for 2 seconds (L for Volume Down, R for Volume Up)
Reject Call	Press and hold for 2 seconds (L/R)

Action	Control
Reset	Five presses (L/R)
Power On/Off	Press and hold for 2/5 seconds (L/R)



Image: A detailed diagram illustrating the intuitive push-button controls on the earbuds, showing single, double, triple, and long presses for various functions like play/pause, skip song, voice assistant, answer/hang up, adjust volume, reject call, reset, and power on/off.

Wireless Phone Charging Pad

The included wireless phone charging pad allows you to conveniently charge compatible smartphones. Simply place your phone on the charging pad. Ensure your phone is centered on the pad for optimal charging. The charging pad requires power from the dual port adapter or another USB power source.

Audio Quality

Experience high-definition stereo sound with robust 10mm drivers, delivering rich bass, clear mids, and crisp highs for an immersive audio experience.

IMMERSE YOURSELF IN HIGH DEFINITION STEREO SOUND BRINGING MUSIC TO LIFE



Image: A visual representation of sound waves emanating from an earbud, illustrating high-fidelity stereo sound and an immersive listening experience.

Maintenance

Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe down the surfaces. For ear cushions, remove them and clean with a mild soap solution if necessary, then rinse and dry thoroughly before reattaching. Do not use abrasive cleaners or immerse the charging case in water.

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This makes them ideal for workouts and outdoor activities, providing protection against sweat and rain. However, the charging case is not waterproof. Always ensure earbuds are dry before placing them back

into the charging case.



Image: The earbuds shown with water droplets, emphasizing their IPX7 waterproof and sweat-resistant features, along with a secure comfort fit design.

Storage

When not in use, store the earbuds in their charging case, and keep the entire kit in the provided protective carrying case. Store in a cool, dry place away from extreme temperatures and direct sunlight.

Troubleshooting

If you encounter any issues with your Groove Electronics Wireless Earbuds, please refer to the following common solutions:

- **Earbuds not pairing:**

Ensure both earbuds are charged. Place them back in the case, close the lid, wait a few seconds, then

open it again to re-enter pairing mode. Delete "GROOVE-X31" from your device's Bluetooth list and try pairing again.

- **No sound from one earbud:**

Check if both earbuds are charged. Try resetting the earbuds (refer to Button Controls section). Ensure they are properly seated in the charging case to make contact with charging pins.

- **Charging case not charging:**

Verify the USB-C cable is securely connected to both the case and the power adapter/source. Try a different USB-C cable or power adapter.

- **Wireless charging pad not working:**

Ensure the charging pad is connected to a power source. Verify your phone supports wireless charging and is correctly aligned on the pad.

- **Poor sound quality:**

Ensure earbuds are clean and ear cushions are properly fitted. Move closer to your connected device to avoid interference.

Specifications

Feature	Detail
Model Number	4-1 Wireless Earbuds Travel Kit- Black
Brand	Groove Electronics
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Earbud Battery Life	14 Hours (single charge)
Total Playtime (with case)	80 Hours
Water Resistance	IPX7
Noise Control	Active Noise Cancellation
Audio Driver Type	Dynamic Driver (10mm)
Control Method	Touch / Button
Included Components	Earbuds, Charging Case, Dual Port 25W Quick Charge Adapter, Wireless Phone Charging Pad, Protective Case, Ear Cushions
Item Weight	11.7 ounces

Feature	Detail
Product Dimensions	5.5 x 4 x 1.75 inches

Official Product Videos

Product Feature Overview

Video: This video provides a comprehensive overview of the Groove Electronics 4-in-1 Wireless Earbuds, highlighting their design, secure fit, sound quality, battery life, Bluetooth connectivity, and the included charging accessories. It demonstrates the product's features and benefits for an active lifestyle.

Product Feature with Audio

Video: This video showcases the key features of the Groove Electronics Wireless Earbuds with accompanying audio narration. It details aspects such as the secure fit, 10mm drivers for clear audio, 55mAh battery for extended playtime, Bluetooth 5.3 for reliable connectivity, and the convenience of the 4-in-1 kit including the fast charger and waterproof case.

Warranty & Support



Groove Electronics stands behind the quality of its products. For warranty information, please refer to the documentation included with your purchase or visit the official Groove Electronics store on Amazon. For further assistance or technical support, please contact Groove Electronics customer service through the Amazon platform or their official website.

Manufacturer: Groove Electronics

For more products and information, visit the [Groove Electronics Store](#).

© 2024 Groove Electronics. All rights reserved.

Related Documents - 4-1 Wireless Earbuds Travel Kit- Black

<p>GROOVE</p>  <p>Kullanım Kılavuzu Araç Takviye Cihazı ve Hava Kompressorü</p>	<p>GROOVE F05 Jump Starter and Air Compressor User Manual</p> <p>User manual for the GROOVE F05 jump starter and air compressor, providing instructions on jump starting vehicles, inflating tires, technical specifications, error codes, and safety warnings.</p>
	<p>IDE11 C12 Wireless Earbuds User Manual</p> <p>User manual for IDE11 C12 wireless earbuds. Learn how to auto-pair, connect via Bluetooth, control music and calls, activate voice assistant, manage power, and troubleshoot. Features include 30-hour playtime, IPX7 water resistance, and CVC 8.0 noise cancellation.</p>
	<p>Losei D73 True Wireless Earbuds User Manual</p> <p>User manual for the Losei D73 True Wireless Earbuds, covering setup, charging, pairing, usage, touch controls, and troubleshooting. Features Bluetooth 5.0, long battery life, and a compact charging case.</p>
	<p>TREBLAB X8 True Wireless Earbuds User Manual</p> <p>Comprehensive user manual for the TREBLAB X8 True Wireless Earbuds, detailing features like Active Noise Cancelling, Bluetooth 5.4, IPX5 waterproofing, 40-hour playtime, and dual ENC mics for optimal audio and comfort during sports and travel.</p>
	<p>i25 True Wireless Stereo Earphones User Manual</p> <p>User manual for the i25 True Wireless Stereo Earphones, detailing features, operation, specifications, and troubleshooting.</p>
	<p>Lahtiwey BX30 Wireless Headphones: IPX7 Waterproof Bluetooth Earbuds with 80-Hour Playtime</p> <p>Explore the Lahtiwey BX30 TWS wireless headphones featuring Bluetooth 5.3, Hi-Res Audio, Bass Boost, IPX7 waterproofing, and an impressive 80-hour playtime with LED display. Ideal for sports and daily use.</p>