

Cutting Edge CXE1-9001-HYP

Cutting Edge Rechargeable Head Shaver

USER MANUAL

Model: CXE1-9001-HYP

1. Introduction

Thank you for choosing the Cutting Edge Rechargeable Head Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your new electric shaver. Please read these instructions thoroughly before first use and retain them for future reference.

This advanced electric rotary shaver is designed for a close and comfortable shave, featuring hypoallergenic titanium blades and five rotating heads that adapt to the contours of your head. It supports both wet and dry shaving and offers cordless operation for convenience.

2. Important Safety Information

To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- **May cause cuts or skin irritation.** Handle with care.
- **Avoid use near water or while charging.** Do not immerse the shaver or charging cable in water or other liquids.
- Always clean and dry the shaver after use to prevent bacterial growth and maintain hygiene.
- Keep the appliance away from children.
- Do not use the shaver if it is damaged or malfunctioning. Contact customer support for assistance.
- Use only the charging cable provided with the shaver.
- Unplug the shaver from the power outlet before cleaning or performing any maintenance.

3. Product Overview

The Cutting Edge Rechargeable Head Shaver is engineered for a superior grooming experience. Key features include:

- **Hypoallergenic Titanium Blades:** Designed to minimize skin irritation and provide a smooth, close shave.
- **Five Rotating Heads:** Adapts to head contours for an even and thorough shave.

- **Wet & Dry Shaving Capability:** Suitable for use with or without shaving cream, in or out of the shower.
- **Cordless Convenience:** Rechargeable battery allows for freedom of movement.
- **Ergonomic Design:** Comfortable handle for precise control and easy maneuverability.



Image: Packaging of the Cutting Edge Rechargeable Head Shaver, showing the shaver and its key features.



Image: Angled view of the Cutting Edge Rechargeable Head Shaver, highlighting the five rotating titanium blade heads.

4. Setup

Before using your new shaver for the first time, please follow these steps:

1. **Unpack:** Carefully remove the shaver and all accessories from the packaging.
2. **Inspect:** Check the shaver for any visible damage. Do not use if damaged.
3. **Initial Charge:** Fully charge the shaver before its first use. Refer to the "Charging the Shaver" section for detailed instructions.

5. Charging the Shaver

The shaver operates on a rechargeable battery, providing cordless convenience. Ensure the shaver is fully charged

for optimal performance.

1. **Connect the Cable:** Insert the small end of the USB charging cable into the charging port on the shaver.
2. **Connect to Power:** Plug the USB end of the cable into a compatible USB power adapter (not included) or a USB port on a computer.
3. **Charging Indicator:** The charging indicator light on the shaver will illuminate to show that it is charging.
4. **Full Charge:** A full charge typically takes approximately 2 hours. The indicator light may change or turn off when charging is complete.
5. **Disconnect:** Once fully charged, disconnect the charging cable from both the shaver and the power source.



Image: The Cutting Edge Rechargeable Head Shaver shown with its USB charging cable.

6. Operating Instructions

Your shaver is designed for both wet and dry use, offering flexibility for your grooming routine.

6.1 Powering On/Off

- To turn the shaver **ON**, press the power button located on the side of the shaver.
- To turn the shaver **OFF**, press the power button again.

6.2 Shaving Technique

For best results, ensure your skin is clean before shaving.

- **Dry Shaving:** For a quick shave, ensure your skin is completely dry. Move the shaver in small, circular motions over your head, applying gentle pressure.
- **Wet Shaving:** For a refreshing shave, you can use the shaver with water, shaving foam, or gel. Apply your preferred shaving product to your head, then move the shaver in small, circular motions. Rinse the shaver

heads frequently during wet shaving to prevent clogging.

- Stretch the skin with your free hand to help the blades capture hairs more effectively, especially in difficult areas.
- Avoid pressing too hard, as this can cause skin irritation and reduce the shaver's efficiency.





Image: Top view of the shaver's five rotary heads, showing the titanium blades.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your shaver.

7.1 Daily Cleaning

1. **Turn Off:** Ensure the shaver is turned off and disconnected from any charging cable.
2. **Open Heads:** Gently twist or press the release button (if applicable) to open the shaver head assembly.
3. **Rinse:** Rinse the shaver heads thoroughly under warm running water to remove hair clippings and residue. For a deeper clean, you can use a mild soap.
4. **Dry:** Shake off excess water and allow the shaver heads to air dry completely before closing the assembly or storing the shaver.

7.2 Deep Cleaning (Weekly/Bi-weekly)

For a more thorough clean, you may carefully remove individual blades for rinsing. Refer to the product packaging or manufacturer's website for specific instructions on blade removal if needed. Always reassemble correctly before next use.

Note: No official seller video for cleaning was available for embedding. Please refer to the text instructions above.

8. Troubleshooting

If you encounter issues with your shaver, consult the following table:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Shaver does not turn on.	Shaver is damaged.	Do not use. Contact customer support.
Poor shaving performance.	Shaver heads are dirty or clogged.	Clean the shaver heads thoroughly as per maintenance instructions.
Poor shaving performance.	Battery is low.	Charge the shaver fully.
Skin irritation after shaving.	Excessive pressure applied.	Use gentle, circular motions. Avoid pressing too hard.
Skin irritation after shaving.	Shaver heads are dirty.	Clean the shaver heads thoroughly.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

Feature	Detail
Model Name	CXE1-9001-HYP
Blade Material	Titanium
Number of Blades	5
Head Type	Rotary
Power Source	Battery Powered (Rechargeable)
Item Weight	0.8 Pounds (approx. 363 grams)
Package Dimensions	8 x 5.5 x 2 inches (approx. 20.3 x 14 x 5.1 cm)
Recommended Use	Scalp
UPC	805106846411

10. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please refer to the contact information provided with your purchase or visit the official Cutting Edge website. Please have your model number (CXE1-9001-HYP) ready when contacting support.