

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster Achieve 300 AirLinks Wireless Earbuds User Manual](#)

## Monster MH12005

# Monster Achieve 300 AirLinks Wireless Earbuds User Manual

Model: MH12005

## INTRODUCTION

Thank you for choosing Monster Achieve 300 AirLinks Wireless Earbuds. These in-ear stereo headphones are designed to provide a high-quality audio experience with advanced features like Bluetooth 5.3 connectivity, smart touch controls, and extended playtime. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

## SAFETY INFORMATION

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the earbuds yourself. Contact qualified service personnel.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified USB-C cable for charging.
- Prolonged exposure to loud sounds may cause hearing damage. Adjust volume to a safe level.

## PACKAGE CONTENTS

Ensure all items are present in your package:

- Monster Achieve 300 AirLinks Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual (this document)
- Quick Start Guide



Image: The Monster Achieve 300 AirLinks earbuds are shown inside their open charging case, with one earbud removed and placed in front. The earbuds are black with gold Monster logos. The charging case is also black with indicator lights on the front.

## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The case provides extended playtime for your earbuds.

- Place the earbuds into the charging case. Ensure they are properly seated.
- Connect the USB-C charging cable to the port on the charging case and plug the other end into a USB power source.
- The indicator lights on the case will show the charging status.
- A 10-minute quick charge can provide up to 2 hours of playtime.

# 32 Hours of Play time

8 Hrs

Single charge

24 Hrs

Long time battery life



## FAST CHARGING:

Type-C 10min charge = 120min playtime

Image: A graphic illustrating the battery life: 8 hours on a single charge for the earbuds, and an additional 24 hours from the charging case, totaling 32 hours. It also highlights fast charging: 10 minutes of charge provides 120 minutes of playtime.



Image: A close-up of the charging case showing the USB-C port with a charging cable inserted, indicating USB-C Quick Charge capability.

## 2. Pairing with Your Device (Bluetooth 5.3)

The earbuds utilize advanced Bluetooth 5.3 technology for a stable and high-quality connection.

1. Ensure the earbuds are in the charging case.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your mobile device, go to Bluetooth settings and turn on Bluetooth.
4. Select "Monster Achieve 300 AirLinks" from the list of available devices to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds are ready for use.




Image: A visual representation of the Bluetooth 5.3 pairing process, showing the earbuds in their case next to a smartphone displaying its Bluetooth settings with "Monster Achieve 300 AirLinks" listed as connected.

## 3. Wearing the Earbuds

For optimal sound quality and comfort, ensure a proper fit.

- Choose the ear tip size (S, M, L) that best fits your ear canal for a secure and comfortable seal.

- Gently insert the earbud into your ear and twist slightly to secure it. The ergonomic design ensures a comfortable and secure fit without protruding.



Image: Two earbuds floating with feathers, emphasizing their lightweight design (each earbud weighs only 4 grams).

## CORRECT WAY TO WEAR BLUETOOTH EARBUDS



## THE WRONG WAY TO WEAR BLUETOOTH EARBUDS



**NOTE: Incorrect wearing method of Bluetooth Earbuds results in no sound during calls.**

Image: A comparison showing the correct and incorrect ways to wear the earbuds. The correct method shows the earbud securely seated in the ear, while the incorrect method shows it protruding. A note indicates that incorrect wearing can result in no sound during calls.

## OPERATING INSTRUCTIONS

---

### Smart Touch Controls

The earbuds feature intuitive touch controls for easy management of music and calls.

# SMART TOUCH CONTROL

Control music and calls with your finger tap



Image: A diagram illustrating the touch control functions: single tap for Play/Pause and Answer/Hang Up, double tap for Previous/Next Track, and hold for Volume +/- and Voice Assistant.


## Touch Control Functions

Action	Function
Single Tap	Play/Pause Music, Answer/End Call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track
Hold (Left Earbud)	Volume Down
Hold (Right Earbud)	Volume Up
Triple Tap	Activate Voice Assistant

## Call Handling

The earbuds feature built-in microphones for clear calls.

- To answer an incoming call: Single tap either earbud.
- To end a call: Single tap either earbud during a call.
- To reject a call: Hold either earbud for 2 seconds.
- The earbuds support clear speakerphone calls with noise reduction technology.



**Built-in microphones  
combined with ENC  
technology, provide crisp voice.**

Image: A person wearing an earbud, with text highlighting "Built-in microphones combined with ENC technology, provide crisp voice."

## MAINTENANCE

- Regularly clean the earbuds and charging case with a soft, dry cloth.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Avoid using abrasive cleaners or solvents.

- The earbuds are IPX6 waterproof, meaning they are resistant to strong jets of water. However, they are not designed for submersion. Dry them thoroughly if exposed to water.



Image: Two earbuds with water splashing around them, indicating IPX6 waterproof rating.

## TROUBLESHOOTING

### Common Issues and Solutions

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Monster Achieve 300 AirLinks" from your device's Bluetooth list and re-pair.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Re-pair the earbuds.
Earbuds falling out	Try different sizes of ear tips for a more secure fit. Ensure earbuds are inserted correctly as shown in the manual.
Charging issues	Ensure the USB-C cable is securely connected to both the case and the power source. Try a different charging cable or power adapter.

## SPECIFICATIONS

Feature	Detail
Model Name	MH12005
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	Dynamic Driver (10mm)
Frequency Range	20 Hz - 20,000 Hz
Impedance	30 Ohm
Control Method	Touch Control
Battery Life (Earbuds)	Up to 8 hours

Feature	Detail
Total Playtime (with Case)	Up to 32 hours
Charging Port	USB-C
Water Resistance	IPX6
Item Weight	4.2 ounces



Image: An exploded view of an earbud showing its internal components, including a 10mm titanium diaphragm dynamic driver, and highlighting Bluetooth 5.3 connectivity for easy and stable connection.

## OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the Monster Wireless Earbuds, Achieve 300 AirLinks Headphones. This video demonstrates

key features such as pairing, touch controls, and usage scenarios, highlighting the product's design and functionality.

## WARRANTY AND SUPPORT

Monster Achieve 300 AirLinks Wireless Earbuds come with a 12-month worry-free service. If you have any questions or encounter any issues, please feel free to contact our customer support team for assistance.

For further support, please refer to the contact information provided in your Quick Start Guide or visit the official Monster website.

© 2025 Monster. All rights reserved.

### Related Documents - MH12005

	<p><a href="#"><u>Monster MH12005 In-ear Earphones Quick Start Guide</u></a></p> <p>Quick start guide for Monster MH12005 In-ear Earphones, covering product overview, charging, pairing, call and music controls, indicator lights, and FCC compliance information. Learn how to set up and use your Monster Achieve 300 AirLinks wireless earbuds.</p>
	<p><a href="#"><u>Monster N-LITE 203 AIRLINKS True Wireless Earbuds - Quick Start Guide</u></a></p> <p>Explore the features and controls of the Monster N-LITE 203 AIRLINKS true wireless Bluetooth earbuds. This guide covers inventory, product specifications, and intuitive touch controls for music, calls, and voice assistants.</p>
	<p><a href="#"><u>Monster N-Lite 203 Airlinks Bluetooth Headphones Quick Start Guide</u></a></p> <p>Concise guide to setting up and using Monster N-Lite 203 Airlinks Bluetooth headphones, covering pairing, controls, and features.</p>
	<p><a href="#"><u>Monster Open Ear AC225 Bluetooth Headphones Quick Start Guide</u></a></p> <p>A concise guide to setting up and using your Monster Open Ear AC225 Bluetooth Headphones, covering charging, pairing, wearing, and basic operations.</p>
	<p><a href="#"><u>Monster N-Lite 203 Airlinks Quick Start Guide</u></a></p> <p>A concise guide to setting up and using the Monster N-Lite 203 Airlinks wireless earbuds, covering pairing, controls, and basic functions.</p>
	<p><a href="#"><u>Monster Aria Free Quick Start Guide - Wireless Open Ear Headphones</u></a></p> <p>Get started quickly with the Monster Aria Free open-ear wireless headphones. This guide covers charging, pairing, controls, and wearing instructions for model MH22134.</p>