

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE ADSG619 150cm Natural TV Stand Instruction Manual

WLIVE ADSG619

WLIVE ADSG619 150cm Natural TV Stand Instruction Manual

Model: ADSG619 | Brand: WLIVE

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE ADSG619 150cm Natural TV Stand. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation. Keep this manual for future reference.



Image 1.1: The WLIVE ADSG619 TV Stand in a modern living room environment.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- This TV stand is designed to support televisions ranging from 24 to 60 inches.
- For larger televisions, ensure the center of gravity is kept low to maintain stability.
- The top panel has a maximum load capacity of 40 kg.
- Each internal storage compartment (behind the doors) has a maximum load capacity of 30 kg.
- Do not exceed the specified load capacities. Overloading can cause the stand to collapse, leading to serious injury or property damage.
- Exercise extreme caution when children or pets are near the TV stand. Ensure all cables are properly managed and secured to prevent tripping hazards or accidental pulling of the TV.
- Always place the TV stand on a flat, stable, and level surface.
- Do not allow children to climb on or play with the TV stand.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present and undamaged. If any parts are missing or damaged, please contact WLIVE customer support.

The package typically includes:

- Main wooden panels (top, bottom, side panels, shelves, doors)
- Six support legs
- Assembly hardware (screws, dowels, hinges, adjustable shelf pins, etc.)
- Instruction manual (this document)



Image 3.1: Overview of product dimensions and packaging.

4. ASSEMBLY INSTRUCTIONS

Assembly requires careful attention to detail. It is recommended to have two people for assembly. Clear a spacious area and lay out all components before starting.

4.1. Tools Required

- Phillips head screwdriver
- Hammer (optional, for dowels)

4.2. Step-by-Step Assembly

1. **Prepare the Base:** Identify the bottom panel and attach the six support legs using the provided screws. Ensure they are securely fastened.



六本の足でテレビ台をしっかり支える

Image 4.1: The TV stand is supported by six sturdy legs.

2. **Attach Side Panels:** Connect the side panels to the bottom panel using the appropriate hardware (dowels and cam locks/screws).
3. **Install Central Shelf:** Insert the adjustable shelf pins into the desired height positions within the central open compartment. Place the central shelf onto these pins. The shelf is adjustable to three different heights.

可動棚高さ三段調節



高さ足りない心配なく、
機器の大きさに合わせて
収納することができます！

背板の無いオープンタイプ

電子機器の熱かがこもりにくく、
背面から自由にコードを通せるので
配線作業も楽に行えます。



Image 4.2: The central shelf offers three adjustable height options.

4. **Attach Top Panel:** Secure the top panel to the assembled structure.
5. **Install Doors:** Attach the hinges to the side storage doors and then to the main frame. Adjust hinges as needed for proper door alignment.



ウッド扉収納

開きタイプだから開口部が大きく、「無駄なく」収納ができ、より幅広の物などを収納しやすくなります。



😊 高さ足りる！収納量も多い！



😞 引き出しが意外に高さが足りない

Image 4.3: The door storage compartments provide ample space for various items.

6. **Cable Management Setup:** Utilize the two cable holes located on the back panel to route power and AV cables neatly.



背面は二つのコード穴があり、
テレビや機器の配線をコード穴に通せます。

Image 4.4: Integrated cable management holes for a tidy setup.

7. **Final Check:** Ensure all screws are tightened and the stand is stable before placing any items on it.

5. USAGE

5.1. Placing Your Television

Carefully place your television on the center of the top panel. Ensure the TV's base is fully supported and does not overhang the edges. The stand is designed for TVs up to 60 inches.

5.2. Storage Compartments

- **Central Open Shelf:** Ideal for AV equipment such as soundbars, DVD players, or game consoles. The open-back design promotes ventilation, preventing overheating. The dimensions of this space are 59cm (width) x 22cm (depth).
- **Side Door Storage:** Use these enclosed compartments to store items like CDs (approx. 150), DVDs (approx. 67), game accessories, or other media. The internal dimensions are 43.7cm (width) x 22cm (depth). The doors help keep your living space tidy and protect contents from dust.

5.3. Cable Management

Route all cables from your television and AV devices through the designated cable holes at the back of the stand. This helps to keep cables organized, reduces clutter, and minimizes potential tripping hazards.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the melamine finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

7. TROUBLESHOOTING

7.1. Stand is Wobbly

- Ensure all assembly screws are fully tightened.
- Verify that the stand is placed on a completely flat and level surface. Adjust the position if needed.
- Check if the legs are securely attached and evenly supporting the stand.

7.2. Doors Do Not Close Properly

- Check the hinge alignment. Loosen hinge screws slightly, adjust the door position, and then re-tighten.
- Ensure no items inside the compartment are obstructing the door's closure.

7.3. Scratches or Minor Damage

- For minor scratches, a furniture repair pen or wood filler matching the natural finish may be used.
- For significant damage, contact WLIVE customer support for advice.

8. SPECIFICATIONS

Feature	Detail
Model Number	ADSG619
Brand	WLIVE
Color	Natural
Style	Modern
Overall Dimensions (W x D x H)	150 cm x 39 cm x 35.7 cm
Top Panel Load Capacity	40 kg

Feature	Detail
Door Storage Load Capacity (each)	30 kg
Total Load Capacity	100 kg
Material	E1 Grade Melamine Particle Board (1.5cm thick)
TV Size Compatibility	24 to 60 inches
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact WLIVE customer service directly. Refer to the contact details provided with your purchase or visit the official WLIVE website. WLIVE is committed to providing quality products and customer satisfaction.

