

[Manuals.plus](#) /

> [Coolaado](#) /

> Bluetooth Mobile Game Controller for iOS & Android, Wireless Retractable Gaming Gamepad Handheld Joystick - Turn Your Phone into a Gaming Console! Support Xbox/PS/Switch/PC/Steam (Black)

Coolaado 47e83847-ace9-4472-945a-0cb977ed80d6

Coolaado Bluetooth Mobile Game Controller User Manual

Model: 47e83847-ace9-4472-945a-0cb977ed80d6

Brand: Coolaado

INTRODUCTION

The Coolaado D6DP mobile gaming controller transforms your smartphone into a portable gaming console, offering a console-quality experience on the go. Designed with analog sticks and buttons, it provides enhanced precision and tactile feedback compared to touch controls. Its ergonomic and portable design ensures comfort during extended gaming sessions, balancing minimal backpack space with comfortable use. This controller is an expandable, flexible dock that securely holds your device, freeing up the screen for an immersive gaming experience.

SETUP

Initial Charging

Before first use, fully charge your Coolaado Mobile Game Controller. The built-in 350mAh rechargeable battery provides over 12 hours of game playing and can be fully charged within 2-3 hours using the included USB-C charging cable. Connect the USB-C cable to the controller's charging port and the other end to a compatible USB power source.




12H
Playing Time


350mAh
Battery


2-3H
Charging Time

Designed for long gaming sessions
No delay, no dead & no drift, provide tactile feedback and precision.

Image: The controller's USB-C charging port and indicators for 12 hours playing time, 350mAh battery, and 2-3 hours charging time.

Connecting to Android Devices

To connect your controller to an Android device (System 6.0+):

1. Long press the "H" button on the controller for 3 seconds until the indicator light flashes orange. This puts the controller into Android pairing mode.
2. On your Android phone, go to Settings > Bluetooth.
3. Turn on Bluetooth and search for available devices.
4. Select "D6DP" from the list to connect. Once connected, the indicator light will stop flashing and remain solid.

Video: Demonstrates the process of connecting the Coolaado controller to an Android phone via Bluetooth.

Connecting to iOS Devices

To connect your controller to an iOS device (System iOS 13.0+):

1. Long press the "M" button on the controller for 3 seconds until the indicator light flashes purple. This puts the

controller into iOS pairing mode.

2. On your iPhone or iPad, go to Settings > Bluetooth.
3. Turn on Bluetooth and search for available devices.
4. Select "DUALSHOCK 4 Wireless Controller" from the list to connect. Once connected, the indicator light will stop flashing and remain solid.

Video: Demonstrates the process of connecting the Coolaado controller to an iPhone or iPad via Bluetooth.

Device Compatibility

The controller is designed to fit almost all popular smartphones and tablets with screen lengths up to 7.2 inches (181 mm). It supports devices running iOS 13.0+, Android 6.0+, and Windows 10+ systems.

UNIVERSAL COMPATIBILITY

Bluetooth-compatible, super quick and easy to pair.

Game Preview

FABLE FORTUNE

Fortnite, Assassin's Creed Mirage, Ghostwire, TBS, Diablo, Palworld, Forza Horizon 4


Bluetooth Symbol

Apple, Android, PC

"M" Button, "H" Button, "X" Button

Image: Visual representation of the controller's universal compatibility with various operating systems and devices.

ERGONOMIC STRUCTURE



Unstretched Length: 127mm/5in



Comfortable Grip



Anti-slip Dock



Sturdy Holders



Up to 181mm/7in length

Image: Diagram illustrating the ergonomic design and retractable nature of the controller, showing unstretched length of 127mm (5in) and up to 181mm (7in) length when stretched.

OPERATING INSTRUCTIONS

Game Compatibility

The controller supports a wide range of popular games and platforms. It features Bluetooth 5.0 for wireless connection, eliminating the need to re-download games or install additional apps. It is compatible with cloud gaming services such as Xbox Cloud, GeForce Now, and Luna, as well as remote play applications like PS Remote Play, Xbox app, and Steam Link. This allows you to enjoy console/PC games on your mobile device. It is especially designed for mobile games like "Peace Elite / Exciting Battlefield," "King Glory," "Wilderness Action," and "Mobile Legends."



Image: The controller holding a smartphone, showcasing compatibility with various gaming platforms and popular mobile games.

PLAY CONSOLE GAMES ON YOUR PHONE

Provide a console-like experience on the go!



IOS



Android



PC



GAMEPASS

Xbox/360/One/Series X/S



PS Remote Play

PS3/PS4/PS5



SWITCH

Switch/Lite/OLED



Arcade



Steam Link



Google play



Luna



Rainway

Image: The controller with a phone, highlighting its ability to play console games on mobile devices and compatibility with major gaming ecosystems.

Adjustable Turbo & Vibration Functions

The controller features highly accurate thumbsticks, a responsive D-pad, and precise buttons for accurate execution of every move. It includes an adjustable TURBO function with speeds of 8, 15, or 25 shots per second, which can free your fingers and enhance performance in action games. The dual motor vibration function provides a realistic and stimulated gaming experience, increasing immersion. Additionally, pressing TURBO + L3 can toggle the lights of the ABXY keys, allowing you to customize your gaming ambiance.



Image: Visual explanation of the adjustable turbo speeds (8, 15, 25 shots/s) and the dual motor vibration feature for enhanced gaming immersion.

MAINTENANCE

Battery Care

To prolong battery life, avoid fully discharging the controller frequently. Charge the controller when the battery indicator is low. If storing the controller for an extended period, ensure it has a partial charge (around 50%) and recharge it every few months to prevent deep discharge.

Cleaning

Clean the controller regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials that could damage the surface or internal components. Ensure no liquid enters the ports or buttons.

Resetting the Controller

If the wireless controller experiences abnormal situations such as inability to connect/charge, or joystick offset, you can try resetting it. Locate the 'RESET' hole on the left side of the USB-C charging port. Use a thin needle or paperclip to gently poke the 'RESET' hole. After resetting, restart the controller and delete any memorized Bluetooth names from your phone's Bluetooth settings before attempting to reconnect. This process can resolve most non-quality related issues.



Image: Detailed view of the controller's components, including the 'RESET' hole next to the Type-C charging port.

SPECIFICATIONS

Feature	Detail
ASIN	B0DFGTDFFZ

Feature	Detail
Item Model Number	47e83847-ace9-4472-945a-0cb977ed80d6
Manufacturer	Coolaado
Item Weight	8.4 ounces
Package Dimensions	8.58 x 3.9 x 1.93 inches
Batteries	1 Lithium Ion batteries required (included)
Date First Available	August 28, 2024

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Coolaado customer service directly. Keep your purchase receipt for any warranty claims.

