

**Electactic Z5812B-BLACK**

# **Electactic Countertop Ice Maker**

**MODEL: Z5812B-BLACK**

## **Instruction Manual**

### **Introduction**

Thank you for choosing the Electactic Countertop Ice Maker. This appliance is designed to provide you with fresh, bullet-shaped ice quickly and efficiently. With its compact design, intuitive control panel, and self-cleaning function, it is perfect for home kitchens, parties, and gatherings. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your ice maker.



Image: The Electactic Countertop Ice Maker, showcasing its sleek black design, clear lid filled with bullet ice, and an accompanying glass of iced beverage.

## Important Safety Instructions

Please read all instructions carefully before using this appliance to prevent injury or damage. Keep this manual for future reference.

- Ensure the power outlet voltage matches the appliance's requirements.
- Do not immerse the power cord, plug, or appliance in water or other liquids.
- Unplug the ice maker from the outlet when not in use, before cleaning, or during maintenance.
- Do not operate the appliance with a damaged cord or plug. Contact customer service for repair.
- Keep the appliance away from heat sources, direct sunlight, and flammable materials.
- Ensure proper ventilation around the unit. Maintain at least 6 inches of clearance from walls or other objects.
- This appliance is for household use only. Do not use outdoors.
- Do not use mechanical devices to defrost the ice maker. Do not puncture refrigerant tubing.

## What's in the Box

Your Electactic Ice Maker package includes the following components:

- Electactic Countertop Ice Maker Unit
- Ice Basket
- Ice Scoop
- Instruction Manual

## Product Specifications

Feature	Detail
Brand	Electactic
Model Name	ice maker
Item Model Number	Z5812B-BLACK
Product Dimensions	11.61"D x 9.45"W x 11.69"H
Weight	14.7 Pounds
Capacity	26 Pounds (ice production per 24H)
Ice Production Rate	9 cubes in 6 minutes
Ice Cube Type	Bullet Ice (2 sizes)
Wattage	300 watts
Country of Origin	China

Image: The compact design of the ice maker with its dimensions clearly labeled, showing its suitability for countertop placement.

# Self-Cleaning Function

Simply press the "Clean" button and the machine will start the self-cleaning process, effortlessly maintaining hygiene



## Setup and First Use

- 1. Unpack:** Carefully remove the ice maker and all accessories from the packaging.
- 2. Clean:** Before first use, clean the interior of the ice maker with a soft cloth and mild detergent. Rinse thoroughly with clean water.
- 3. Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure adequate ventilation.
- 4. Add Water:** Open the top cover and remove the ice basket. Pour potable water into the water reservoir up to the 'MAX' fill line. Do not overfill.
- 5. Power On:** Plug the power cord into a grounded electrical outlet. The 'POWER' indicator light will illuminate.
- 6. Initial Cleaning Cycle:** For the first use, it is recommended to run a self-cleaning cycle. Press and hold the 'CLEAN' button for 3-5 seconds. The machine will run a cleaning cycle for approximately 15 minutes. After the cycle, drain the water from the drain plug at the bottom of the unit.

## Visual Guide: Setup and Operation

Video: This official product video demonstrates the process of adding water, powering on the unit, selecting ice size, and the self-cleaning function. It provides a comprehensive visual guide to setting up and operating your Electactic

ice maker.

## Operating Instructions

- Start Ice Production:** After adding water and plugging in the unit, press the 'ON/OFF' button to start ice production. The 'POWER' indicator will light up.
- Select Ice Size:** Press the 'SELECT' button to choose between small (S) or large (L) bullet ice cubes. The corresponding indicator light will illuminate.
- Ice Making Cycle:** The ice maker will begin its cycle. It produces 9 ice cubes in approximately 6 minutes.
- Ice Full Indicator:** When the ice basket is full, the 'ICE FULL' indicator light will turn on, and the ice maker will automatically stop production. Remove ice from the basket to resume production.
- Add Water Indicator:** If the water level is too low, the 'ADD WATER' indicator light will turn on, and the ice maker will stop. Add more water to the reservoir to resume operation.

## Key Features in Operation:

Image: A close-up of the ice maker's control panel, highlighting the 'ADD WATER', 'ICE FULL', 'POWER ON/OFF', and 'SELECT' buttons for intuitive operation.




Image: Visual representation of the ice maker's rapid production, showing ice cubes forming and highlighting its ability

to produce 9 cubes in 6-12 minutes and up to 26 lbs per 24 hours.

# Fast Ice Making



**Ice ready in  
6-12 Mins**

**9 Cubes/ 6 Mins**

**26 Lbs/ 24 H**

Image: Comparison of small and large bullet ice cubes produced by the machine, suitable for various beverages and uses like frozen sashimi or cocktail drinks.

# Two Ice Cube Sizes

Choose between small or large ice cubes to suit any drink or occasion.



**Small**



For Frozen Sashimi

**Large**



For Cocktail Drinks

Image: An illustration demonstrating the low noise level of the ice maker, comparing it to common sounds like rain or a whisper, indicating quiet operation.

# Low Noise

With its intuitive control panel, making ice has never been



## Maintenance and Cleaning


Regular cleaning and maintenance will extend the life of your ice maker and ensure fresh-tasting ice.

### Self-Cleaning Function:

The Electactic Ice Maker features a convenient self-cleaning cycle:

1. Ensure the unit is plugged in and has water in the reservoir.
2. Press and hold the 'CLEAN' button for 3-5 seconds. The cleaning cycle will begin, circulating water through the system for approximately 15 minutes.
3. Once the cycle is complete, unplug the unit.
4. Locate the drain plug at the bottom of the unit and remove it to drain the water.
5. Replace the drain plug securely.

Image: A visual sequence demonstrating the self-cleaning process: activating the 'Clean' button, the internal water circulation during the cycle, and finally, draining the water from the bottom plug.



Activate "Clean" Button



Perform Self-cleaning Cycle Mode



Remove Cleaned Sewage

### General Cleaning:

- Clean the interior and exterior surfaces with a soft cloth and mild soap. Do not use abrasive cleaners.
- Regularly clean the ice basket and ice scoop with warm, soapy water.
- For thorough cleaning, it is recommended to clean the water reservoir every few weeks, especially if the ice maker is used frequently.
- Ensure all parts are completely dry before reassembling and storing the unit.

### Troubleshooting Guide

If you encounter issues with your ice maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
'ADD WATER' light is on	Water reservoir is empty or water level is too low.	Add potable water to the reservoir up to the 'MAX' line.
'ICE FULL' light is on	Ice basket is full.	Remove ice from the basket. The unit will resume ice production automatically.
Ice maker is not producing ice	No water, clogged water line, or unit is not powered on.	Check water level, ensure unit is plugged in and powered on. Run a cleaning cycle to clear any blockages.

Ice cubes are too small or misshapen	Water temperature is too high, or ambient temperature is too warm.	Use colder water. Ensure the unit is in a cool, well-ventilated area. Select the 'L' (Large) ice size setting.
Unit is making unusual noises	Normal operation sounds (compressor, water pump) or unit needs cleaning.	Some sounds are normal. If sounds are excessive or unusual, run a self-cleaning cycle. If the issue persists, contact support.

## **Warranty and Customer Support**

For warranty information or technical assistance, please refer to the warranty card included with your product or contact Electactic customer support directly. Our team is available to help with any questions or concerns you may have regarding your ice maker.

Please have your model number (Z5812B-BLACK) and purchase date ready when contacting support.