

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Eueiriup](#) /
- › [Eueiriup LED-800W Plug-in Electric Wall Heater Instruction Manual](#)

Eueiriup LED-800W

Eueiriup LED-800W Plug-in Electric Wall Heater

Instruction Manual

1. INTRODUCTION

Thank you for purchasing the Eueiriup LED-800W Plug-in Electric Wall Heater. This manual provides essential information for the safe and efficient operation of your new heater. Please read it thoroughly before use and retain it for future reference.



Image 1: Front view of the Eueiriup LED-800W Electric Wall Heater.

2. SAFETY INSTRUCTIONS

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or property damage.

- Read all instructions before using this heater.
- Do not use this heater outdoors or in wet locations. It is designed for indoor use only.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in

any manner.

- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front of the heater and away from the sides and rear.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an anti-tip safety feature. If the heater is tipped over by more than 45 degrees, it will automatically shut off.
- This heater is equipped with overheat protection. If the heater reaches an unsafe temperature, it will automatically shut off.
- The heater is IPX4 waterproof rated, making it suitable for bathroom use, but avoid direct water spray.
- The V0 flame retardant material ensures enhanced safety.

3. PACKAGE CONTENTS

Please check the package contents upon receipt:

- Eueiriup LED-800W Electric Wall Heater Unit
- Wheel Assembly (for freestanding use)
- Wall Mounting Accessories (screws, anchors)
- Instruction Manual

4. SETUP

4.1 Freestanding with Wheels Installation

1. Carefully unpack the heater and all accessories.
2. Attach the wheel assemblies to the bottom of the heater using the provided screws. Ensure they are securely fastened.
3. Place the heater on a stable, level surface, away from any obstructions.

4.2 Wall Mount Installation

1. Select a suitable wall location, ensuring it is away from combustible materials and has a power outlet nearby.
2. Using the provided wall mounting accessories, mark and drill holes according to the heater's mounting points.
3. Securely attach the heater to the wall. Ensure it is level and firmly fixed.



Image 2: Heater shown in both freestanding and wall-mounted configurations, with dimensions.

4.3 Initial Power-up

After installation, plug the heater directly into a standard 120V AC wall outlet. The LED display will illuminate, indicating it is ready for operation.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The heater features an intuitive LED display and touch controls for easy operation.

45-86°F TEMPERATURE REGULATION



Image 3: Detailed view of the LED control panel and its functions.

- **Decrease Button (<):** Adjusts temperature or timer settings downwards.
- **Confirm Button (OK):** Confirms selections.
- **Increase Button (>):** Adjusts temperature or timer settings upwards.
- **Heat Indicator (SSS):** Illuminates when the heating element is active.
- **Mute Switch:** Toggles sound notifications.
- **Timer Setting:** Accesses and sets the 24-hour timer.
- **Turn On/Off:** Powers the unit on or off.
- **Menu Button:** Navigates through different modes and settings.
- **Child Lock:** Activates/deactivates the child lock feature.
- **Temperature Conversion:** Switches between Celsius and Fahrenheit.

5.2 Temperature Regulation

The heater offers three operating modes:

- **Comfort Mode:** Provides consistent heating to maintain your desired temperature (45-86°F).
- **Economic Mode:** An energy-saving mode. The set temperature cannot be higher than the Comfort Mode setting.
- **Low Mode (Thaw):** Maintains a low temperature to prevent freezing.

Use the **Menu Button** to select your desired mode, then use the **Increase (>)** and **Decrease (<)** buttons to adjust the temperature within the 45-86°F range. Press **OK** to confirm.

5.3 Timer Setting

To set the 24-hour timer, press the **Timer Setting** button. Use the **Increase (>)** and **Decrease (<)** buttons to set the desired operating duration. The LED display will show the countdown. Press **OK** to confirm.

5.4 Child Lock

Activate the **Child Lock** feature to prevent accidental changes to settings. Press and hold the Child Lock button until the indicator appears on the display. Repeat to deactivate.

5.5 Mute Function

Press the **Mute Switch** to silence operational beeps and notifications.

6. FEATURES

6.1 Energy Efficient Convection Heating

This electric heater utilizes convection technology to efficiently warm your space. It heats the bottom of the panel, transferring heat to the entire aluminum frame, which then circulates warm air throughout the room. This design can contribute to energy savings.

EFFICIENT & QUIET HEATING



Low Noise



Energy Efficient



Fast Heating



Image 4: Illustration of efficient and quiet convection heating.

WHOLE ROOM CONVECTION WARMING



Image 5: Transparent view demonstrating whole room convection warming.

6.2 Quiet Operation

The fan-less, oil-less, and gas-less design ensures quiet heating without disturbing noise. This also helps prevent drying out the air, creating a more comfortable environment.

6.3 Safety Protections

The heater is equipped with multiple safety features:

- **Anti-Tip Protection:** Automatically shuts off if the heater is accidentally knocked over.
- **Overheat Protection:** Automatically shuts off if internal components reach an unsafe temperature.
- **IPX4 Waterproof Rating:** Provides protection against splashing water, making it suitable for use in bathrooms.
- **V0 Flame Retardant Material:** Constructed with materials that resist ignition and spread of fire.
- **Child Lock:** Prevents unintended operation by children.

ENJOY HEATER WITHOUR SAFE CONCERN



Image 6: Visual representation of the heater's safety features.

6.4 Portable and Convenient Design

The heater can be easily moved thanks to its universal wheels and hidden handles, offering flexibility in placement.



Image 7: Details of the heater's portable design elements.

7. MAINTENANCE

7.1 Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the interior of the heater.

7.2 Storage

When not in use, store the heater in a cool, dry place. If possible, use the original packaging to protect it from dust and damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Overheat protection activated. Tip-over switch activated.	Check if the power cord is securely plugged in. Ensure the wall outlet is functional. Unplug, wait 10 minutes, then plug back in. Ensure the heater is upright on a flat surface.
Heater produces minimal heat.	Incorrect mode selected. Room size too large for heater capacity. Temperature setting too low.	Select Comfort Mode. Ensure the heater is appropriate for the room size (up to 150 sq ft). Increase the temperature setting.
Heater suddenly turns off.	Overheat protection activated. Tip-over switch activated. Timer has expired.	Unplug, wait 10 minutes, then plug back in. Ensure proper ventilation. Ensure the heater is upright on a flat surface. Check and reset the timer if necessary.
Control panel is unresponsive.	Child Lock is active.	Deactivate the Child Lock feature.

9. SPECIFICATIONS

Feature	Specification
Model Number	HKWH003-800W (LED-800W)
Brand	Eueiriup
Power Output	800W
Voltage	120V AC
Heating Coverage	Up to 150 Sq Ft
Dimensions (D x W x H)	3.54" x 25.28" x 22.24"
Item Weight	22.9 pounds
Special Features	LED Display, Touch Control, Portable (Wheels), Wall Mountable, Anti-Tip, Overheat Protection, IPX4 Waterproof, V0 Flame Retardant
Indoor/Outdoor Usage	Indoor

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Eueiriup website. Keep your purchase receipt as proof of purchase.



