



Manuals.plus /

› TUOHAITIME /

› TUOHAITIME Android 14 Tablet User Manual - Model RM

## TUOHAITIME RM

# TUOHAITIME Android 14 Tablet User Manual

Model: RM

## 1. INTRODUCTION

---

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your TUOHAITIME Android 14 Tablet. Please read this manual thoroughly to ensure proper use and to maximize your device's performance and longevity.

## 2. PACKAGE CONTENTS

---

Upon opening your TUOHAITIME Android 14 Tablet package, please verify that all the following items are included:

- TUOHAITIME Android 14 Tablet
- Shock-proof Case
- User Manual (this document)
- USB Cable



Image: The TUOHAITIME Android 14 Tablet displayed with its protective case and charging cable.

### 3. SETUP GUIDE

#### 3.1. Initial Charging

Before first use, it is recommended to fully charge your tablet. Connect the provided USB cable to the tablet's charging port and plug the other end into a compatible USB power adapter (not always included) or a computer's USB port. The charging indicator will typically show progress on the screen.

#### 3.2. Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the screen illuminates and the TUOHAITIME logo appears.
- **To Power Off:** Press and hold the Power button until a power menu appears on the screen. Select "Power off" and confirm.
- **To Restart:** From the power menu, select "Restart" and confirm.

#### 3.3. Initial Configuration

The first time you power on your tablet, you will be guided through a setup wizard. Follow the on-screen prompts to:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one.
4. Set up screen lock (PIN, pattern, password, or face unlock).
5. Review and accept terms and conditions.

## 4. OPERATING INSTRUCTIONS

---

### 4.1. Basic Navigation

The Android 14 operating system uses intuitive touch gestures:

- **Tap:** To select an item or open an application.
- **Swipe:** To scroll through pages or lists.
- **Pinch:** To zoom in or out on images and web pages.
- **Long Press:** To access contextual menus or move icons.

### 4.2. Wi-Fi Connection

To connect to a Wi-Fi network:

1. Go to **Settings > Network & internet > Internet**.
2. Ensure Wi-Fi is turned on.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted and tap **Connect**.

The tablet supports Wi-Fi 6 (802.11ax) for faster and more reliable wireless connectivity.

### 4.3. Google Kids Space and Parental Controls

The tablet comes pre-installed with Google Kids Space, offering a curated selection of apps, books, and videos for children aged 3 and above. To set up Google Kids Space:

1. Open the Google Kids Space app.
2. Follow the on-screen instructions to create a child profile and link it to your Google account.
3. Utilize the parental controls to manage content, set screen time limits, and monitor activity.

# Android 14

## 2024 Newest and Stablest Android Tablet System

- Parallel View
- Optimized landscape experience
- Taskbar
- Convenient multitasking
- Privacy&Security
- Manage permissions
- Parental Control



Image: A visual representation of the Android 14 interface highlighting features like Parallel View, Taskbar, Privacy & Security, and Parental Control, which are integral to Google Kids Space.

### 4.4. Widevine L1 Support

Your tablet supports Widevine L1, enabling high-quality streaming from services like Amazon Prime Video, Disney+, and Hulu. This ensures you can enjoy content in HD resolution. Note that some services, such as Netflix, may have their own device restrictions that could affect image quality, potentially defaulting to Widevine L3.

### 4.5. Using the Cameras

The tablet features dual cameras for capturing photos and videos.

- **Front Camera:** Ideal for video calls and selfies.
- **Rear Camera:** Suitable for general photography.

To access the camera, tap the Camera app icon on your home screen or app drawer. You can switch between front and rear cameras within the app interface.

## Front& Rear cameras Capture your every beautiful moments



Image: The tablet screen showing a video conference with multiple participants, demonstrating the use of the front camera for communication.



## Dual front & rear cameras, capture every beautiful moment




Image: A person using the tablet to capture a moment, with callouts indicating a 5MP front camera and an 8MP rear camera.

## 5. MAINTENANCE

### 5.1. Battery Care

To prolong your tablet's battery life:

- Avoid extreme temperatures.
- Do not let the battery completely drain frequently.
- Unplug the charger once the battery is full.
- Adjust screen brightness to a comfortable level.
- Close unused applications running in the background.

# 6000mAh Large & Powerful

All while enjoying all-day battery life.



Standby  
72H



Website Browse  
14H



Music  
10H



Video  
8H

# 6000mAh



Image: A graphic illustrating the 6000mAh battery capacity and estimated usage times: 72 hours standby, 14 hours website browsing, 10 hours music, and 8 hours video playback.

## 5.2. Storage Management

Your tablet comes with 64GB of internal storage and supports expansion up to 512GB via an SD card. To manage storage:

- Regularly delete unnecessary files and apps.
- Move large files (photos, videos) to an inserted SD card.
- Utilize cloud storage services for backups.

# Storage & Expansion 1TB

The tablet has 10GB(4GB+6GB) RAM + 64GB ROM storage space and you can also add an SD card to expand the memory to 1TB  
The large storage space allows you to never worry about insufficient memory



Image: A visual representation of the tablet's storage capabilities, indicating 10GB (4GB+6GB) RAM and 64GB ROM, with the option to expand memory up to 1TB via an SD card.

## 5.3. Software Updates

Ensure your tablet's software is up to date for optimal performance and security. To check for updates:

1. Go to **Settings > System > System update**.
2. Follow the on-screen instructions to download and install any available updates.

## 6. TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

Problem	Solution
Tablet does not power on	Ensure the battery is charged. Connect the charger and try again. If unresponsive, perform a forced restart by holding the power button for 10-15 seconds.
Wi-Fi connectivity issues	Restart the tablet and your Wi-Fi router. Forget the network in Wi-Fi settings and reconnect. Ensure you are within range of the Wi-Fi signal.
Slow performance or app crashes	Close unused apps. Clear app caches (Settings > Apps > [App Name] > Storage > Clear cache). Free up storage space. Restart the tablet.
Screen is unresponsive	Perform a forced restart. If the issue persists, contact customer support.

If these steps do not resolve your issue, consider performing a factory reset **Settings > System > Reset options > Erase all data (factory reset)**. **Warning: This will erase all data on your tablet. Back up important information before proceeding.**

## 7. SPECIFICATIONS

---

Below are the technical specifications for the TUOHAITIME Android 14 Tablet (Model RM):

Feature	Detail
Model	RM
Operating System	Android 14
Processor	2.0GHz Octa-Core Processor (Allwinner)
RAM	10GB (4GB + 6GB Expansion)
Internal Storage	64GB
Expandable Storage	Up to 512GB via SD card
Display Size	10.1 Inches
Display Resolution	1280 x 800 Pixels (HD IPS)
Graphics Coprocessor	Adreno 305 (Chipset Brand: AMD)
Rear Camera	8 MP
Front Camera	5 MP
Battery Capacity	6000mAh
Average Battery Life	Up to 12 Hours
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth 5.0
Dimensions (LxWxH)	10 x 4 x 0.35 inches
Item Weight	2.33 pounds



Image: An infographic showcasing key features including 10.1-inch display, Octa-Core processor, dual cameras, 10GB RAM, 64GB ROM, Bluetooth 5.0, 6000mAh battery, and Android 14.

## 8. WARRANTY AND SUPPORT

Your TUOHAITIME Android 14 Tablet is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact TUOHAITIME customer support through the official website or the contact information provided with your purchase documentation.