



[Manuals.plus](#) /

› [Kipcush](#) /

› Kipcush D2 Portable White Noise Sound Machine Instruction Manual

## Kipcush D2

# Kipcush D2 Portable White Noise Sound Machine Instruction Manual

Model: D2

## 1. INTRODUCTION

---

Thank you for choosing the Kipcush D2 Portable White Noise Sound Machine. This device is designed to enhance your sleep and relaxation experience with a variety of soothing sounds, breathing exercises, and smart alarm clock features. Please read this manual thoroughly to understand how to operate your device safely and effectively.



*Image: Kipcush D2 Portable White Noise Sound Machine, gray model.*

## 2. IMPORTANT SAFETY INFORMATION

---

- Do not expose the device to water or excessive moisture.
- Keep the device away from heat sources and direct sunlight.
- Use only the provided USB-C charging cable. A power adapter is not included to reduce environmental waste.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of children and pets.

## 3. PACKAGE CONTENTS

---

- Kipcush D2 Portable White Noise Sound Machine
- USB-C Charging Cable
- User Manual

## 4. SETUP

---

## 4.1. Charging the Device

Before first use, fully charge the device using the provided USB-C cable. Connect the USB-C cable to the charging port on the device and the other end to a compatible USB power adapter (not included) or a computer USB port. The battery indicator on the screen will show charging status.



Image: Kipcush D2 on a nightstand, illustrating its rechargeable battery feature.

## 4.2. Initial Power On

Press and hold the power button located on the side of the device until the screen illuminates. The device will boot up and display the main interface.

## 4.3. Setting Date and Time

Upon first power-on or after a factory reset, you may need to set the date and time. Navigate to the 'Settings' menu on the touch screen and select 'Date & Time'. You can choose to set it manually or connect to Wi-Fi for automatic synchronization.

## 4.4. Customizing Clock Display

The Kipcush D2 offers various clock display styles. From the main clock screen, swipe left or right on the touch screen to browse and select your preferred clock face.




Image: Kipcush D2 showing different customizable clock dials.

# 5. OPERATING INSTRUCTIONS

---

## 5.1. Navigating the Touch Screen

The Kipcush D2 features an intuitive color LCD touch screen. Tap icons to select functions, swipe to navigate through lists or clock faces, and use the back arrow icon to return to the previous screen.



Image: Close-up of the Kipcush D2's intelligent touch screen interface.

## 5.2. Selecting Sleep Sounds

The device offers 24 scientifically researched sleep sounds, including white noises, ambient noises, sounds of nature, and lullabies. From the main menu, tap the 'White Noises' icon or other sound categories to browse and select your desired sound. Tap a sound to play it.




Image: Kipcush D2 displaying sound selection options on its touch screen.



*Image: Kipcush D2 showcasing its 24 soothing sound options.*

Your browser does not support the video tag.

*Video: This video demonstrates the Kipcush D2 Portable White Noise Sound Machine's various features, including sound selection, alarm clock settings, and overall user interface navigation.*

### 5.3. Using the Favorites Feature

While a sound is playing, tap the heart-shaped button on the screen to add it to your favorites. To access your saved sounds, navigate to the 'Favorites' menu. This allows for quick and easy playback of your preferred sounds.



*Image: Kipcush D2 displaying the favorites menu on its touch screen.*

### 5.4. Adjusting Volume

Use the volume up and down icons on the screen to precisely adjust the sound level from 0% to 100%. The device offers high-quality sound output.



*Image: Kipcush D2 showing its precision volume control interface.*

### 5.5. Breathing Exercises

The Kipcush D2 includes a professional breath training function with 5 different modes (e.g., Sleep pattern 4-7-8, Stress pattern 3-4-5, Calm pattern 4-6, Mind & Body pattern 4-4, Relax pattern 4-4). Navigate to the 'Breath Training' menu, select a mode, and follow the on-screen visual and audio guidance to achieve relaxation.

## Built-in Professional Breath Training Function

### 5 Breathing Training Modes

4-7-8 3-4-5 4-8 5-7 3-4



Image: Person meditating with the Kipcush D2, demonstrating the breath training function.

Your browser does not support the video tag.

Video: This video illustrates the Kipcush D2 Portable White Noise Sound Machine's integrated breathing training function, showing how to select and use different breathing patterns for relaxation.

## 5.6. Setting Alarms

Access the 'Alarms' menu to set multiple alarms. You can customize the alarm time, choose from various alarm sounds, set repeat days, and configure snooze time and count.




Image: Kipcush D2 displaying alarm settings on its touch screen.

## 5.7. Setting Timers

The 'Timers' menu allows you to set countdown timers for various durations. This is useful for short relaxation sessions or as a reminder.

## 5.8. Snooze Function

When an alarm sounds, you can activate the snooze function by simply flipping the device over. This will pause the alarm for the set snooze duration.

## Intelligent Touch Design

Navigate with ease



Image: Kipcush D2 demonstrating the 'Flip to Snooze' feature.

## 6. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port is free of dust and debris.
- Store the device in a cool, dry place when not in use for extended periods.

## 7. TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the device is fully charged. Connect to a power source using the USB-C cable.
No sound output.	Check the volume level. Ensure a sound is selected and playing.
Touch screen unresponsive.	Restart the device by holding the power button. If the issue persists, contact customer support.
Alarm not sounding.	Verify alarm settings (time, days, sound, volume). Ensure the alarm is enabled.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Kipcush
Model Number	D2
Color	Gray
Display Type	Intelligent Color LCD Touch Screen
Product Dimensions	1"W x 1"H (Note: This seems to be a placeholder, actual dimensions might vary)
Power Source	Battery Powered (Rechargeable)
Material	Polypropylene (PP)

Feature	Detail
Item Weight	0.47 Kilograms
Alarm Clock	Yes
Breathing Exercises	Yes (5 modes)
Soothing Sounds	24 (White Noises, Ambient Noises, Sounds of Nature, Lullabies)

## 9. WARRANTY AND SUPPORT

---

Kipcush products come with a lifelong warranty. If you have any questions, encounter issues, or require assistance with your Kipcush D2 Portable White Noise Sound Machine, please contact our customer support team. We are committed to providing support and ensuring your satisfaction.

For support, please visit the Kipcush store on Amazon or refer to the contact information provided with your purchase.