TracFone T435D

Tracfone TCL FLIP 3 User Manual

Model: T435D | Brand: TracFone

Introduction

The Tracfone TCL FLIP 3 (Model T435D) is a modern flip phone designed for simplicity and essential communication. It combines the familiar flip-phone form factor with updated technology, including dual displays and 4G LTE connectivity. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your device.

What's in the Box

Upon opening your Tracfone TCL FLIP 3 package, please ensure all the following items are present:

- TCL Flip 3 Handset
- USB Cable (for charging and data transfer)
- Quick Start Guide





Image: The TCL FLIP 3 flip phone in its open position, showing the main display and keypad. This is the primary component of your package.

Setup

1. Charging the Battery

Before first use, fully charge the phone's 1850 mAh Lithium Ion battery. Connect the provided USB cable to the phone's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The battery

indicator on the screen will show charging progress.

2. Powering On/Off

To power on, press and hold the Power/End Call button until the screen illuminates. To power off, press and hold the Power/End Call button, then select 'Power off' from the options.



Image: The TCL FLIP 3 alongside Tracfone branding, indicating the phone is ready for activation with a Tracfone plan. Plans are sold separately.

Operating Your Phone

Making Calls

1. Open the flip to activate the main screen.
2. Dial the desired phone number using the keypad.
3. Press the green Call button to initiate the call.
4. To end a call, press the red End Call button.

Sending Text Messages

1. Navigate to the 'Messages' application from the main menu.
2. Select 'New Message' or 'Create Message'.
3. Enter the recipient's phone number or select from contacts.
4. Type your message using the keypad.
5. Press 'Send'.

Using the Camera

The TCL FLIP 3 features a 5MP video-capable camera. To access the camera, navigate to the 'Camera' application. You can take photos or record videos directly from this application.



Image: The TCL FLIP 3 in a closed position, highlighting its external display which shows the current time, date, and battery status. The

camera lens is visible above the external screen.

Maintenance

Cleaning Your Phone

Use a soft, lint-free cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials, as they may damage the device.

Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture or disassemble the battery.
- If the battery appears damaged or swollen, discontinue use and contact support.

Troubleshooting

Problem	Possible Solution
Phone does not power on	Ensure the battery is charged. Connect to a charger and try again.
No network signal	Check if you are in an area with network coverage. Restart the phone. Verify your Tracfone plan is active.
Poor call quality	Move to an area with better signal. Ensure nothing is obstructing the microphone or speaker.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background data usage.

Specifications

Feature	Detail
Model Number	T435D
Operating System	KaiOS 3.1
Display Size	1.77 Inches (Standing screen display size)
Resolution	128 x 160
Camera	5MP (Video Capable)
Battery Capacity	1850 mAh Lithium Ion
Talk Time	Up to 14 Hours
Connectivity	4G LTE, Bluetooth, Wi-Fi, GSM/UMTS/LTE
Memory (RAM)	1 GB
Storage Capacity	1 GB
Color	Stone Gray

Feature	Detail
Item Weight	12.3 ounces
Manufacturer	TCL

Warranty and Support

For warranty information and technical support regarding your Tracfone TCL FLIP 3, please refer to the documentation included with your device or visit the official Tracfone website. Tracfone offers customer support to assist with activation, plan inquiries, and device troubleshooting.
You can also find more information and support resources by visiting theTracfone Store on Amazon.

© 2025 TracFone. All rights reserved.