

[manuals.plus](#) /› [Kikkaboo](#) /› [Kikkaboo Clyde 2-in-1 Sterilizer and Steamer Instruction Manual](#)**Kikkaboo Clyde 31304020017**

Kikkaboo Clyde 2-in-1 Sterilizer and Steamer Instruction Manual

Model: 31304020017

INTRODUCTION

The Kikkaboo Clyde 2-in-1 Sterilizer and Steamer is designed to simplify the process of sterilizing baby bottles and accessories, as well as steaming food. This appliance offers two distinct modes: steam sterilization for up to five baby bottles and small accessories, and a steaming function for heating or cooking food. Its compact and portable design ensures convenience, while its effective steam action reliably eliminates bacteria and germs. The transparent lid allows for observation during operation. Please read this manual thoroughly before first use to ensure safe and proper operation.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury. Read all instructions carefully before using the appliance.

- **Read all instructions:** Familiarize yourself with the appliance's operation before use.
- **Keep out of reach of children:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- **Electrical safety:** Do not immerse the base unit, cord, or plug in water or other liquids. Do not operate the appliance with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- **Hot surfaces:** Surfaces are subject to residual heat after use. Do not touch hot surfaces. Use handles or oven mitts. Always allow the appliance to cool completely before cleaning or storing.
- **Water usage:** Use only distilled or purified water in the heating plate to prevent limescale buildup and ensure efficient operation. Do not add any other liquids or additives.
- **Ventilation:** Ensure adequate ventilation around the appliance during operation. Do not place it against a wall or under cabinets.
- **Unplug when not in use:** Always unplug the appliance from the outlet when not in use and before cleaning.
- **Intended use:** This appliance is designed for household use only for sterilizing baby bottles and accessories, and steaming food. Do not use it for any other purpose.
- **Placement:** Place the appliance on a stable, level, heat-resistant surface, away from edges and heat sources.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Kikkaboo Clyde 2-in-1 Sterilizer and Steamer:

- **Base Unit:** Contains the heating plate and electrical components.
- **Bottle Rack (Lower Basket):** Designed to hold baby bottles during sterilization.
- **Accessory Tray (Upper Basket):** For smaller items like pacifiers, teats, or for holding a bowl during steaming.
- **Lid:** Transparent cover to contain steam and observe the process.
- **Control Knob/Power Button:** Used to turn the appliance on/off and select modes.



Image 1: The Kikkaboo Clyde 2-in-1 Sterilizer and Steamer configured for sterilization, showing the clear upper chamber with bottle posts.



Image 2: The Kikkaboo Clyde 2-in-1 Sterilizer and Steamer in sterilization configuration, highlighting the control knob on the base unit.



Image 3: The Kikkaboo Clyde 2-in-1 Steamer configured for steaming, showing the shorter upper chamber with a bowl for food.

SETUP AND FIRST USE

Before using your Kikkaboo Clyde 2-in-1 Sterilizer and Steamer for the first time, follow these steps:

- 1. Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
- 2. Clean:** Wash the bottle rack, accessory tray, and lid in warm soapy water. Rinse thoroughly and allow to air dry. Wipe the base unit with a damp cloth. Do not immerse the base unit in water.
- 3. Placement:** Place the base unit on a clean, dry, stable, and heat-resistant surface. Ensure it is away from children and other heat sources.
- 4. Initial Sterilization Cycle (Recommended):** For the first use, it is recommended to run a sterilization cycle without any items inside. Add 70-100ml of distilled water to the heating plate, assemble the unit with the empty bottle rack and lid, plug it in, and turn it on. Allow the cycle to complete, then unplug and let it cool.

OPERATING INSTRUCTIONS

Sterilization Mode

This mode is used for sterilizing baby bottles, pacifiers, teats, and other small accessories.

- 1. Prepare Items:** Ensure all bottles and accessories are thoroughly cleaned before placing them in the sterilizer.
- 2. Add Water:** Pour approximately 70-100ml of distilled or purified water onto the heating plate of the base unit. Do not overfill.
- 3. Load Items:** Place bottles upside down on the bottle rack's posts. Arrange smaller accessories (teats, pacifiers, bottle rings) on the accessory tray.
- 4. Assemble:** Place the bottle rack onto the base unit, then place the accessory tray on top of the bottle rack. Finally,

cover with the lid, ensuring it is securely seated.

- Start Cycle:** Plug the appliance into a suitable power outlet. Turn the control knob to the 'Sterilize' position or press the power button to start the sterilization cycle. An indicator light may illuminate.
- Completion:** The cycle will automatically complete when the water has evaporated. The appliance may turn off automatically, or the indicator light will switch off.
- Cool Down and Remove:** Allow the appliance to cool down for several minutes before opening the lid. Use tongs to carefully remove sterilized items to avoid burns.

Steaming/Heating Mode

This mode is suitable for steaming baby food or heating small portions.

- Add Water:** Pour approximately 70-100ml of distilled or purified water onto the heating plate of the base unit.
- Prepare Food:** Place the food to be steamed or heated into a heat-safe bowl.
- Load Food:** Place the accessory tray onto the base unit (without the bottle rack). Place the bowl with food onto the accessory tray.
- Assemble:** Cover the unit with the lid, ensuring it is securely seated.
- Start Cycle:** Plug the appliance into a suitable power outlet. Turn the control knob to the 'Steam' or 'Heat' position, or press the power button to start the steaming cycle.
- Monitor and Remove:** Monitor the steaming process. The duration will depend on the type and quantity of food. Once steaming is complete, turn off the appliance and unplug it. Carefully remove the lid and the bowl using oven mitts or tongs.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your appliance.

- Always unplug:** Before cleaning, always unplug the appliance from the power outlet and allow it to cool completely.
- Base Unit:** Wipe the exterior of the base unit with a damp cloth. Do not use abrasive cleaners or immerse the base unit in water.
- Removable Parts:** The bottle rack, accessory tray, and lid can be washed in warm soapy water. Rinse thoroughly and allow to air dry. These parts may also be suitable for dishwasher cleaning (check product markings for specific instructions).
- Descaling:** Over time, mineral deposits (limescale) may build up on the heating plate, especially if tap water is used. To descale, mix 50ml of white vinegar with 100ml of water, or use a citric acid solution according to package instructions. Pour the solution onto the heating plate and let it stand for 30 minutes to 1 hour. Do not turn on the appliance during descaling. Pour out the solution, then wipe the heating plate clean with a damp cloth. Rinse by running a short cycle with clean water. Perform descaling every 2-4 weeks depending on water hardness and frequency of use.

TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common problems and solutions:

- Appliance does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the control knob is set to an 'On' position or if the power button has been pressed.
- Sterilization/Steaming not effective or cycle stops too quickly:**

- Verify that the correct amount of water (70-100ml) was added to the heating plate.
- Ensure the lid is properly seated and sealed to contain the steam.
- Check for excessive limescale buildup on the heating plate and perform descaling if necessary.

- Excessive limescale buildup:**

- This is normal with regular use, especially with hard water. Refer to the 'Cleaning and Maintenance' section for descaling instructions.
- Use distilled or purified water to minimize limescale formation.

- Steam leakage:**

- Ensure the lid is correctly positioned and fully closed.
- Check if the accessory tray or bottle rack are properly aligned.

If the problem persists after attempting these solutions, please contact Kikkaboo customer support.

SPECIFICATIONS

Model Number	31304020017
Product Dimensions (L x W x H)	16 x 17 x 34 cm
Product Weight	1.2 kg
Capacity	4-5 baby bottles and accessories
Functions	Steam Sterilization, Steam Cooking/Heating

WARRANTY AND SUPPORT

This Kikkaboo product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Kikkaboo website. If you require technical assistance, have questions about operation, or need to report a defect, please contact Kikkaboo customer support through their official channels. Please have your model number (31304020017) and proof of purchase available when contacting support.